CAUTION

Be sure to attach the protective cover and fix with the screws.

If the protective cover is not attached, this unit will not turn on.

ATTENTION

Veillez à placer le cache de protection et à fixer avec les vis.

Si le couvercle de protection n'est pas installé, cet appareil ne s'allume pas.

ACHTUNG

Bringen Sie unbedingt die Schutzabdeckung an und befestigen Sie sie mit den Schrauben.

Wenn die Schutzabdeckung nicht angebracht ist, lässt sich das Gerät nicht einschalten.

↑ LET OP

Zorg ervoor dat u de beschermkap bevestigt en vastmaakt met de schroeven.

Als de beschermkap niet is bevestigd, zal deze unit niet ingeschakeld worden.

ATTENZIONE

Assicurarsi di applicare il coperchio di protezione e di fissarlo con le viti.

Se il coperchio di protezione non è applicato, questa unità non si accenderà.

⚠ PRECAUCIÓN

Asegúrese de colocar la cubierta protectora y fijarla con los tornillos.

Si la cubierta protectora no está colocada, esta unidad no se encenderá.

⚠ ATENÇÃO

Certifique-se de que monta a tampa de proteção e a fixa com os parafusos.

Se a tampa de proteção não estiver colocada, esta unidade não se liga.

∧ осторожно!

Обязательно установите защитную крышку и закрепите ее винтами.

Если защитная крышка не установлена, устройство не включится.

↑ UWAGA

Pamiętaj, aby założyć pokrywę ochronną i zamocować ją śrubami.

Bez założenia pokrywy ochronnej włączenie tego urządzenia będzie niemożliwe.

↑ POZOR

Nezapomeňte nasadit ochranný kryt a přišroubovat jej.

Pokud ochranný kryt nenasadíte a nepřipevníte, jednotka se nezapne.

↑ VIGYÁZAT


Mindenképpen helyezze fel a védőburkolatot, és rögzítse a csavarokkal.

Ha a védőburkolatot nem helyezte fel, a készülék nem kapcsol be.

MUPOZORNENIE

Nezabudnite pripojiť ochranný kryt a upevniť ho pomocou skrutiek.

Ak sa ochranný kryt nepripojí, táto jednotka sa nezapne.





DMX1057XR DMX1037S

MONITOR WITH RECEIVER

INSTRUCTION MANUAL

JVCKENWOOD Corporation

- Updated information (the latest Instruction Manual, system updates, new functions, etc.) is available from
 - https://www.kenwood.com/cs/ce/>.
- The Instruction manual is subject to change for modification of specifications and so forth. Be sure to download the latest edition of the Instruction manual for reference.
 - https://manual.kenwood.com/edition/im406/

Take the time to read through this instruction manual.

Familiarity with installation and operation procedures will help you obtain the best performance from your new receiver.

For your records

Record the serial number, found on the top of the unit, in the spaces designated on the warranty card, and in the space provided below. Refer to the model and serial numbers whenever you call upon your KENWOOD dealer for information or service on the product.

Model DMX1057XR / DMX1037S Serial number _____

US Residence Only

Register Online

Register your KENWOOD product at www.kenwood.com/usa/

Contents

| Before Use 4 |
|---|
| Precautions4 |
| How to read this manual4 |
| Basic Operations 5 |
| Functions of the Buttons on the Front Panel $\dots 5$ |
| Turning on the Unit6 |
| Initial Settings6 |
| Adjusting the volume8 |
| Touch screen operations8 |
| HOME screen descriptions8 |
| Popup menu9 |
| Source selection screen description9 |
| Source control screen descriptions11 |
| List screen12 |
| Alert Message13 |
| Widget 14 |
| Widget14 |
| Drive Widget Panel14 |
| Importing Image Files15 |
| APPS 16 |
| Wireless Mirroring Operation16 |
| Apple CarPlay Operation16 |
| Android Auto Operation18 |
| KENWOOD Traffic Powered By INRIX20 |

| USB | 21 |
|---|----|
| Connecting a USB device | 21 |
| USB Basic Operation | 21 |
| Search Operation | 23 |
| iPod/iPhone | 24 |
| Preparation | 24 |
| iPod/iPhone Basic Operation | 25 |
| Search Operation | 26 |
| HD Radio™Tuner | 27 |
| HD Radio Tuner Basic Operation | 27 |
| Receive Mode | 29 |
| Memory Operation | 29 |
| Selecting Operation | 29 |
| Bookmark | 31 |
| SiriusXM® | 32 |
| SiriusXM® Basic Operation | 32 |
| Storing Channels in Preset Memory | 34 |
| Preset select | 34 |
| Direct search | 34 |
| Category/Channel search | 35 |
| Replay | 35 |
| TuneMix™ | 36 |
| $SmartFavorites, Tune Start ^{\intercal \!$ | |
| TuneScan [™] | |
| Traffic & Weather Now™ | 37 |
| Content Alerts | 37 |
| SportsFlash™ | 38 |
| SiriusXM SETUP | 30 |

| Bluetooth Control | 44 |
|--|-----|
| Information for using Bluetooth® devices | s44 |
| Register the Bluetooth device | 45 |
| Bluetooth Setup | 47 |
| Playing the Bluetooth Audio Device | 48 |
| Using the Hands-Free Unit | 50 |
| Hands-Free Setup | 55 |
| Other External Components | 56 |
| View Camera | 56 |
| Use Dashboard Camera | 58 |
| External audio/video players (AV-IN) | 59 |
| HDMI source | 59 |
| OEM Features Operation | 60 |
| Setup | 61 |
| Monitor Screen Setup | 61 |
| Connections & AV Setup | 61 |
| Display & Button Setup | 63 |
| User Interface Setup | 64 |
| System Setup | 65 |
| Controlling Audio | 67 |
| 3-way speaker system setup | 67 |
| Speaker / X'over setup | 68 |
| Equalizer Control | |
| Listening Position / DTA | 70 |
| Fader / Balance / Zone Control | 72 |
| Volume Offset | 74 |
| Sound Effect | 74 |
| Parametric Equalizer | 75 |
| Audio Setup memory | 78 |
| | |

| Remote control | 79 |
|---|-----|
| Battery Installation | 79 |
| Functions of the Remote control Buttons | s79 |
| Connection/Installation | 82 |
| Before Installation | 82 |
| Installing the unit | 85 |
| Troubleshooting | 95 |
| Problems and Solutions | 95 |
| Error Messages | 95 |
| Appendix | 97 |
| Playable Media and Files | 97 |
| Specifications | 99 |
| About this Unit | 102 |

Before Use

Precautions

A WARNINGS

To prevent injury or fire, take the following precautions:

- To prevent a short circuit, never put or leave any metallic objects (such as coins or metallic tools) inside the unit.
- Do not watch or fix your eyes on the unit's display when you are driving for any extended period.
- If you experience problems during installation, consult your KENWOOD dealer.

Precautions on using this unit

- When you purchase optional accessories, check with your KENWOOD dealer to make sure that they work with your model and in your area.
- You can select a language to display menus, audio file tags, etc. See System Setup (P.65).
- The Radio Broadcast Data System feature won't work in areas where the service is not supported by any broadcasting station.

Protecting the monitor

• To protect the monitor from damage, do not operate the monitor using a ball point pen or similar tool with a sharp tip.

Cleaning the unit

 If the faceplate of this unit is stained, wipe it with a dry soft cloth such as a silicon cloth.
 If the faceplate is stained badly, wipe it with a cloth moistened with neutral cleaner, then wipe it again with a clean soft dry cloth.

NOTE

 Applying spray cleaner directly to the unit may damage its mechanical parts. Wiping the faceplate with a hard cloth or using a volatile liquid such as thinner or alcohol may scratch the surface or erase the screened print.

Acquiring GPS signal

The first time you turn on this unit, you must wait while the system acquires satellite signals for the first time. This process could take up to several minutes. Make sure your vehicle is outdoors in an open area away from tall buildings and trees for fastest acquisition. After the system acquires satellites for the first time, it will acquire satellites quickly each time

■ About GLONASS

thereafter

This unit uses Global Navigation Satellite System (GLONASS) in addition to GPS.

Combining GPS and GLONASS can refine positioning accuracy than using GPS only.

■ Caution for Smartphone Users

Simultaneously running multiple applications on your smartphone while screen sharing places heavy demand on the microprocessor of the phone, potentially affecting communication and performance.

For best results while pairing with your KENWOOD receiver, please be sure to close any unused applications.

How to read this manual

 The screens and panels shown in this manual are examples used to provide a clear explanation of operations.


For this reason, they may be different from the actual screens or panels, or some display patterns may be different from the actual ones.

Display language: English is used for the purpose of explanation. You can select a display language from the **SETUP** menu. See *System Setup (P.65)*.

4

Basic Operations

Functions of the Buttons on the Front Panel



| Number | Name | Motion |
|--------|------------------|--|
| 1 | Remote Sensor | Receives the remote control signal. |
| 2 | HOME/ U | Displays the HOME screen (P.8). Pressing for 1 second turns the power off. When the power is off, turns the power on. |
| 3 | CAM | Switches view camera display on/off. The camera whose view is displayed first changes according to the Camera Assignment Settings (P.56) and the shift lever position in the shift gate. The camera whose view was displayed last is kept and the same camera view will be displayed the next time. If its assignment setting is changed, the rear camera view is displayed. |
| 4 | MENU/ATT | Displays the popup menu screen. Pressing for 1 second switches attenuation of the volume on/off. |
| 5 | Volume knob | • Adjusts the volume. (P.8) |
| 6 | == | Displays the APP (Apple CarPlay/Android Auto/Wireless Mirroring) screen. While the APP screen is displayed, switches to the control screen of current source. |
| 7 | VOICE | Switches the voice recognition function on/off. See (P.18, 20, 52). When neither Apple CarPlay, Android Auto, nor a Bluetooth Hands-Free phone is connected, pressing and holding displays Bluetooth pairing waiting dialog. (P.45) |

Turning on the Unit

1 Press the HOME/也 button.



- ➤ The unit is turned on.
- To turn off the unit:
- 1 Press the HOME/ button for 1 second.

NOTE


 If it is your first time to turn the unit on after installation, it will be necessary to perform Initial SETUP (P.6).

Initial Settings

Initial SETUP

Perform this setup when you use this unit first time.

1 Set each item as follows.



Language

Select the language used for the control screen and setting items. Default is "American English(en)".

- 1 Touch Language.
- 2 Touch Language Select.
- 3 Select the desired language.
- 4 Touch 6.

For details, see System Setup (P.65).

■ Clock

Sets the synchronization of the clock and adjusts it.

For details, see *Calendar/clock settings* (P.7).

■ Display & Button

Set the button illumination color.

- 1 Touch Display & Button.
- 2 Touch Button Illumination Color.
- (3) Select the desired color.
- 4 Touch 6.

For details, see *Display & Button Setup* (P.63).

■ Camera

Set the parameters for the camera.

- 1) Touch Camera.
- ② Set each item and touch 5.

For details, see Camera Setup (P.56).

■ OEM SETUP

This function requires a commercial adaptor. Consult your KENWOOD dealer for details.

■ DEMO

Set the demonstration mode. Default is "ON".

2 Touch Finish.



NOTE

• These settings can be made from the SETUP menu. See **Setup** (**P.61**).

Calendar/clock settings

- 1 Press the HOME/ button.
- 2 Touch .
- 3 Touch SETUP.

> SETUP Menu screen appears.

- 4 Touch System.
 - > System setting menu appears.
- **5** Set each item as follows.
 Scroll the page to show hidden items.



■ Time Format

Select the time display format.

12-Hour (Default)/24-Hour

■ Clock

GPS-SYNC (Default): Synchronizes the clock time with the GPS.

Manual: Set the clock manually.

■ Time Zone

Select the time zone.

■ Clock Adjust

If you select **Manual** for Clock, adjust the date and time manually. **(P.7)**

NOTE

 Please set the date and time. If they are not set, some functions may not work.

Adjust the date and time manually


- 1 Touch **Clock** in the System setting menu.
- 2 Select Manual.
- 3 Touch **Time Zone** in the System setting menu.
- 4 Select the time zone.
- 5 Touch Clock Adjust in the System setting menu.
- 6 Adjust the date, then adjust the time.



7 Touch Set.

Adjusting the volume

You can adjust the volume (0 to 40). Turn the knob clockwise to increase, and counter-clockwise to decrease.



Touch screen operations

To perform operations on the screen, you need to touch, touch and hold, flick or swipe to select an item, display a setting menu screen or change pages.

Touch

Touch the screen gently to select an item on the screen.



Touch and hold

Touch the screen and keep your finger in place until the display changes or a message is displayed.



Flick

Slide your finger quickly to the left or right on the screen to change the page. You can scroll a list screen by flicking up/down on the screen.



Swipe

Slide your finger up or down on the screen to scroll the screen.



HOME screen descriptions


Most functions can be performed from the HOME screen.



- Widget **(P.14)**
- Displays the source selection screen. (P.10)
- Displays the SETUP Menu screen. (P.61)
- Short-cut playback source icons (P.11)

Display the HOME screen

1 Press the HOME/ button.




➤ HOME screen appears.

Popup menu

- 1 Press the MENU/ATT button.
 - ➤ Popup menu appears.
- 2 Touch to display the popup menu.



The contents of the menu are as follows.



Turn off the screen

1 Select **Display OFF** on the popup menu.



NOTE

- · Touch the display to turn on the screen.
- To display the clock while the screen is off, it is necessary to set "OSD Clock" to "ON". (P.63)

Source selection screen description

You can display icons of all playback sources and options on the source selection screen.



- · Changes playback sources. П For playback sources, see Select the playback source (P.10).
- 2 Changes pages. (Touch ⟨/⟩.) You can also change pages by flicking left or right on the screen.
- · Returns to the previous screen. 3
- · Displays the SETUP Menu screen. (P.61) 4

Select the playback source

- Press the HOME/७ button.
 ➤ HOME screen appears.
- 2 Touch .

From the screen, you can select the following sources and functions.

| HD Radio | • Switches to the HD Radio broadcast. (P.27) |
|--------------------|---|
| E Apple CarPlay | Switches to the Apple CarPlay screen from the connected iPhone. (P.16) |
| Android Auto | Switches to the Android Auto screen from the connected Android smartphone. (P.18) |
| TEL | Displays the Hands-Free screen. (P.50) When neither Apple CarPlay, Android Auto, nor a Bluetooth Hands-Free phone is connected, displays Bluetooth pairing waiting dialog.*1 (P.45) |
| Wittless Mitroring | Switches to the Wireless Mirroring screen from the connected Android smartphone. (P.16) |
| SiriusXM | Switches to the SiriusXM® satellite radio broadcast. (P.32) |
| Bluetooth | • Plays a Bluetooth audio player. (P.48) |
| iPod | • Plays an iPod/iPhone. (P.24) |
| USB | • Plays files on a USB device. (P.21) |
| Ģ HDMI | Plays a device connected to the HDMI input terminal. (P.59) |
| AV-IN | Switches to an external component connected to the AV Audio input and the Video input terminal.*2*3 (P.59) |
| 71 | • Puts the unit in standby. (P.10) |

- For sources and information displayed when an iDatalink is connected, see *OEM Features Operation* (*P.60*).
- *1 When connecting as Apple CarPlay or Android Auto, it works as a phone provided in Apple CarPlay or Android Auto. If Apple CarPlay or Android Auto are connected during talking by the Bluetooth device or iDatalink phone, the current call will be continued.
- *2 You can use the **AV-IN** source when a cable from a visual source except a camera is connected to the Video input terminal, and a cable is connected to the AV Audio input terminal. **(P.91)**
- *3 Set "VIDEO IN" to "None" in Camera Assignment Settings. (P.57)

Put the unit in standby

- 1 Press the HOME/₺ button.
 ➤ HOME screen appears.
- 2 Touch .
- 3 Touch STANDBY.



Customize Short-cut source icons

You can arrange the positions of the source icons as you like.

The 4 items placed in bottom line will appear on the bottom bar in various screens, as the short-cut playback source icons.

- 1 Press the HOME/ button. ➤ HOME screen appears.
- 2 Touch #
- 3 Touch and hold the icon which you want to move in the customizing mode.
- 4 Drag the icon to the desired position.



Changes the page





Source control screen descriptions

There are some functions which can be performed from most screens.



П

Displays the source selection screen. (P.9)

2 🔯

Displays the SETUP Menu screen. (P.61)

3 Short-cut source icons

The source changes to the one you have set with a short-cut. For the short-cut setting, refer

to Customize Short-cut source icons (P.11).

4 Function panel *

Touch the right side of the screen to display the function panel. Touch again to close the panel.



Connected Bluetooth device information

6 Indicator items

Displays the current source condition and so on.

- ATT: The attenuator is active.
- **DUAL**: The dual zone function is active.
- MUTE: The mute function is active.
- LOUD: The loudness control function is active.

7 Content list *

Displays the track/file/station/channel list.

8 Operation keys

You can operate the current source with these operation keys. The available functions are different depending on the source type.

Basic Operations

* For right hand drive vehicles, the left and right drawers are swapped. For how to set up the driving position, see *User Interface Setup* (*P.64*).

List screen

There are some common function keys in the list screens of most sources. See (*P.23, 26, 49*).

Display the list screen

For USB/iPod:

- 1 Touch Q or the item listed on the information area in the source control screen.
 - ➤ The list screen appears.

For Bluetooth audio:

- 1 Touch Q.
 - ➤ The list screen appears.

You can use following operation keys from this screen.



Displays the list type selection window.

2 1 📙

Displays a music/movie file list.



Keys with various functions are displayed here.

- Play: Plays all tracks in the folder containing the current track.
- • Az : Jumps to the letter you entered (alphabetical search).
- Top I Up : Moves to the upper hierarchy level.

4 Text scroll

Scrolls the displayed text.

5 ^ / ∨ / 木 / 坐 Page scroll

You can change pages to display more items by touching ^/ .

• ► ✓ : Displays the top or bottom page.



Returns to the previous screen.

NOTE

• Depending on the current source or mode, some function key may not appear.

Alert Message

This function is to receive alert messages. First, you need to turn on the "Emergency Alerts" on the HD Radio source control screen. (P.28)

When an Alert Message comes



- · The alert message is erased. Same alert \Box message cannot be displayed for next 10 minutes.
- The alert message is erased. Same alert 2 message cannot be displayed for next 12
- · Touch to tune to that channel of HD Radio 3 source

Display of the received Alert Message

You can read the received alert message afterward.

1 Touch on the right side of the HD Radio source control screen. Touch Alert Message Log.



2 Select the desired Alert Message from the list.



➤ The Alert Message appears.



3 Touch Close.

Widget

Widget

- 1 Press the **HOME**/[⊕] button.
- You can change the widget or customize the widget area.



1 Full screen widget panel

You can change the full screen panel widget by flicking left or right on the widget panel. The widget is switched in the following sequence: Album Art, Visualizer, Photo Frame.

2 Flexible source widget panel

- Displays the current source information and operation keys.
- While playing an audio source, you can switch the widget panel size between 2-line and 4-line by touching the right top corner of the widget panel.
- Mathematical (USB/HDMI/AV-IN/Wireless Mirroring source only):

Displays the source control screen.

(HDMI/AV-IN/Wireless Mirroring source only):

Switches the widget panel orientation between horizontal and vertical.

3 Drive widget panel

You can change the drive panel widget by touching the right top corner of the widget panel. **(P.14)**

Photo Frame Widget

You can display a slideshow of the image files stored in your iPhone or Android smartphone.

Preparation

· See Importing Image Files (P.15).

Drive Widget Panel

You can change the widget.

- 1 Press the **HOME**/ \bigcirc button.
- 2 Touch the right top corner of the drive widget panel.



- ➤ The drive widget list appears.
- **3** Touch the desired widget.

You can select from the following widgets.

- · Clock Widget
- Weather Widget *1
- · Compass Widget
- · EQ Setting Widget
- · Camera Widget
- Climate/TPMS/Radar Widget *2
- ADAS Widget *2
- *1 You can receive INRIX weather forecast by connecting your iPhone or Android smartphone in which the "KENWOOD Traffic Powered By INRIX" application is installed.
- *2 Displayable widgets vary depending on the type of the connected iDatalink (commercially available) and the model of the vehicle

• To change the widget position

You can change the widget panel position to right or left. If the drive widget panel position is changed, the full screen widget panel position and flexible source widget panel position are also changed.

1 Touch and hold the drive widget panel.

➤ Widget customize mode is activated.



2 Drag the drive widget to right or left.

Weather Widget

You can display the weather forecast of the present location.

Preparation

 See KENWOOD Traffic Powered By INRIX (P.20).

Importing Image Files

You can display image files stored in your iPhone or Android smartphone by connecting your iPhone or Android smartphone in which the "KENWOOD Portal APP" application is installed to this unit.

The image files are displayed on the photo frame widget. Also, you can set an image as the wallpaper.

See **Photo Frame Widget (P.14)** and **To register an original image (P.64)**.

Preparation

- Install the latest version of the "KENWOOD Portal APP" application on your iPhone or Android smartphone.
 - iPhone: Search for "KENWOOD Portal APP" in the Apple App Store to find and install the most current version.
- Android smartphone: Search for "KENWOOD Portal APP" in Google play to find and install the most current version.
- For details, see "KENWOOD Portal APP" application.

1 Connect the device.

- To connect a device via Bluetooth, register it as the Bluetooth device and do the App (SPP) profile setting of the connection beforehand. See Register the Bluetooth device (P.45) and Switch the connected device (P.46).
- Connect an iPhone using KCA-iP103 via the USB terminal. (P.93)
- 2 Unlock your device.

APPS

Wireless Mirroring Operation

You can display the same screen of the Android smartphone on the monitor of the unit using the Wireless Mirroring function of the Android smartphone.

Preparation

- You can use the Wireless Mirroring function with Android smartphones compatible with this function.
- This function may be called Wireless Display, Screen Mirroring, AllShare Cast, etc., depending on the manufacturer.
- The settings on the Android smartphone differ depending on the device type. For details, refer to the instruction manual supplied with your Android smartphone.
- If your Android smartphone is locked, Mirroring screen may not appear.
- If the Android smartphone is not ready for UIBC, you cannot perform touch operation.
- 1 Press the HOME/ button.
- **2** Touch **!**.
- Touch Wireless Mirroring. (P.10)The App screen is displayed.
- 4 Operate your Android smartphone to activate the Wireless Mirroring function, then connect to this unit.
- 5 Select ("DMX****") as the network to use.
 - When the connection is established, then the same screen displayed on the Android smartphone is displayed.

NOTE

- Apps is discontinued when the power is turned ON/OFF or you leave the vehicle. To restart Apps, operate the Android smartphone.
- When the Apps source is displayed, you cannot register or reconnect a Bluetooth device. Switch the Apps source to another source, and then operate the Bluetooth device.

Apple CarPlay Operation

Apple CarPlay is a smarter, safer way to use your iPhone in the car. Apple CarPlay takes the things you want to do with iPhone while driving and displays them on the screen of the product. You can get directions, make calls, send and receive messages, and listen to the music from iPhone while driving. You can also use Siri voice control to make it easier to operate iPhone.

For details about Apple CarPlay, visit https://www.apple.com/ios/carplay/.

Compatible iPhone devices

You can use Apple CarPlay with the following iPhone models.

- iPhone XS Max
- ii iioiie /io iiia/
- iPhone XS
- iPhone XR
- iPhone X
- iPhone 8 Plus
- · iPhone 7 Plus
- iPhone 7
- iPhone SE
- iPhone 6s Plus
- iPhone 6s
- iPhone 8

Connecting an iPhone

Wired connection

1 Connect your iPhone using KCA-iP103 via the USB terminal. (P.93)

When an iPhone compatible with Apple CarPlay is connected to the USB terminal, the Bluetooth Hands-Free phone currently connected is disconnected. If another Bluetooth Hands-Free phone is being used, disconnection will occur after ending the call.

2 Unlock your iPhone.

Wireless connection

You can select the iPhone registered in **Device List** and use it as the Apple CarPlay device. See *Register the Bluetooth device (P.45)*.

NOTE

- Turn on the Bluetooth function and Wi-Fi function of an iPhone.
- If two or more iPhone have been registered, select the iPhone to be used as the Apple CarPlay source. (P.17)
- It is necessary to connect the GPS antenna in order to use a wireless Apple CarPlay.
- When the Wi-Fi connection becomes unavailable, the HOME screen is displayed.
- You cannot use Apple CarPlay if the function is turned off by operating the iPhone at functional setup.

To switch the Current Screen to the Apple CarPlay Screen When Connecting Your iPhone

- Touch Apple CarPlay icon on the source selection screen. (P.10)
- Touch the following connection message if the message appears.



NOTE

- · The connection message appears when;
 - The iPhone you used previously is connected again.
 - The screen other than HOME and the source selection screen is displayed.
- The connection message is displayed for about 5 seconds.

Select an Apple CarPlay device

If two or more iPhone compatible with Apple CarPlay have been registered, select the iPhone to be used as the Apple CarPlay source. See **Switch the connected device (P.46)**.

Operation keys and available Apps on the home screen of Apple CarPlay

You can use the Apps of the connected iPhone. The items displayed and the language used on the screen differ among the connected devices.

To enter the Apple CarPlay mode, touch **Apple CarPlay** icon on the source selection screen. *(P.10)*



- 1
- Displays the home screen of Apple CarPlay.
- · Touch and hold to activate Siri.

2 Application keys

Starts the application.

3 HOME

Exits the Apple CarPlay screen and displays the Home screen.

* The icon design may change depending on the iOS version.


To exit the Apple CarPlay screen

1 Press the HOME/O button.

Use Siri

You can activate Siri.

1 Press the **VOICE** button.



2 Talk to Siri.

To deactivate

- 1 Press the **VOICE** button.
- Switch to the Apple CarPlay screen while listening to another source
- 1 Press the □■ button.



NOTE

 When listening to another source with the Apple CarPlay screen displayed, playing music in the Apple CarPlay mode will switch the current source to the Apple CarPlay source.

Android Auto™ Operation

Android Auto enables you to use the functions of your Android smartphone convenient for driving. You can easily access route guidance, make calls, listen to music, and access convenient functions on the Android smartphone while driving.

For details about Android Auto, visit https://www.android.com/auto/ and https://support.google.com/androidauto.

Compatible Android smartphones

You can use Android Auto with Android smartphones of Android version 5.0 or later. For Wi-Fi connection, Android 8.0 or later.

NOTE

 Android Auto may not be available on all devices and may not be available in all countries or regions.

About the placement of smartphone

Install the smartphone connected as Android Auto device in the place where it can receive the GPS signals.

When using Google Assistant, install the smartphone in the place where the smartphone easily catch a voice by the microphone.

NOTE

- Do not put the smartphone in a spot exposed to direct sunlight or near an air blowing out port of an air conditioner. The placement of the smartphone in such places can lead to malfunction or damage of your smartphone.
- Do not leave the smartphone in the vehicle.

Connect Android smartphone

Wired connection

Connect an Android smartphone via the USB terminal. (P.93)

To use the Hands-Free function, connect the Android smartphone via Bluetooth. When an Android smartphone compatible with Android Auto is connected to the USB terminal, the device is connected via Bluetooth automatically, and the Bluetooth Hands-Free phone currently connected is disconnected.

- **2** Unlock your Android smartphone.
- 3 Press the HOME/ button.
- **4** Touch **#**.
- 5 Touch Android Auto . (P.10)

Wireless connection

You can select the Android smartphone registered in **Device List** and use it as the Android Auto device. See **Register the Bluetooth device** (**P.45**).

- 1 Press the **HOME**/ \oplus button.
- **2** Touch **.**
- 3 Touch Android Auto . (P.10)

NOTE

- Turn on the Bluetooth function and Wi-Fi function of Android smartphone.
- If two or more Android smartphones have been registered, select the Android smartphone to be used as the Android Auto source. (P.19)
- To change the password for wireless connection manually, refer to **Reset Android Auto Wireless Connection (P.62)**.
- When the Wi-Fi connection becomes unavailable, the HOME screen is displayed.

Select an Android smartphone


If two or more Android smartphones have been registered, select the Android smartphone to be used as the Android Auto source. See **Switch the connected device** (P.46).

Operation keys and available Apps on the Android Auto screen

You can perform the operations of the Apps of the connected Android smartphone.

The items displayed on the screen differ among the connected Android smartphones.
To enter the Android Auto mode, touch the

Android Auto icon on the source selection screen. (P.10)



1 Navigation bar

Starts the application or displays information.

To exit the Android Auto screen

1 Press the **HOME** / ① button.

Using voice control

1 Press the VOICE button.




2 Start speaking.

NOTE

 When you press and hold the **VOICE** button while inputting voice, you can start over from the beginning.

To cancel

- 1 Press the **VOICE** button.
- Switch to the Android Auto screen while listening to another source
- 1 Press the □■ button.



NOTE

 When listening to another source with the Android Auto screen displayed, playing music in the Android Auto mode will switch the current source to the Android Auto source.

KENWOOD Traffic Powered By INRIX

You can receive INRIX weather forecast by connecting your iPhone or Android smartphone in which the "KENWOOD Traffic Powered By INRIX" application is installed to this unit.

Preparation

- Install the latest version of the KENWOOD Traffic Powered By INRIX application on your iPhone or Android smartphone.
 - iPhone: Search for "KENWOOD Traffic Powered By INRIX" in the Apple App Store to find and install the most current version.
 - Android smartphone: Search for "KENWOOD Traffic Powered By INRIX" in Google play to find and install the most current version.
- For details, see "KENWOOD Traffic Powered By INRIX" application.

1 Connect the device.

- To connect a device via Bluetooth, register it as the Bluetooth device and do the App (SPP) profile setting of the connection beforehand. See Register the Bluetooth device (P.45) and Switch the connected device (P.46).
- Connect an iPhone using KCA-iP103 via the USB terminal. (P.93)

NOTE

 When an Apple CarPlay is connected, you can receive INRIX traffic information and weather forecast.

USB

Connecting a USB device

Connect the USB device with the USB cable. (P.92)



- 2 Press the HOME/ button.
- **3** Touch **.**
- 4 Touch USB. (P.10)

Disconnect the USB device

- 1 Press the **HOME**/ \circlearrowleft button.
- 2 Touch a source other than USB.
- 3 Detach the USB device.

Usable USB device

You can use a mass-storage-class USB device with this unit.

The word "USB device" appearing in this manual indicates a flash memory device.

About the file system

The file system should be the one of the following.

• FAT16 • FAT32 • exFAT • NTFS

NOTE

- Install the USB device in the place where it will not affect safe driving.
- You cannot connect a USB device via a USB hub and Multi Card Reader.
- Take backups of the audio files used with this unit. The files can be erased depending on the operating conditions of the USB device.
 We shall have no compensation for any damage arising from any erased data.

USB Basic Operation

Most functions can be controlled from the source control screen and playback screen.

NOTE

 Set the remote controller mode switch to AUD mode before starting operation, see Switch the operation mode (P.79).

Control screen



Open the drawer



1 CODEC

When a high-resolution source is played, its format information is displayed.

2 Operation keys

- Q : Searches track/file. For details on search operation, see Search Operation (P.23).
- Ida I : Searches the previous/next track/

Touch and hold to fast forward or fast backward. (It will be cancelled automatically after about 50 seconds.)

- ►II : Plays or pauses.
- iii : Displays the Graphic Equalizer screen. (P.69)
- Page 1: Repeats the current track/folder. Each time you touch the key, repeat modes are switched in the following sequence:

 File repeat (), Folder repeat (), Repeat all ()

3 Content list

- Touch the left side of the screen to display the Content list. Touch again to close the list.
- Displays the playing list. When you touch a track/file name on the list, playback will start.

4 Track information

Displays the information on the current file. Only a file name and a folder name are displayed if there is no tag information.

5 Play mode indicator/Playing time

- ▶, ▶▶, etc.: Current play mode indicator Meanings of individual icons are as follows:
- ► (play), ►► (fast forward), ◄◄ (fast backward), **!!** (pause).
- For confirmation of current playing position. You can drag the circle left or right to change the playing position.

► 0:01:23 **-----** 0:05:4

6 Function panel

Touch the right side of the screen to display the function panel. Touch again to close the panel.

• Searches for the previous/next folder.

7 Artwork

The jacket of the currently playing file is displayed.

Video screen



8 File search area (Video file only)

Touch to search for the next/previous file.

9 Key display area (Video file only)

Touch to display the control screen.


Search Operation

You can search music or video files by the following operations.

- 1 Touch Q.
- 2 Touch ▼.



3 Select a list type.



NOTE

• For operations on the list screen, see List screen (P.12).

Category search

You can search for a file by selecting a category.

- 1 Touch Category List.
- 2 Select whether you search audio files or video files 🔳 .
- 3 Touch the desired category.



- > The list corresponding to your selection appears.
- 4 Touch to select the desired item in the list. Repeat this step until you find the desired file.

Link search (Audio file only)

You can search for a file of the same artist/ album/genre as that in the current track.

- 1 Touch Link Search.
- 2 Touch the desired tag type. You can select from artists, albums and genres.



- ➤ The list corresponding to your selection appears.
- 3 Touch the desired item in the content list.

Folder search

You can search for a file according to hierarchy.

- 1 Touch Folder List
- 2 Touch the desired folder.



When you touch a folder its contents are displayed.

3 Touch to select your desired item in the list. Repeat this step until you find the desired file.

iPod/iPhone

Preparation

■ Connectable iPod/iPhone

The following models can be connected to this unit.

Made for

- iPhone XS Max
- iPhone 7 Plus
- iPhone XS
- iPhone 7
- iPhone XR
- iPhone SF
- iPhone X
- iPhone 6s Plus
- iPhone 8 Plus
- iPhone 6s
- iPhone 8
- iPod touch (6th generation)

NOTE

- Latest compatible list of iPod/iPhone. For details, see www.kenwood.com/cs/ce/ipod/.
- By connecting your iPod/iPhone to this unit with the iPod connection cable KCA-iP103 (optional accessory), you can supply power to your iPod/ iPhone as well as charge it while playing music. Note that the power of this unit must be held on.
- If you restart playback after connecting the iPod, the music that has been played by the iPod is played first.

Connect iPod/iPhone

Wired connection

Preparation

- Connect an iPod/iPhone with the KCA-iP103 (optional accessory) while Apple CarPlay is not connected.
- With an iPhone compatible with Apple CarPlay, turn off Apple CarPlay by operating the iPhone at functional setup before connecting iPhone. For details of the setup method, contact the manufacturer of the terminal.
- Plug the iPod/iPhone into the USB terminal with the KCA-iP103 (optional accessory).
- · Only one iPod/iPhone can be connected.

- Connect the iPod/iPhone using the KCAiP103. (P.93)
- 2 Press the HOME / U button.
- **3** Touch **Ⅲ**.
- 4 Touch iPod. (P.10)
- To disconnect the iPod/iPhone connected with the cable:
- 1 Detach the iPod/iPhone.

Bluetooth connection

Pair the iPhone through Bluetooth.

Preparation

- To connect an iPhone via Bluetooth, register it as a Bluetooth device and do the profile setting for the connection beforehand. See Register the Bluetooth device (P.45) and Switch the connected device (P.46).
- Connect an iPhone via Bluetooth while Apple CarPlay and an iPod/iPhone are not connected via USB.
- With an iPhone compatible with Apple CarPlay, turn off Apple CarPlay by operating the iPhone at functional setup before connecting iPhone.
 For details of the setup method, contact the manufacturer of the terminal.
- Select the method of making connections for outputting sound from the iPod source
- 1 Press the **HOME**/ \circlearrowleft button.
- 2 Touch 🖾.
- 3 Touch SETUP.
 - > SETUP Menu screen appears.
- 4 Touch Connections & AV.
 - ➤ Connections & AV setting menu appears.
- 5 Touch iPod Bluetooth Connection.

Bluetooth (Default): Output sound using a Bluetooth device.

Bluetooth+HDMI: Output sound using an HDMI device and perform music selection, etc. using a Bluetooth device.

iPod/iPhone Basic Operation

NOTE

 Set the remote controller mode switch to AUD mode before starting operation, see **Switch the** operation mode (P.79).

Control screen



Open the drawer



1 Operation keys

- Q: Searches for a track/file. For details on search operation, see **Search Operation** (P.26).
- I → I : Searches for the previous/next track/file.

Touch and hold to fast forward or fast backward. (It will be cancelled automatically after about 50 seconds.)

- ►II : Plays or pauses.
- iii : Displays the Graphic Equalizer screen. (*P.69*)
- Property : Repeats the current track/album. Each time you touch the key, repeat modes are switched in the following sequence:

 Song repeat (), All songs repeat (), Repeat off ()
- : Randomly plays all tracks in the current album. Each time you touch the key, random modes are switched in the following sequence: Song random (), Random off ()

2 Content list

- Touch the left side of the screen to display the Content list. Touch again to close the list.
- Displays the playing list. When you touch a track/file name on the list, playback will start.

NOTE

 The Content list is not displayed unless you select a file from the category list and play it. To use the category list, see **Search Operation (P.26)**.

3 Track information

- Displays the information on the current file.
- Touch to display the category list screen. See *Category search (P.26)*.

4 Play mode indicator/Playing time

- **>**, **>>**, etc.: Current play mode indicator Meanings of individual icons are as follows:
 - ► (play), ►► (fast forward), ◄◄ (fast backward), **!!** (pause).

► 0:01:23 -

 For confirmation of current playing position.
 You can drag the circle left or right to change the playing position.

5 Artwork

The jacket of the currently being played file is displayed.

Search Operation

You can search music files by the following operations.

- 1 Touch Q.
- **2** Touch **▼**.



3 Select a list type.



NOTE

• For operations on the list screen, see *List screen* (P.12).

Category search

You can search for a file by selecting a category.

- 1 Touch Category List.
- **2** Touch the desired category.



- ➤ The list corresponding to your selection appears.
- 3 Touch to select the desired item in the list. Repeat this step until you find the desired file.

Link search

You can search for a file of the same artist/ album/genre/composer as that in the current track.

- 1 Touch Link Search.
- 2 Touch the desired tag type. You can select from artists, albums, genres and composers.



- ➤ The list corresponding to your selection appears.
- 3 Touch the desired item in the content list.

HD Radio™ Tuner

HD Radio Tuner Basic Operation

Most functions can be controlled from the source control screen.

To listen to the HD Radio source, touch **HD** Radio icon on the source selection screen. (P.10)

NOTE

- Set the remote control mode switch to AUD mode before starting operation, see **Switch the operation mode (P.79)**.
- HD Radio broadcasting is for North American sales area only.

Control screen



Open the drawer



1 Operation keys

- I Tunes in a station. The method of switching frequencies can be changed (see 4
 Seek mode).
- CH▼ CH▲ : Selects a channel.
- Q: Display the Channel List screen. See *Channel search (P.30)*.
- Ei : Display a list of registered bookmarks. See **Bookmark list (P.31)**.
- iii : Displays the Graphic Equalizer screen. (P.69)

2 Preset list

- Touching (/) allows you to change the display size.
- Recalls the memorized station or channel.
- When touched for 2 seconds, stores the currently being received station or channel in the memory.

3 Band keys

Switches bands (between FM and AM).

4 Seek mode

Touch to switch seek mode in the following sequence: **AUTO1**, **AUTO2**, **MANUAL**.

- **AUTO1**: Tunes in a station with good reception automatically.
- **AUTO2**: Tunes in the memorized stations one after another.
- **MANUAL**: Switches to the next frequency manually.

5 Function panel

Touch the right side of the screen to display the function panel. Touch again to close the panel.

- 10key Direct: Display the direct station/ channel search screen. For details, see Direct search (P.30).
- AME: Presets stations automatically. For details, see Auto memory (P.29).
- **RCV**: Change the HD Radio reception mode. For details, see *Receive Mode (P.29)*.
- PTY (FM only): Searches for a program by program type. For details, see Search by program type (P.30).
- Stores the information about the song being received. See **Bookmark (P.31)**.

HD Radio™ Tuner

- Emergency Alerts: Turn on or off the alert message. See *Alert Message (P.13)*.
- Alert Message Log: Displays the alert message received. See Alert Message (P.13).

6 Picture

The picture data or station Logo data is displayed if available from current content.

7 Information display

Displays the information on the current station: Frequency and Channel

Touching allows you to switch between Content A, Content B and Content C.
Content A: Station name, Song Title, Artist Name Content B: Station Message, Radio Text Content C: PTY Genre, Album Name

8 Indicator Items

- MC: A multicast digital broadcast is being received.
- EA:

White: Emergency Alert is on.
No light: Emergency Alert is off.
Orange: Interrupting or in snooze/ignore state.

· ST: A stereo broadcast is being received.

9 Indicator display

While receiving an HD Radio station, it lights with orange when the audio is digital and lights with gray when it is analog. While receiving an analog station, it is off.



HD2/HD3

 Adjacent to traditional main stations are HD2/HD3 Channels, providing new original programming on the FM dial

Bookmark

 A music & product discovery feature that enables users to store information about content on the radio, and can deliver interactive information via OR codes

Digital Sound

 Crystal clear, CD-like digital audio quality to consumers; eliminates background noise

Program Info

 Provides song name, artist, station ID, and other relevant data to enrich the listening experience

Artist Experience

 Visual images, such as album art of over-the-air broadcasts from HD Radio stations

Emergency Alerts

 Delivers critical and life-saving messages to the public during emergency situations

Receive Mode

You can set the radio broadcasts receive mode.

1 Touch (on the right side of the screen. Touch RCV.



2 Select a receive mode.



Switch between digital and analog audio automatically.

■ Digital

Select this to tune to digital audio only.

Analog

Select this to tune to analog audio only.

Memory Operation

Auto memory

You can store stations with good reception in the memory automatically.

1 Touch desired band key.



2 Touch (on the right side of the screen. Touch AME.



3 Touch Yes.



> Auto memory starts.

Manual memory

You can store the currently being received station or channel in the memory.

- 1 Select the station or channel you wish to store in the memory.
- **2** Touch **FM**# (#:1-15) or **AM**# (#:1-5) in which you want to store the station or channel for 2 seconds until a beep sounds.

Selecting Operation

Preset select

You can list and select memorized stations or channels.

Touch on the left side of the screen. Select a station or channel from the list.



Direct search

You can tune in by entering the desired frequency or channel number.

1 Touch on the right side of the screen.
Touch 10key Direct.



2 Select the search method.



- 3 Enter the frequency or channel number.
- 4 Touch Enter.

NOTE

• To clear the number you entered, touch **BS**.

Channel search

You can specify the desired channel.

1 Touch Q.



2 Select the desired content from the list.




NOTE

• Touch **Info Change** in the channel list. Select the sequence of the list (Song title, artist name, album name).

Search by program type (FM only)

You can tune in the station broadcasting the specified type of program when listening to FM.

1 Touch on the right side of the screen.
Touch PTY.



- ➤ TUNER PTY Mode screen appears.
- 2 Select a program type from the list.
- 3 Touch Search.



You can search for the station broadcasting the selected type of program.

Bookmark

Stores tag information (title, artist, album, URL, and description) about the song you are listening to now.

Detailed information and QR codes can be displayed according to the stored tag information.

Bookmark registration

1 Touch on the right side of the screen.

Touch .



> Registers a bookmark.

NOTE

• Up to 100 bookmarks can be registered to this unit.

■ Bookmark list

Displaying a list of registered bookmarks and detailed information and QR code of the song.

1 Touch **≡**(*).



2 Select the desired bookmark from the list.



➤ The bookmark information appears.



■ **I** Delete

Deletes the bookmarks being displayed.

Touch **Delete** and then touch **YES** on the confirmation screen

Bookmark delete

Deleting a bookmark.

1 Touch Delete.



2 Select the bookmark to delete from the list.



■ ☑ AII

Select all bookmarks.

Frases all check marks.

- 3 Touch Delete.
 - ➤ Confirmation message appears.
- 4 Touch Yes.
 - ➤ All the selected bookmark(s) is deleted.

SiriusXM®

SiriusXM® Basic Operation

Only SiriusXM® brings you more of what you love to listen to, all in one place. Get over 140 channels, including commercial-free music plus the best sports, news, talk, comedy and entertainment. Welcome to the world of satellite radio. A SiriusXM Vehicle Tuner and Subscription are required. For more information, visit www.siriusxm.com.

To listen to the SiriusXM source, touch the **SiriusXM** icon on the source selection screen. **(P.10)**

Activating subscription

- · Check your Radio ID.
- The SiriusXM Satellite Radio ID is required for activation and can be found by tuning in Channel 0 as well as on the label found on the SiriusXM Connect tuner and its package.
- The Radio ID does not include the letters I, O, S or E.
- Activate the SiriusXM Connect Vehicle Tuner using either one of the two methods below:
 - For users in U.S.A.
 Online: Visit www.siriusxm.com/activatenow
 Phone: Call SiriusXM Listener Care at 1-866-635-2340
 - For users in Canada:
 Online: Visit https://www.siriusxm.ca/help/activation-help/
 - Phone: Call XM customer Care at 1-877-438-9677

NOTE

- Set the remote control mode switch to AUD mode before starting operation, see **Switch the** operation mode (P.79).
- To use SiriusXM® Satellite Radio, the optional accessory is necessary.

Control screen



Open the drawer





1 Operation keys

- Q.: Display the Category search screen. For details on search operation, see Category/ Channel search (P.35).
- CH▼ CH▲ : Selects a channel.
- iii : Displays the Graphic Equalizer screen. (P.69)

2 Preset list

- Touching (/) allows you to change the display size.
- · Recalls the memorized channel.
- When touched for 2 seconds, stores the currently being received channel in the memory.

3 Information display

Displays the information on the current channel: Channel Name

P#: Preset number

#CH: Channel number

Logo: Channel logo

Touching allows you to switch between Content A, Content B and Content C.
Content A: Artist Name, Song Title
Content B: Content Info, Category Name
Content C: Channel Description, Similar
Channels

: Touch for 2 seconds to register the artist of the current song as a Content Alert.

: Touch for 2 seconds to register the current song as a Content Alert.

For details, see Content Alerts (P.37).

NOTE

• While getting contents, "Waiting" is showing on the display.

4 Function panel

Touch the right side of the screen to display the function panel. Touch again to close the panel.

- Direct Channel: Touch and enter the desired number. For details, see Direct search (P.34).
- SETUP: Touch to display the SiriusXM SETUP screen. For details, see SiriusXM SETUP (P.38).
- Replay/Live: Touch to turn on or off the replay mode. See Replay (P.35).
- Traffic & Weather For SXV300 *1

Traffic & Weather Now™ allows you to access the latest report whenever you want to hear it. Select your city from the set up menu (see *Select a City for Traffic & Weather (P.43)*) and touch *Traffic & Weather* to check the latest report. It will start from the beginning.

• White) : Played already.

• (Green) : New information arrived.

(Purple): Playing.(Gray): No information.

For SXV200 or SXV100 *2

Turns the Traffic & Weather Jump function on or off.

White): Function on.

Playing.

• (Gray) : Function off.

• TuneScan *3: Allows you to hear a few seconds of songs from each of the

SmartFavorite music channels on the current preset band. See *TuneScan™ (P.36)*.

- TuneMix*4: When turned ON, shuffles the preset channels on P1-P6 to play a blend of songs from your favorite channels. See TuneMix™ (P.36).
- SportsFlash **4: Displays during SportsFlash™.
 Touch to cancel the SportsFlash™ function and return to the previous channel. See
 SportsFlash™ (P.38) and SportsFlash™ setup (P.42).
- *1 Compatible with SXV300 or later tuner models. It may take a few minutes after power on to get the first full report on your city. Traffic channels are not available in Canada.
- *2 When SXV200 or SXV100 is connected with this unit
- *3 Compatible with SXV200 or later tuner models.
- *4 Compatible with SXV300 or later tuner models.

5 Indicator display

6 Seek mode

Touch to switch seek mode.

- **SEEK1**: Tunes in a station with good reception automatically.
- **SEEK2**: Tunes in the memorized stations one after another.

7 Band key

Switches among bands. (SXM1/SXM2/SXM3/SXM4)

8 Artwork

Displays the album artwork for most SiriusXM music channels

Storing Channels in Preset Memory

You can store the current channel in memory.

- Tune in the channel you wish to store in the memory.
- **2** Touch on the left side of the screen.





3 Touch SXM(1-4) P(1-6) in which you want to store the channel for 2 seconds until a beep sounds.

Preset select

You can list and select memorized channels.

To select from the preset list

1 Touch on the left side of the screen. Select a channel from the list.



Direct search

You can tune in a channel directly.

1 Touch on the right side of the screen.
Touch Direct Channel.



2 Enter the channel number and touch **Enter**.



NOTE

• To clear the number you entered, touch BS.

Category/Channel search

You can specify the desired category and select a channel.

1 Touch Q.



2 Select a category.



- > Channel list appears.
- 3 Select the desired content from the list.



NOTE

- All channels in the selected category appear.
- Touching **All-Channels** displays all channels.
- Touch Info Change in the channel list. Select a desired item: content info, channel name, artist name, song
- title, category name.
- Categories which have the prefix "Featured " are Featured Favorites.
- Featured Favorites are groups of channels that are created by the SiriusXM Programming department allowing you to discover new channels. Featured Favorite channels are dynamic and can change often, allowing you to discover new channels.
 - You can set whether to be notified when the featured seasonal theme is updated. (P.43)

Replay

You can replay the last 60 minutes of the program from the current channel.

1 Touch **Replay** on the function panel.



Press to skip to the previous/next track. Press and hold to rewind or fast forward. (It will be cancelled automatically after about 50 seconds.)

■ ►II

Plays or pauses.

■ Replay time bar/Play mode indicator Displays the recorded data capacity and playback position.

▶, ▶▶, etc.: Current play mode indicator



Displays a list of recorded data on a program basis.

2 Touch Q to display an Instant Replay List screen.



■ Instant Replay List

Touching this plays back the displayed program.

LIVE: Touch to return to the live music/content.

■ Info Change

Touch **Info Change**. Select a desired item: content info, channel name, artist name, song title, category name.

To return to live music/content

- 1 Touch (on the right side of the screen.
- 2 Touch Live.

TuneMix™

TuneMix™ plays a unique blend of songs from your Preset music channels of the current SiriusXM Preset Band, allowing you to build a custom channel from as few as two to as many as 6 music channels. You can even skip songs you don't want to hear.

Touch on the right side of the screen. Touch TuneMix to set ON or OFF.



NOTE

· Compatible with SXV300 or later tuner models.

SmartFavorites, TuneStart™

Preset channels 1 through 6 of the current band are SmartFavorites channels.

The SiriusXM Vehicle Tuner automatically buffers the broadcast audio content of the SmartFavorites channels in the background.

You can rewind and replay up to 30 minutes of any of the missed news, talk, sports or music content on SmartFavorites channels. (See *Replay (P.35)*.)

When tuning in a SmartFavorites channel, songs will be played from the beginning of each track (TuneStart™). You can enable/disable TuneStart. (See *TuneStart*™ (P.431.)

NOTE

· Compatible with SXV200 or later tuner models.

TuneScan™

TuneScan[™] is a feature that plays samples from the starts of multiple buffered songs from each of the SmartFavorites channels that predominantly play music selections.

You have easy access to a large sampling of music content and can enjoy hearing a full song by stopping the scan on a song of interest.

1 Touch (on the right side of the screen.



2 Touch **TuneScan** to begin scanning your SmartFavorites channels.

You will hear a few seconds of the songs from each of the SmartFavorite channels.

While your favorite song is being played, touch TuneScan again to start listening to that song.



➤ Scan finishes and the song is played continuously.

NOTE

- To cancel TuneScan[™], touch the right side of the screen. Touch **TuneScan**.
- Touch and hold **TuneScan** to cancel TuneScan, and the music/content which was present on the channel before starting TuneScan will be played.
- Compatible with SXV200 or later tuner models.

Traffic & Weather Now™

Traffic & Weather Now™ allows you to access the latest report whenever you want to hear it. First select your city in the set up menu. See Select a City for Traffic & Weather (P.43).

1 Touch on the right side of the screen.





2 Touch Traffic & Weather.

The report starts from the beginning. To stop and return to the previous channel, touch it again.

Indicator display

- White) : Played already.
- (Green) : New information arrived.
- (Purple) : Playing.
- (Gray): No information.

NOTE

· Compatible with SXV300 or later tuner models.

Content Alerts

When a broadcast program related to the registered artist, song or team starts, an Alert Content List screen appears to allow you to switch the current channel to the relevant channel.

 When the broadcast of the registered content starts, an Alert Content List screen appears.



2 Select a content from the list.

NOTE

- Touch **Type**. Select a desired item. Artist Alert, Song Alert, GameAlert™
- To learn how to register artists and songs for the Content Alert function, see 3 Information display in *SiriusXM® Basic Operation (P.32)*.
- To learn how to set up the Content Alerts function and select Teams for alerts, see **Content Alerts setup (P.40)**.

SportsFlash™

SportsFlash™ will notify you when a big play happens during a game with one of your favorite sports teams. Choose to tune in and hear the play unfold like it was live. Continue listening to the game or return to your previous channel.

1 When a big play happens during one of the games, an Alert screen appears.



Listen

Touch to tune in that channel and play back the big play.

■ Ignore

Touch to cancel this specific SportsFlash alert. Touching **Ignore** will ignore this specific alert but will allow future alerts for this game.

Cancel

Touch to cancel SportsFlash alert. No alerts for this game will be displayed afterward.

NOTE

- Compatible with SXV300 or later tuner models.
- To learn how to set up the SportsFlash alert function, see SportsFlash™ setup (P.42).

SiriusXM SETUP

1 Touch on the right side of the screen. Touch **SETUP**.





- SiriusXM SETUP screen appears.
 See the following sections for each setting.
- Set up the parental code (P.39)
- Set up the Parental Control (P.39)
- Set up the skip channel select (P.40)
- Set up the Content Alerts (P.40)
- Set up the teams for SportsFlash™
 (P.42)
- Select the city for Traffic & Weather Jump or Traffic & Weather Now™ (P.43)
- Select the Featured Bands Update Messages (P.43)
- Set up the TuneStart[™] (P.43)
- Reset to the default settings (P.43)

Parental code

You can set a SiriusXM parental code for Parental Control.

- Touch Parental Code on the SiriusXM SETUP screen.
 - ➤ Parental Pass Check screen appears.

NOTE

- The code number is set to "0000" as default
- 2 Enter the current code number and touch Enter.



- ➤ Parental Pass 1st screen appears.
- 3 Enter the new code number and touch



- > Parental Pass 2nd screen appears.
- 4 Enter the same code number as that you entered in step 3 and touch **Enter**.
 - ➤ The code number is confirmed and the SiriusXM parental code is now set.

Parental Control

Parental Control is a feature that provides the user with the ability to prevent unauthorized access to mature content and user selected channels.

- Touch Parental Control on the SiriusXM SETUP screen.
- 2 Touch User, Mature or OFF.
 - User

Locks only the selected channels.

Mature

Locks channels classified as "mature" only.

■ OFF

Deactivates the parental mature and user locks.

3 Enter the parental code you originally input in as stated in *Parental code* (P.39) and touch **Enter**.

When selecting User

This allows you to limit access to any SiriusXM channel (Parental Lock Channel).

- 1 Touch Parental Lock Channel Selection on the SiriusXM SETUP screen.
 - ➤ Parental Pass Check screen appears.

NOTE

- You need to set up a parental code beforehand as stated in *Parental code* (P.39).
- 2 Enter the parental code you originally input as stated in *Parental code (P.39)* and touch **Enter**.
 - ➤ Parental Lock Category Select screen appears.
- **3** Touch the desired category in the list.



➤ Displays all channels in the selected category.

NOTE

- Touch All-Channels to display all channels.
- To delete the parental lock channel setting, touch **Disable All** and then touch **YES** on the confirmation screen.
- 4 Touch each channel on the list and set to ON or OFF.

ON: Locks the channel. **OFF**: Unlocks the channel.



NOTE

• Touch **Info Change**. Select a desired item: content info, channel name, artist name, song title, category name.

Skip channel select

You can set the undesired channels to skip.

- 1 Touch Skip Channel Select.
 - ➤ Skip Category Select screen appears.
- 2 Touch the desired category from the list.



➤ Displays all channels in the selected category.

3 Touch each channel in the list and set to ON or OFF.



NOTE

- To delete the skip channel setting, touch Disable All and then touch YES on the confirmation screen.
- Touch **Info Change**. Select a desired item: content info, channel name, artist name, song title, category name.
- Direct Channel and Preset Memory functions allow you to select channels.

Content Alerts setup

Activating content alert

- Touch Content Alerts on the SiriusXM SETUP screen.
 - ➤ Content Alerts is turned on or off. Default is "ON".

Selecting the content for Content Alerts

- 1 Touch Content Alerts Contents Set on the Sirius XM SETUP screen.
- 2 Select the content you want to set up.



NOTE

- To cancel all alert contents, touch **Clear** and then touch **YES** on the confirmation screen.
- Select **OFF** for the content you want to deactivate the content alert for.

3 Touch each content list item you want to check or uncheck.



NOTE

You can select (
 □) up to 60 artists or songs.

- To delete the Artist and Song
- 1 Touch Delete.



2 Touch the content(s) in the list you want to select.



■ ☑ AII

Selects all contents.

Clears all check marks.

3 Touch Delete and then touch YES on the confirmation screen.

To select a Team

Get alerted when your favorite sports team is playing on another SiriusXM channel with GameAlert™

1 Touch My Games.



2 Touch the desired league in the list.



3 Touch the team(s) in the list you want to select.



NOTE

• You can select (☑) up to 30 teams.

SportsFlash™ setup

Activating SportsFlash

- Touch SportsFlash on the SiriusXM SETUP screen.
 - ➤ SportsFlash is turned on or off. Default is "ON".

Selecting SportsFlash Beep

- 1 Touch SportsFlash Beep on the SiriusXM SETUP screen.
 - ➤ SportsFlash Beep is turned on or off. Default is "ON".

Selecting the teams for SportsFlash

- 1 Touch SportsFlash Team Set on the SiriusXM SETUP screen.
 - ➤ Team Set screen appears.
- 2 Touch Edit.



3 Touch the desired league in the list.



4 Touch each team(s) in the list you want to select.



5 Touch 4 twice.



■ Edit

Sets and removes teams.

■ Priority

Sets the priority of a team.

■ Clear

Removes all teams that have been set. Touch **Clear**. When the confirmation screen appears, touch **YES**.

NOTE

- Sports Flash $^{\rm m}$ is available on SXV300 or later tuner models.
- Up to 50 teams can be added.

Set the SportsFlash™ Team Priority

1 Touch Priority.



2 Set the priority of a team.

Each time you touch a Team, the priority is set of reset.



3 Touch Done.



NOTE

- · Priority can be set on up to 5 teams.
- When priority has already been set for 5 teams, it cannot be set for any other team. Delete an unnecessary team.

Select a City for Traffic & Weather

You can select a city for which you wish to receive SiriusXM Traffic & Weather broadcasts and hear them from the beginning.

- 1 Touch Traffic & Weather City Select on the SiriusXM SETUP screen.
- **2** Touch **◄** and **▶** to select a city.



3 Touch Close.

Selecting Featured Bands Update Messages

You can set whether to be notified when the featured seasonal theme is updated.

Touch Featured Bands Update
 Messages on the SiriusXM SETUP screen.
 Featured Bands Update Messages is turned on or off.

I TuneStart™

Touch Tune Start on the SiriusXM SETUP screen.

The TuneStart is turned on or off. Default is "ON".

Reset

- Touch SiriusXM Reset on the SiriusXM SETUP screen.
 - ➤ Confirmation screen appears.
- 2 Touch YES.
 - ➤ All SiriusXM settings are reset to defaults.

Bluetooth Control

Using the Bluetooth function allows you to use various functions such as listening to the audio file and making/receiving a call.

Information for using Bluetooth® devices



Bluetooth is a short-range wireless radio communication technology for mobile devices such as smartphones/cell-phones, portable PCs, and other devices.

Bluetooth devices can be connected without cables and communication with each other.

NOTE

- While driving, do not perform complicated operations such as dialing numbers, using the phonebook, etc. When you perform these operations, stop your car in a safe place.
- Some Bluetooth devices may not be connected to this unit depending on the Bluetooth version of the device.
- This unit may not work for some Bluetooth devices.
- Connecting conditions may vary depending on your environment.
- Some Bluetooth devices are disconnected when this unit is turned off.
- The Bluetooth devices cannot be used while using Apple CarPlay.
- The Bluetooth currently connected with other device is disconnected when an iPhone compatible with Apple CarPlay is connected.

About the smartphone/cellphone and Bluetooth audio player

This unit conforms to the following Bluetooth specifications:

Version

Bluetooth Ver. 5.0

Profiles

Smartphone/cell-phone:

HFP (V1.7) (Hands Free Profile) SPP (Serial Port Profile) PBAP (Phonebook Access Profile)

Audio player:

A2DP (Advanced Audio Distribution Profile) AVRCP (V1.6) (Audio/Video Remote Control Profile)

Sound codec

LDAC (DMX1057XR), SBC, AAC

NOTE

- The units supporting the Bluetooth function have been certified for conformity with the Bluetooth Standard according to the procedure prescribed by Bluetooth SIG.
- However, it may be impossible for such units to communicate with your smartphone/cell-phone depending on its type.

Register the Bluetooth device

It is necessary to register the Bluetooth audio player or smartphone/cell-phone in this unit before using the Bluetooth function.

You can register up to 10 Bluetooth devices.

NOTE

- · Up to 10 Bluetooth devices can be registered. If an attempt is made to register the 11th Bluetooth device, the Bluetooth device connected on the earliest date will be deleted to register the 11th
- This unit is compatible with the Apple Easy Pairing function. When an iPod touch or iPhone connected via USB terminal previously is connected again, an authentication dialog appears. Performing operation for authentication on this unit, or iPod touch or iPhone registers the smartphone as a Bluetooth device.
- 1 Press the HOME/() button.
- 2 Touch
- 3 Touch SETUP.
 - > SETUP Menu screen appears.
- 4 Touch Connections & AV.



- 5 Touch Device List.
- 6 Select a device type.



Bluetooth

To connect as Bluetooth Hands-Free and Bluetooth audio source.

Apple CarPlay

To connect as Apple CarPlay source.

Android Auto

To connect as Android Auto source.

- 7 Touch +0.
 - ➤ Bluetooth pairing waiting dialog appears.





NOTE

- If an Apple CarPlay device is currently connected. the Apple CarPlay device will be disconnected.
- · When neither Apple CarPlay, Android Auto, nor a Bluetooth Hands-Free phone is connected, pressing and holding the **VOICE** button displays Bluetooth pairing waiting dialog.
- 8 Search for the unit ("DMX****") from your smartphone/cell-phone.

Complete steps 8 to 10 within 30 seconds.

- **9** Operate your smartphone/cell-phone according to the displayed messages.
 - Confirm the request both on the smartphone/cell-phone.



Input the PIN Code in your smartphone/cell-phone.

PIN Code is set to "0000" as the default.



10 Touch Yes.

When data transmission and connection have completed, the Bluetooth connection icon appears on the screen.

NOTE

- When registering the iPhone that is available for Apple CarPlay wirelessly, a confirmation message appears
 - Yes: Displays the Apple CarPlay screen for wireless connection.
 - No: Apple CarPlay is not connected. When using Apple CarPlay, see Select an Apple CarPlay device (P.17).

Switch the connected device

If two or more Bluetooth devices have been registered, select the device to be used.

- 1 Touch Device List in the Connections & AV setting menu.
- 2 Select the device type.

■ Bluetooth

To connect as Bluetooth Hands-Free and Bluetooth audio source.

■ Apple CarPlay

To connect as Apple CarPlay source.

Android Auto

To connect as Android Auto source.

3 Touch the name of the device you want to connect.



NOTE

- If the icon is lighted, it means that the unit will use that device.
- If you touch the device name with the icon on the list of Apple CarPlay devices, it will be disconnected.
- You can quickly display the Device List screen by touching in the popup menu. (P.9)

To switch the connected device to a Bluetooth device

- 1 Touch **Bluetooth** on the Device List screen.
 - ➤ Bluetooth device list appears.
- 2 Touch the name of the Bluetooth device you want to connect.
- 3 Set each profile as follows.



■ TEL (HFP) 1, TEL (HFP) 2

Select when the device is connected with the unit as Hands-Free phone 1 or 2.

■ Audio (A2DP)/App (SPP)

Select to use as an audio player or to interwork with an application installed in a smartphone.

4 Touch Close.

To delete the registered device

You can delete the device that is registered as Bluetooth source or Apple CarPlay source. When you delete a Bluetooth device which supports Android Auto, the device is also deleted from the Android Auto device list.

1 Touch on the Device List screen.



2 Touch the device name to check.



Selects all Bluetooth devices.

Clears all check marks.

NOTE

- · You cannot select a device currently connected.
- When you select Android Auto tab, is not displayed.
- 3 Touch Delete.
 - ➤ Confirmation message appears.
- 4 Touch Yes.
 - ➤ All the selected device(s) is deleted.

Bluetooth Setup

NOTE

- The Bluetooth Setup is disabled while using Apple CarPlay.
- 1 Press the HOME/ U button.
- 7 Touch 🕮.
- 3 Touch SETUP.
 - > SETUP Menu screen appears.
- 4 Touch Connections & AV.



➤ Connections & AV setting menu appears.

5 Touch Bluetooth and set to ON.

See the following section for each setting.

- Change the PIN Code (P.47)
- Change the device name (P.47)
- · Change the settings for Hands-Free function, see Hands-Free Setup (P.55).

NOTE

· For the other setting items on this screen, see Connections & AV Setup (P.61).

Change the device name

- 1 Touch **Device Name** in the Connections & AV setting menu.
 - ➤ Change Device Name screen appears.
- 2 Touch and hold (BS).
- 3 Input the device name.



4 Touch Enter.

Change the PIN Code

- 1 Touch PIN Code in the Connections & AV setting menu.
 - ➤ Change PIN Code screen appears.
- 2 Touch and hold S.
- 3 Input the PIN Code.



4 Touch SET.

Playing the Bluetooth Audio Device

Most function can be controlled from the source control screen.

To select Bluetooth source, touch **Bluetooth** icon on the source selection screen. **(P.10)**

NOTE

- The Bluetooth audio source is disabled while using Apple CarPlay.
- The Bluetooth audio source is disabled when the device set as Audio(A2DP)/App(SPP) is using Android Auto.

Bluetooth basic operation

Control screen



1 Operation keys *

- Q : Searches for a file. See File search (P.49).
- I◀◀ ▶►I: Searches for the previous/next content

Touch and hold to fast forward or fast backward. (It will be cancelled automatically after about 50 seconds.)

- ►: Plavs.
- II: Pauses.
- iii : Displays the Graphic Equalizer screen. (P.69)
- ② : Repeats the current track/folder. Each time you touch the key, repeat modes are switched in the following sequence:
 File repeat (②), Folder repeat (②), All songs repeat (②), Repeat off (②)
- Is and omly plays all tracks in the current folder. Each time you touch the key, random modes are switched in the following sequence: Folder random (), All random (), Random off ()

2 Information display *

- Displays the name of track information.
- · Connected device name.

3 Play mode indicator/Playing time

- ▶, **II**: Current play mode indicator
- Meanings of individual icons are as follows:
- ► (play), ►► (fast forward), ◄◄ (fast backward), (pause), (stop).

4 CODEC (DMX1057XR)

When an LDAC-compatible device is connected, "LDAC" is displayed.

5 #0

Displays the Connections & AV setting menu.

6 KENWOOD Music Mix

Bluetooth audio devices can be switched easily to play music. See **KENWOOD Music Mix** (P.49).

* These items appear only when the audio player which supports AVRCP profile is connected.

NOTE

- The operation keys, indications and information displayed on the screen differ depending on the connected device.
- If the operation keys do not appear, operate from the player.
- Depending on your smartphone/cell-phone or audio player, sound may be heard and controlled but text information may not appear.
- If the volume is too low, raise it on your smartphone/cell-phone or audio player.
- It is recommended that you change the playback quality from "priority on sound quality" to "priority on stable connection" in the settings of your LDAC-compatible device so that the intermittent sound problem is less likely to occur. (DMX1057XR)

■ KENWOOD Music Mix

Up to 5 Bluetooth audio device can be connected and switched easily to play music.

- 1 Touch
 - ➤ A list of registered devices is displayed.
- 2 Touch of device name you want to connect.
 - Touching displays the Device List screen. (P.46)



- 👩 : Device used normally.
- IIII: Device used for KENWOOD Music Mix
- 3 Touch (White/dark blue background) on the left of the name of the device to be played.

The background changes from dark to light blue and starts playback.



- ► (Gray) : Not connected.
- (White/dark blue background) : Connected.
- White/light blue background) : During playback.
- 4 Touch 🔄

NOTE

- If a connected Bluetooth audio device is operated to play music, connections are switched.
- When a Bluetooth source is switched to another one, its settings are deleted and the connection is restored to the connection before source switching.
- You cannot select an Android smartphone connected as an Android Auto device.

File search

- 1 Touch Q.
- 2 Touch the desired file or folder.



When you touch a folder its contents are displayed.

Touch the desired item in the content list.Playback starts.

NOTE

• For operations in the list screen, see *List screen* (P.12).

Using the Hands-Free Unit

You can use the telephone function by connecting the Bluetooth telephone to this unit.

NOTE

- While Apple CarPlay or Android Auto is connected, the Bluetooth Hands-Free function and two Bluetooth devices connections cannot be used. Only the Apple CarPlay or Android Auto Hands-Free function can be used.
- Make a call
- 1 Press the HOME/ button.
- **2** Touch **Ⅲ**.
- 3 Touch TEL.



➤ Hands-Free screen appears.

NOTE

- If your smartphone/cell-phone supports PBAP, you can display the phonebook and call lists onto the touch panel screen when the smartphone/ cell-phone is connected.
 - Phonebook: up to 1000 entries
 - Up to 50 entries including dialed calls, received calls, and missed calls

4 Select a dialing method.



- Call using call records
- 🕒 : Call using the phonebook
- * : Call using the preset number
- 🖫 : Call by entering a phone number

Select the smartphone/cell-phone to use

When you connect two smartphones/cell-phones

- 1) Touch Device name1 Device name2 to select the phone you want to use.
- Bluetooth Setup
- 1) Touch ... Connections & AV setting menu appears. (P.47)
- Voice Recognition
- 1) Touch (P.52)

NOTE

- Status icons such as battery and antenna icons may differ from those displayed on the smartphone/cell-phone.
- Setting the smartphone/cell-phone in the private mode can disable the Hands-Free function.

Call using call records

- 1 Touch .
- **2** Select the phone number from the list.



Call using the phonebook


- 1 Touch
- 2 Touch Q A-Z
- **3** Select the initial.



- Characters with no corresponding name will not appear.
- A first character with an accent character such as "ü" can be searched for with a non-accent character "u". A character with an accent character in a sentence cannot be searched for.
- 4 Select the person you want to call from the list.



5 Select the phone number from the list.



NOTE

- You can sort the phone numbers in the list by last name or first name. For details, see *Hands-Free* Setup (P.55).
- When Russian is selected in "Language Select"
 (P.65), you can switch between English keyboard and Russian keyboard.
- When Hebrew is selected in "Language Select"
 (P.65), you can switch between English keyboard and Hebrew keyboard.
- You can search with 3 initial letters on the English keyboard and 1 initial letter on the Russian / Hebrew keyboard.

Call using the preset number

- 1 Touch 🛨
- **2** Touch the name or phone number.



Call by entering a phone number

- 1 Touch 12.
- 2 Enter a phone number with number keys.




3 Touch

■ Voice Recognition

You can access the voice recognition function of the smartphone/cell-phone connected to this unit. You can search the smartphone/cell-phone phonebook by voice. (The functionality depends on the smartphone/cell-phone.)

1 Press the **VOICE** button.



➤ Voice Recognition screen appears.

2 Start speaking.

NOTE

- You can use the voice recognition function by touching on the Hands-Free screen.
- You can use the voice recognition function for the connected smartphone/cell-phone if you selected **TEL (HFP) 1** or **TEL (HFP) 2** for HFP when registered.

Receive a call

1 Touch to answer a phone call or to reject an incoming call.



NOTE

- When shifting the gear to the reverse (R) position and monitoring the picture from the rear view camera, this screen does not appear even if a call comes in.
- The portrait registered in the phonebook is displayed while making/receiving calls and during a call.
- If you edit the phonebook on the connected device side after downloading the phonebook, the portrait may not be displayed depending on the edited content. It is recommended that you download the phonebook whenever you edit it.
- The image quality of a displayed portrait may depends on a connected device.

To end call

1 While talking, touch

Operations during a call




- Adjust the volume of your voice
- 1) Touch Speech Quality.
- 2) Touch ◀ or ▶ for Microphone Level.



Adjust the receiver volume

Turn the volume knob clockwise to increase, and counter-clockwise to decrease.



Mute your voice

Touch to mute or not to mute your voice.

Output the dial tone

Touch **DTMF** to display the tone input screen. You can send tones by touching desired keys on the screen.

Switching between speaking voice output destinations

Touching each time switches speaking voice output destinations between the smartphone/cell-phone and the speaker.

Call-waiting

When you receive a new call while talking on the phone, you can answer the newly received call by touching . The current call is put on hold.

Each time you touch , the caller will change to the other one.

When you touch , the current call will end to be switched to the call waiting on hold.

Phone number preset

You can register frequently used phone numbers in this unit.

- 1 Touch 🛣
- 2 Touch Edit.



3 Select where to preset.



■ Delete all

To delete all preset numbers, touch **Delete** all and then touch **Yes** on the confirmation screen.

4 Select how to preset.



Add number from phonebook

Select the number to preset from the phonebook.

Add number direct

Enter the telephone number directly and touch **SET**.

Delete

To delete a preset number, touch **Delete** and then touch **OK** on the confirmation screen.

Phonebook transfer

You can transfer phonebook data from your Bluetooth smartphone using PBAP.

- 1 Touch
- 2 Touch **±** □ .



➤ Phonebook data transfer starts.

NOTE

- If the Phonebook contains more than 1000 entries, only 1000 entries are transferred. The 1001st and later entries are not transferred.
- If no Phonebook has been downloaded, touching Download Phonebook Now will start downloading the Phonebook.
- The portrait registered in the phonebook is displayed while making/receiving calls and during a call.

If you edit the phonebook on the connected device side after downloading the phonebook, the portrait may not be displayed depending on the edited content. It is recommended that you download the phonebook whenever you edit it.

Phonebook deletion

- 1 Touch "鹽.
- 2 Touch the name to check.



■ ☑ AII

Checks all boxes.

Clears all check marks

- 3 Touch Delete.
 - ➤ Confirmation message appears.
- 4 Touch Yes.

Hands-Free Setup

You can make various settings for the Hands-Free function.

- 1 Press the HOME/ button.
- 2 Touch 🖾.
- 3 Touch SETUP.
 - > SETUP Menu screen appears.
- 4 Touch Connections & AV.



- ➤ Connections & AV setting menu appears.
- 5 Touch TEL SETUP.
 - ➤ TEL SETUP screen appears.
- 6 Set each function as follows.



■ Bluetooth HF/Audio

Select the speakers to output the sound from the smartphone/cell-phone (such as phone call voice and ringing tone) and Bluetooth audio player.

Front: Outputs sound from the front speakers.

All (Default): Outputs sound from all speakers.

■ Auto Response*

Set the automatic response time to pick-up an incoming call.

- **OFF** (Default): Turns off the Automatic response function.
- 1/5/10/15/20/25/30: Sets the ringing time (second).

Auto Pairing

When set to "ON", the Apple Auto Pairing function is turned on to automatically register the iPod touch or iPhone connected to this unit.

- **ON** (Default): Turns on the Apple Auto Pairing function.
- **OFF**: Turns off the Apple Auto Pairing function.


Sort Order

Set how to sort the data in the smartphone/cell-phone phonebook.

First (Default): Sorts data by the first name.

Last: Sorts data by the last name.

- * Either the auto response time set on this unit or the time set on the smartphone/cell-phone, whichever is shorter takes effect.
- 7 Touch OK.



Other External Components

View Camera

NOTE


- To connect a camera, see **Connecting the** camera (P.94).
- To use a rear view camera, a REVERSE lead connection is required. (P.90)
- If Rear Camera Interruption is active the camera screen is displayed when you shift the gear to the reverse (R) position.
- The camera whose view was displayed last is kept and the same camera view will be displayed the next time. If its assignment setting is changed, the rear camera view is displayed.
- Rear/front camera interruption screen is not kept as the camera screen which will be displayed the next time.

■ Display the camera screen

- 1 Press the MENU/ATT button.
 - ➤ Popup menu appears.
- 2 Touch Camera.



- ➤ View camera screen appears.
- 3 Adjust each item as follows.



1 Camera Switching Keys *1

Touch to switch the view camera. It is necessary to set "Camera Assignment Settings" beforehand except "Rear". See **To set up the camera assignment settings** (P.57).

2 Camera off

Touch to exit the camera screen.

3 Switching the Guideline *2

Touching each time turns on or off the guideline.

4 Switching the Angle *2

Touching each time changes camera angles.

- *1 When two or more cameras of rear, front, dashboard, left, right, and 3rd are connected with this unit.
- *2 Only when the rear camera screen is displayed and CMOS-3xx series is connected with this unit as the rear camera.

Camera Setup

- 1 Press the **HOME**/ \circlearrowleft button.
- 2 Touch
- 3 Touch SETUP.
 - > SETUP Menu screen appears.
- 4 Touch Camera.
 - ➤ Camera setting menu appears.
- 5 Set each item as follows.



■ Camera Assignment Settings

Set up the camera assignment. See **To set up** the camera assignment settings (P.57).

■ Rear Camera Interruption

ON (Default): Displays the picture from the rear view camera when you shift the gear to the reverse (R) position.

OFF: Select this when no camera is connected

■ Rear Camera Message *1

Always display (Default): Always displays the caution message on the rear camera interruption screen.

Clear after 5 seconds: Displays the caution message for about 5 seconds on the rear camera interruption screen.

■ Rear Camera Settings *2

Adjusts the CMOS-3xx series with ID 1 ("Rear Camera") set. For details, see the instruction manual of your camera.

■ Parking Guidelines

You can display parking guidelines to enable easier parking when you shift the gear to the reverse (R) position.

Default is "ON".

■ Guidelines SETUP

If you select **ON** for **Parking Guidelines**, you can adjust the parking guidelines. See **To** adjust the parking guidelines (P.58).

■ Front Camera Settings *3

Adjusts the CMOS-3xx series with ID 2 ("Front Camera") set. For details, see the instruction manual of your camera.

■ Front Camera Interruption *4

10 sec/15 sec (Default)/20 sec: The front camera screen is displayed when return the gear from the reverse (R) position.

OFF: Cancel.

- *1 To use the function, it is necessary to set **Rear Camera Interruption** to **ON**.
- *2 When CMOS-3xx series is connected with this unit.
- *3 To use the function, it is necessary to connect CMOS-3xx series and to set **Camera**

Assignment Settings to Front (P.57)

*4To use the function, it is necessary to set **Rear**Camera Interruption to **ON** and to set

Camera Assignment Settings to Front.

(P.57)

To set up the camera assignment settings

- 1 Touch Camera Assignment Settings in the Camera setting menu. (P.56)
- 2 Select the item to set up.

■ REAR VIEW CAMERA

Set the camera assignment from view camera connected to Rear view camera input terminal.

■ FRONT VIEW CAMERA / DASH CAM

Set the camera assignment from view camera connected to Front view camera/ Dashboard camera input terminal.

■ 3rd VIEW CAMERA

Set the camera assignment from view camera connected to 3rd view camera input terminal.

■ VIDEO IN

Set the camera assignment from view camera connected to Video input terminal.

3 Select the view camera to set up.



1 Picture from view camera

Displays the picture from the view camera connected to the input terminal to be set.

(P.94)

2 Camera position

Assign each position to the view camera connected to the selected input terminal. Front *1/Left *1/Right *1/Dashboard

Camera *1/Rear *2/ None *1

3 Picture quality settings

Switch the picture quality setting.

Signal *3: "HD"/"NTSC" (Default)/"PAL"

Mirror *4: "ON"/"OFF" (Default)

Other External Components

- *1 Except the **REAR VIEW CAMERA** setting screen.
- *2 The **REAR VIEW CAMERA** setting screen only.
- *3 The **REAR VIEW CAMERA** and **FRONT VIEW CAMERA / DASH CAM** setting screens only.
- *4 The **FRONT VIEW CAMERA / DASH CAM** and **3rd VIEW CAMERA** setting screens only.

4 Touch Enter.

NOTE

- The screen shot above is for the FRONT VIEW CAMERA / DASH CAM setting screen. It may be different from the ones for REAR VIEW CAMERA, 3rd VIEW CAMERA and VIDEO IN.
- The Dashboard Camera can be selected when it is connected. (P.94)


To adjust the parking guidelines

NOTE

- Install the rear view camera in the appropriate position according to the instruction manual supplied with the rear view camera.
- When adjusting the parking guidelines, make sure to apply the parking brake to prevent the car from moving.
- 1 Touch Parking Guidelines in the Camera screen and set to ON. (P.56)
- 2 Touch Guidelines SETUP on the Camera screen.
- 3 Adjust the parking guidelines by selecting the mark.



4 Adjusting the position of the selected mark.



Make sure that lines (A) and (B) are horizontally parallel, and that lines (C) and (D) are of the same length.

NOTE

• Touch **Initialize** and then touch **Yes** to set all the marks to their initial default position.

Use Dashboard Camera

A Dashboard Camera, DRV-N520 (optional accessory), connected to this unit lets you play video-recorded data and so on.


For details, see the instruction manual of the Dashboard Camera DRV-N520 (optional accessory).

NOTE

- To connect a dashboard camera, see **Connecting the camera (P.94)**.
- To use the dashboard camera function, it is necessary to set "Camera Assignment Settings" to "Dashboard Camera". (P.57)

Display the dashboard camera screen

- 1 Press the MENU/ATT button.
 - > Popup menu appears.
- 2 Touch Camera.



1 Camera Switching Keys

Touch to switch the view camera. It is necessary to set "Camera Assignment Settings" beforehand except "Rear". See To set up the camera assignment settings (P.57).

2 Camera off

Touch to exit the camera screen

3 Key display

Touch to display the dashboard camera control keys.

External audio/video players (AV-IN)

- 1 Connect an external component to the AV Audio input and the Video input terminal.
- 2 Select AV-IN as the source. (P.10)
- **3** Turn on the connected component and start playing the source.

NOTE

• To select the AV-IN source, it is necessary to set "VIDEO IN" to "None" in Camera Assignment Settings (P.57)

HDMI source

- 1 Connect your smartphone to the HDMI input terminal. (P.91) Use HDMI cable KCA-HD100 (optional accessory).
- 2 Select **HDMI** as the source. (P.10)
- 3 Start an application or playback on your smartphone.

OEM Features Operation

This unit can display vehicle information when connected to the bus system of the vehicle using an iDatalink (commercially available).

- 1 Press the HOME/ button.➤ HOME screen appears.
- 2 Touch on the HOME screen.
- 3 Touch icon.



- Displays the control screen of the Bluetooth Hands-Free function provided for the vehicle.
- Displays the control screen of the accessories in the vehicle.
- Displays information about the tire pressures of the vehicle. *
- Displays the control screen of the satellite radio source provided for the vehicle.
- Displays the control screen of the media player source provided for the vehicle.
- Displays the control screen of the Bluetooth streaming source provided for the vehicle.
- Displays information about the Radar Detector. *
- Displays information about the instruments such as a speedometer.
- Displays information about the air conditioner of the vehicle. *
- Displays information about the Parking
 Distance Sensor of the vehicle.

NOTE

 Displayable screens, key names, and screen names vary depending on the type of the connected iDatalink and the model of the vehicle. For more details, access the following URL:

www.idatalink.com/

^{*}These iDatalink features are displayed as the widget on the Home screen. **(P.8)** You can display the relevant screens by touching the widget.

Setup

- 1 Press the **HOME**/ \circlearrowleft button.
- 2 Touch [™].
- 3 Touch SETUP.



See the following section for each setting.

- Set up connections and AV (P.61)
- Set up display and button (P.63)
- Set up the user interface (P.64)
- Set up camera (P.56)
- · Set up systems (P.65)

Monitor Screen Setup

You can adjust the image quality of video, menu screen, etc.

- 1 Press the MENU/ATT button.
 - > Popup menu appears.
- 2 Touch Screen Adjustment.



- > Screen Adjustment screen appears.
- 3 Adjust each setting as follows.



■ Backlight / Contrast / Black / Brightness / Color / Tint

Adjust each setting.

Aspect

Select a screen mode.

Full: Changes the aspect ratio of video and displays video fully on the screen.

Normal: Displays video at the ratio of 4:3.

Auto:

USB device: Displays video fully (vertically or horizontally) with no ratio change.

NOTE

 Settings to adjust vary depending on the current source.

Connections & AV Setup

You can set connections and AV parameters.

- 1 Press the **HOME**/ \circlearrowleft button.
- 2 Touch [™].
- 3 Touch SETUP.
 - > SETUP Menu screen appears.
- 4 Touch Connections & AV.
 - ➤ Connections & AV setting menu appears.
- 5 Set each parameter as follows.



■ Bluetooth

Turns the Bluetooth function on or off.

■ Device List

Select the connected device to be used. (P.46)

■ Device Name

If you select **ON** for **Bluetooth**, you can change the Bluetooth device name.

See Change the device name (P.47).

■ PIN Code

If you select **ON** for **Bluetooth**, you can change the PIN code.

See Change the PIN Code (P.47).

Device address

Display the Bluetooth device address.

■ TEL SETUP

You can make various settings for the Hands-Free function.

See Hands-Free Setup (P.55).

■ Wi-Fi SETUP

You can change the device name and display the device address, password. See **Change the device name (P.62)**.

■ Speech Quality Adjust

Adjust the speech quality.

Microphone Level: Adjust the level of microphone gain. Default is "0".

Echo Cancel Level: Adjust the level of echo cancellation. Default is "0".

Noise Reduction Level: Reduce the noise generated in the surrounding environment without changing the microphone volume. Use this function when the voice of caller is not clear. Default is "0".

■ iPod Bluetooth Connection

See Select the method of making connections for outputting sound from the iPod source (P.24).

AV-OUT

You can select an AV source to be output from the AV OUTPUT port.

OFF, iPod, USB, or AV-IN

- You cannot select AV-IN if the Video input terminal is used for camera.
- You cannot select iPod if it is connected via Bluetooth or Apple CarPlay is connected.
- If you select iPod as the main source, you cannot select USB as the AV output source.
- If you select USB as the main source, you cannot select iPod as the AV output source.

- If you select HDMI as the main source, files with sampling rates higher than 96 kHz in USB selected as the AV output source are skipped.
- If you select Bluetooth audio, HD Radio, Wireless Mirroring, Apple CarPlay or Android Auto as the main source, you cannot select USB or iPod as the AV output source.

■ Reset Android Auto Wireless Connection

You can change the password for wireless Android Auto.

The system of the unit is rebooted after selecting **YES**.

Change the device name

1 Touch **Device Name** in the Connections & AV setting menu.

or

Touch Wi-Fi SETUP and then touch **Device Name**.

- ➤ Change Device Name screen appears.
- 2 Touch and hold .
- 3 Input the device name.



4 Touch Enter.

Display & Button Setup

- 1 Press the HOME/ button.
- 2 Touch 🖾.
- 3 Touch SETUP.
 - > SETUP Menu screen appears.
- 4 Touch Display & Button.
 - > Display & Button setting menu appears.
- 5 Set each parameter as follows.



Dimmer

Select the dimmer mode.

OFF: Does not dim the display and buttons.

ON: Dims the display and buttons.

SYNC (Default): Turns the dimmer function on or off when the vehicle light control switch is turned on or off.

OSD Clock

Select if you want to display the clock while the screen is off, or while watching video files on USB. etc.

"ON" (Default)/"OFF"

■ Button Illumination Color

You can set the button illumination color. (P.63)

■ Wallpaper Customize

You can change the wallpaper image or color. (P.64)

■ Screen transition effect

Select whether to use the screen transition effect when the source control screen is switched to the Home screen.

"ON" (Default)/"OFF"

Customizing the button color

You can set the button illumination color.

- Touch Button Illumination Color in the Display & Button setting menu.
- 2 Touch the desired color.



■ Variable

You can set the button color to continuously scan through the color spectrum.

User

You can set the color created with the RGB color mixer.

Car Color

This can be selected when the iDatalink (commercially available) is connected.

3 Touch 🔄

To register an original color

You can register your original color.

- 1 Touch **User** on the Button Illumination Color screen.
- 2 Use and + to adjust each color value.



3 Touch 6

NOTE

You can create a color based on a preset color.
 Touch the preset color instead of **User**, and adjust the color value.

Change the wallpaper image or color

- Touch Wallpaper Customize in the Display & Button setting menu.
- 2 Select an image.



- *1 The album art currently being displayed is used as a wallpaper.
- *2 Select a wallpaper color in advance.
- *3 Select an original image in advance.

To select wallpaper color

- Touch Wallpaper Color on the Wallpaper Customize screen.
- 2 Select a wallpaper color.



User

You can set the color created with the RGB color mixer. For how to create an original color, see *To register an original color* (P.63).

Car Color

This can be selected when the iDatalink (commercially available) is connected.

■ Button Illumination Synch *1

The color you have selected at **Button Illumination Color** can be set. If you adjust the color value with the following RGB color mixer, the adjusted color will be applied to the wallpaper and the button illumination. For how to set the button illumination color and create an original color, see

Customizing the button color (P.63). "ON"/"OFF" (default)

- *1 When **Button Illumination Color** is "Variable", this option is fixed to OFF.
- 3 Touch 4


To register an original image

With "KENWOOD Portal APP" application installed on your iPhone or Android smartphone, you can upload image files to this unit and set an image as the wallpaper image. See *Importing Image Files (P.15)*.

User Interface Setup

You can setup user interface parameters.

- 1 Press the **HOME**/ \circlearrowleft button.
- 2 Touch [™].
- 3 Touch SETUP.
 - > SETUP Menu screen appears.
- 4 Touch User Interface.
 - ➤ User Interface setting menu appears.
- 5 Set each parameter as follows.



■ Source Setup - Remote Control

Select the sources to be switched with the remote controller. For how to operate the remote controller, see *Basic Operation* (*P.80*).

■ Beep

Turn the key touch tone on or off. Default is "ON".

■ Parking Assist Display

When the iDatalink (commercially available) is connected, you can display information about obstacles around the car.

ON: Always displays information.

Dyn. (Default): Displays information when the sensor detects obstacles.

OFF: Cancels this function. This can be set when the iDatalink (commercially available) is connected.

■ Parking Assist Position

Select where to display information about obstacles on the screen (left or right).

"Left"/"Right" (Default)

This can be set when the iDatalink (commercially available) is connected.

■ Driving Position

Select the driving position (left or right). "Left" (Default)/"Right"

System Setup

You can setup system parameters.

- 1 Press the **HOME**/ \bigcirc button.
- 2 Touch 🖭.
- 3 Touch SETUP.

> SETUP Menu screen appears.

- 4 Touch System.
 - System setting menu appears.
- 5 Set each parameter as follows.



■ DEMO

Select the demonstration mode. Default is "ON".

■ Software Information

Confirm the software version of this unit. (P.66)

Open Source Licenses

Display the open source licenses.

Initialize

Touch **Initialize** and then touch **Yes** to set all the settings to the initial default settings.

· Audio SETUP Memory is not initialized.

OEM SETUP

Confirm the information about or change the settings for using the iDatalink (commercially available).

■ Language Select

Select a language.

- Time Format
- Clock
- Time Zone
- Clock Adjust

You can set the date and time. See

Calendar/clock settings (P.7).

Setup

Software Information

You can confirm the software version of this unit.

- 1 Touch **Software Information** in the System setting menu.
- 2 Confirm the software version.



NOTE

 For how to update the software, see the relevant update procedure manual which comes with the software.

Controlling Audio

You can adjust various settings such as audio balance or subwoofer level.

- 1 Press the HOME /(1) button
- 2 Touch [™].
- 3 Touch Audio.



See the following section for each setting.

- Set up Speaker / X'over (P.68)
- · Controlling EO / SW Level (P.69)
- Set Position / DTA (P.70)
- · Controlling FAD / BAL / Zone (P.72)
- Set Volume Offset (P.74)
- · Set Sound Effect (P.74)
- Use Audio Memory (P.78)

NOTE


- When the iDatalink (commercially available) is connected, the best audio settings are set automatically.
- Each parameter as follows are set.
- Speaker / X'over
- FO / SW Level
- Position / DTA
- FAD / BAL / Zone
- Sound Effect
- · To recall the settings automatically adjusted by the iDatalink connection when the settings are changed manually, touch Audio SETUP Clear in the Audio Memory setting menu. (P.78)

3-way speaker system setup (DMX1057XR)

Select the appropriate crossover network mode for the speaker system used (2-way or 3-way speaker system).

A CAUTION

- Connecting 3-way speakers with the 2-way mode selected can break the speakers.
- 1 Press the HOME/ button.
 - ➤ HOME screen appears.
- **2** Touch **#**.
 - ➤ Source selection screen appears.
- 3 Touch STANDBY.
- 4 Press **□** button ① followed by the **HOME**/也 button ② for 1 second at the same time.



- > Speaker system select screen appears.
- 5 Select the crossover network mode.



- ➤ A confirmation screen appears.
- 6 Touch Yes

NOTE

- When the 3-way speaker system is selected, the following functions are disabled.
 - Front focus of Listening Position / DTA
 - Fader for Controlling General Audio
 - Zone Control
 - Selection of the speakers to output sound from the smartphone/cell-phone of Bluetooth HF/ Audio
 - Beep for User Interface Setup
- While talking on the paired phone or using the voice recognition function, the speaker system cannot be switched.
- When the dual zone is selected and audio source other than "OFF" is selected as Rear Source, the speaker system cannot be switched to the 3-way mode.

Speaker / X'over setup

- 1 Press the HOME/ U button.
- 2 Touch .
- 3 Touch Audio.
 - ➤ Audio screen appears.
- 4 Touch Speaker / X'over.
- **5** Select a car type.

You can select the car type and speaker network, etc.

When you select your car type, the Delay Time Alignment is activated automatically (for timing adjustment of sound output for each channel) to have the highest surround effects.



6 Touch the speaker (1) you wish to adjust and set each parameter (2) as follows.



Speaker

You can select a speaker type and its size to get the best sound effects.

When the speaker type and size are selected, the speaker crossover network is set automatically.

■ Location (Only for Front, Rear)

Select the speaker position you have installed

■ Tweeter (Only for Front)

You can set up the tweeter when you are selecting front speakers.

None, Small, Medium, Large

■ **HPF FREQ** (Only for Front, Rear)

High Pass Filter adjustment.

■ LPF FREQ (Only for Subwoofer)

Low Pass Filter adjustment.

Slope

Set a crossover slope.

Gain

Adjust the gain of the front speaker, rear speaker, or subwoofer.

■ TW Gain (Only for Front)


Adjust the tweeter level.

■ Phase Inversion (Only for Subwoofer)

Set the phase of subwoofer output.

Check **Phase Inversion** to shift the phase 180 degrees.

When Speaker network is set to 3-way:



Speaker

You can select a speaker type and its size to get the best sound effects. If you have no speakers, select "None".

When the speaker type and size are selected, the speaker crossover network is set automatically.

■ FREQ (High Pass)

High Pass Filter adjustment. (Only for High Pass)

■ FREQ (Low Pass)

Low Pass Filter adjustment. (Only for Low Pass)

■ HPF FREQ, LPF FREQ (Only for Band Pass)

Band Pass Filter adjustment.

■ Slope *1 *2

Set a crossover slope.

■ Gain

Set the gain of each speaker.

Phase Inversion

Set the phase of tweeter, mid range, and woofer output.

Check **Phase Inversion** to shift the phase 180 degrees.

- *1 Only when "LPF FREQ"/"HPF FREQ" (Band Pass) is set to a mode other than "Through".
- *2 Only when "FREQ" (Low Pass) is set to a mode other than "Through".

NOTE

• For how to switch to the 3-way speaker system, see **3-way speaker system setup (P.67)**.

Equalizer Control

You can adjust equalizer by selecting the optimized setting for each category.

- 1 Press the **HOME**/ \bigcirc button.
- 2 Touch .
- 3 Touch Audio.
 - ➤ Audio screen appears.
- 4 Touch EQ / SW Level.
- 5 Touch the screen and set the Graphic Equalizer as desired.



■ Gain level (area in dotted frame)

Adjust the gain level by touching each frequency bar.

You can select a frequency bar and adjust its level by \triangle , ∇ .

ALL SRC

Apply the adjusted equalizer curve to all sources. Touch **ALL SRC** and then touch **OK** on the confirmation screen.

■ Memory

Saves the adjusted equalizer curve as "User1" to "User4". (P.70)

■ Initialize

Initialize (flatten) the current EQ curve.

■ Bass EXT (Bass Extend Settings)

When turned on, the frequencies lower than 62.5 Hz is set to the same gain level (62.5 Hz).

SW Level

Adjust the subwoofer volume. This setting is not available when Subwoofer is set to "None". See **Speaker / X'over setup (P.68)**.

Pops/Easy/Top40/Jazz/Powerful/ Rock/Flat/Bass Boost/User1/ User2/User3/User4

Recall the preset EQ curve.

Save the EQ curve

- 1 Adjust the EQ curve.
- **2** Touch **Memory**.
- 3 Select where to save.



Listening Position / DTA

Listening Position / DTA allows you to improve the sound field depending on the position of the seat you sit.

Listening Position / DTA allows you to set "Listening Position" and "Front Focus". You cannot set both at the same time.

- 1 Press the HOME/ button.
- 2 Touch .
- 3 Touch Audio.
 - ➤ Audio screen appears.
- 4 Touch Position / DTA.



- · Set up Listening Position (P.70)
- Set up Front Focus (P.71)

Listening Position

Adjust the sound delay time so that the sounds from different speakers arrive at the listener sitting on the selected seat at the same time.

- 1 Touch **Listening Position** on the Position / DTA screen.
- 2 Select a listening position from Front R (Right front), Front L (Left front), Front All (All front), and All.



Position DTA control

You can fine-adjust your listening position.

- 1 Touch Adjust.
- 2 Touch Delay.
- **3** Touch **◄** or **▶** to adjust the delay time of the selected speaker.



- 4 Touch Level.
- **5** Touch **◄** or **▶** to adjust the sound level of the selected speaker.



NOTE

· To initialize the Delay and Level settings, touch Initialize and YES on the confirmation screen.

Front Focus

You can focus the imaginary sound image on the front of the selected seat.

- 1 Touch Front Focus in the Position / DTA screen.
- 2 Select a front focus position.

For Front All and All, select Priority L or R depending on which side you want to put the imaginary sound image.




NOTE

• When the 3-way speaker system is selected, front focus feature is disabled.

Front Focus fine adjustment

- 1 Touch Adjust.
- 2 Touch Delay.
- 3 Set each parameter as follows.



■ Sound Image LR (Front)

Focus the sound image on the front of front seats.

■ Sound Image LR (Rear)

Focus the sound image on the front of rear seats.

■ Size of the Virtual Sound Field

Adjust the size of sound image to meet your taste. If the sound image is shifted from the front, move it back by **Sound Image LR** (**Front**) or **Sound Image LR** (**Rear**).

■ Subwoofer Delay

Adjust the delay time of subwoofer sound.

- 4 Touch Level.
- 5 Touch ◀ or ▶ to adjust the sound level of the selected speaker.




NOTE

To initialize the Delay and Level settings, touch
 Initialize and YES on the confirmation screen.

Fader / Balance / Zone Control

- 1 Press the HOME/ button.
- 2 Touch 🖾.
- 3 Touch Audio.
 - ➤ Audio screen appears.
- 4 Touch FAD / BAL / Zone.




- Fader / Balance Control (P.72)
- Set up Zone Control (P.73)

■ Fader / Balance Control

You can adjust the volume balance among the speakers.

1 Touch ◀, ▶, ▲, and ▼ to adjust the volume balance.



- **◄** and **►** adjust the left and right volume balance.
- lacktriangle and lacktriangle adjust the front and rear volume balance.

Center

Clear the adjustment.


NOTE

• When the 3-way speaker system is selected, "Fader" adjustment is disabled.

Zone Control

You can select different sources for front and rear positions in the vehicle.


1 Touch Dual Zone on the FAD / BAL / Zone screen.



Source

You can switch the current source.

2 Set each source as follows.



Zone Select

Touch **Single Zone** to turn off the dual zone function.

■ Front Source . Rear Source

Select an audio source for each. Rear Source:

"AV-IN"/"iPod"/"USB"/"OFF"

Rear VOL.

Adjust the rear source volume.

NOTE

- When the rear source is switched, the audio source that is output at the AV OUTPUT terminal is also switched to the same source.
- When the dual zone function is set to on, the following functions are not available.
 - Output from the subwoofer
 - Subwoofer Level/Bass Boost (P.74)
 - Equalizer Control/Sound Effect/Listening Position (P.69, 74, 70)
 - Speaker Setup (P.68)
 - Fader for Controlling General Audio
 - High-resolution Sound Source File Playback
- When the dual zone is selected and audio source other than "OFF" is selected as Rear Source, the speaker system cannot be switched.
- You cannot select AV-IN if the Video input terminal is used for camera.

Rear Source

- You cannot select iPod if it is connected via Bluetooth or Apple CarPlay is connected.
- If you select iPod as the Front Source, you cannot select USB as the Rear Source.
- If you select USB as the Front Source, you cannot select iPod as the Rear Source.
- If you select HDMI as the Front Source, files with sampling rates higher than 96 kHz in USB selected as the Rear Source are skipped.
- If you select Bluetooth audio, HD Radio, Wireless Mirroring, Apple CarPlay or Android Auto as the Front Source, you cannot select USB or iPod as the Rear Source.

Volume Offset

Finely adjust the volume of the current source to minimize the difference in volume between different sources.

- 1 Press the HOME/ button.
- 2 Touch .
- 3 Touch Audio.
 - ➤ Audio screen appears.
- 4 Touch Volume Offset.
- 5 Touch + or to adjust the level.



Initialize

Returns to the initial settings.

Touch **Initialize** and then touch **YES** on the confirmation screen.

NOTE

 If you have increased the volume first, then reduce the volume using "Volume Offset".
 Switching the current source to another source suddenly may output extremely loud sound.

Sound Effect

You can set sound effects.

- 1 Press the HOME/ button.
- 2 Touch .
- 3 Touch Audio.
 - ➤ Audio screen appears.
- 4 Touch Sound Effect

5 Set each parameter as follows.



■ Bass Boost

Set the amount of bass boost "OFF"/"1"/"2"/"3"

Loudness

Set the amount of boost of low and high tones

"OFF", "Low", "High"

■ Drive Equalizer

Reduces the driving noise by raising the bandwidth.

"OFF", "ON"

■ Space Enhancer

Select the feeling of sound space enhancement.

"OFF"/"Small"/"Medium"/"Large".

This setting is not available for the HD Radio tuner source.

Supreme

Turn ON/OFF the Supreme function.
Technology to extrapolate and supplement with proprietary algorithm, the high-frequency range that is cut off when encoding.

■ Realizer

Virtually make the sound more realistic using the Digital Signal Processor (DSP) system.
Select the level from "OFF"/"1"/"2"/"3".

Stage EQ

You can adjust the height of speakers virtually to suit your listening position. "OFF"/"Low"/"Middle"/"High".

■ Parametric EQ (DMX1057XR)

When set to "ON", you can use the parametric equalizer. For details, see *Parametric Equalizer (P.75)*.

Parametric Equalizer (DMX1057XR)

In addition to the conventional Graphic Equalizer, this unit has a parametric equalizer, which allows you more precise adjustments. By using each equalizer properly, you can calibrate the unit more thoroughly.

Adjustment using this function requires expertise.

When to Use Each Function

Parametric Equalizer

Use this to finely correct or improve the frequency characteristics of the acoustics of the car in order to establish a basis for adjustments.

Practiced ears or a measuring equipment may be required to apprehend the problems of the sound field inside the car.

Graphic Equalizer

Use this to actively create an attractive sound as conventionally.

Everybody can easily get the result through trial and error of intuitive operations.

Even more effective adjustments are possible when the basis is established by using the Parametric Equalizer.

■ About the Parametric Equalizer

This system allows you to freely control the filter, frequency, Q factor (acuteness) and slope gain at 14 points consisting of 9 points common for front/rear/subwoofer, 2 points for front only, 2 points for rear only, and one point for subwoofer only.

NOTE

- Configure the Parametric Equalizer to establish the basis for adjustments before making adjustments using the Graphic Equalizer.
- The changes made using the Parametric Equalizer are not shown on the Graphic Equalizer screen.
- You can check the effects using the Parametric Equalizer ON/OFF key.


About Adjustments

If there are unpleasant peaks, you can slide the peaking filter to the left or right and search the frequencies by ear. Studio engineers use this method to make adjustments quickly and efficiently.

However, in order to identify peaks and dips of a car audio system, you have to capture the pink noise outputted from the speaker using a microphone and analyze it using a real time analyzer (RTA). From the analysis result, identify the peaks and/or dips that need to be corrected and configure the filters to cancel them.

About the Filters of Parametric Equalizer

Filters allow you to remove or extract specific sound through signal processing.




NOTE

 Cutoff frequency is the boundary between the passband and the stopband. The definition of cutoff frequency is a frequency for which the output is -3 dB of the nominal passband value.

High-Pass Filter

Passes signals with frequencies higher than a certain frequency (fc: cutoff frequency) and attenuates signals with frequencies lower than the cutoff frequency. Use this to pass only high-frequency signals. Use this in the following cases for example:


- For extracting the frequency band for separate tweeters. By extracting the specific frequency band, level adjustment can be made to the frequency band individually.
- The sound may be muddy when you play back low frequency sound. This occurs when frequencies below the speaker capacity is inputted. To cancel this, use the high-pass filter to cut off the frequencies below the speaker capacity.



High-Shelving Filter/Low-Shelving Filter

These filters reduce or increase signals above or below a certain frequency (fc: cutoff frequency), which create shelves in the frequency spectrums. A high-shelving filter reduces or increases the frequencies above the target frequency and a low-shelving filter reduces or increases the frequencies below the target frequency. The low shelf controls the lower frequencies and the high shelf controls the high frequencies. Use these in the following cases for example:


- When you want to change the volume of the tweeters, for example when they are close to your ears and are sounding too loud.
- When you want to change the subwoofer volume at hand.



Peaking Filter

The frequencies in the vicinity of a certain frequency (f0: center frequency) are boosted or attenuated. Use this in the following cases for example:


- When you want to control a narrow range of frequencies to correct the frequency abnormality in the car.
- To diminish a chattering noise from the speaker by attenuating the frequency range of the noise.
- To adjust of the sound balance of the whole range between the low end and the high end.



Low-Pass Filter

Passes signals with frequencies lower than a certain frequency (fc: cutoff frequency) and attenuates signals with frequencies higher than the cutoff frequency. Use this to pass only low-frequency signals. Use this in the following cases for example:

- For extracting the low frequencies band for a subwoofer.
- For extracting middle/low frequencies when you are using speakers with separate tweeters and you want to output the high frequencies to the tweeters and output the middle/low frequencies to the woofers.
- To cut the high frequencies when they are too loud.



Adjust the Parametric Equalizer

Preparation

- Correct the value in "Listening Position" and "Front Focus" before adjusting the parametric equalizer.
 See Listening Position / DTA (P.70).
- 1 Press the **HOME**/ \bigcirc button.
- 2 Touch .
- 3 Touch Audio.
- 4 Touch Sound Effect
- 5 Set the Parametric EQ to ON and touch Yes.
- 6 Touch SETUP.
 - > Parametric EQ screen appears.
- 7 While auditioning music, move the peaking filter to the left and right to search for unpleasant peaks and suppress them.
- 8 Use pink noise and an analyzer to identify dips, as dips are difficult to find. Correct steep (10 dB or greater) peaks and dips as these are generally regarded as obstructions to sound quality.
- 9 Set each parameter as follows.



1 Speaker

Select the speaker.

When Speaker network is set to 2-way:
"Common"/"Front"/"Rear"/"Subwoofer"

When Speaker network is set to 3-way: "Common"/"Tweeter"/"Middle"/"Woofer"

2 EQ points/curve

Displays the EQ point and the curve. Adjust the EQ points by touching.

EQ point (red): The EQ point currently being adjusted.

EQ point (blue/yellow): EQ points that are not currently being adjusted.

Curve (orange): EQ curve of the speaker currently being adjusted.

Curve (blue): Overall EQ curve.

3 Filter

Select the filter.

"High Pass" / "High Shelving" / "Peaking" / "Low Shelving" / "Low Pass"

4 Affects All Speakers *1

- ON: Outputs sound from all speakers.
- **OFF**: Outputs sound from the currently selected speaker only.

5 Initialize / Flat

- **Initialize**: Initialize (flatten) the adjustment of all the speakers.
- **Flat**: Initialize (flatten) the adjustment of the current speaker.

6 Frequency / Gain

Set the frequency and gain.

- and
 adjust the frequency.
- ▲ and ▼ adjust the gain.

NOTE

 Touch the EQ point to roughly determine the frequency and gain, then use this key to make fine adjustments.

7 Q / Slope*2

Set the Q factor and slope.

8 Point

Select the EQ point to adjust.

9 Preset

- User1 / User2 / User3: Recalls the preset FO
- Memory: Stores the current EQ settings.
- *1 Only when the speaker other than "Common" is selected.
- *2 When "Peaking" filter is selected, you can adjust the Q factor. When "High Pass" or "Low Pass" filter is selected, you can adjust the slope.

NOTE

 You can adjust the EQ points and curve based on a preset EQ. Recall the preset EQ and touch the preset key again to unselect it before adjustment.

Controlling Audio

- 10 When you have finished adjustments, save the results as a preset, and check the effects by switching presets or turning the Parametric EQ ON and OFF.
- 11 Use the Graphic Equalizer to make final adjustments. (P.69)

Audio Setup memory

Audio Control settings can be memorized. The memorized settings can be recalled at any time.

- 1 Press the HOME/ button.
- 2 Touch .
- Touch Audio.Audio screen appears.
- 4 Touch Audio Memory.



■ SETUP Memory

Lock or unlock the Audio SETUP Memory/ Recall/Clear.

■ Audio SETUP Memory

Memorize the current audio settings.

 FAD / BAL / Zone, Speaker / X'over, Equalizer (User Preset, SW Level), Position / DTA, Sound Effect (P.67)

Audio SETUP Recall

Recall the memorized audio setting.

Audio SETUP Clear

Clear the Audio SETUP Memory and the currently memorized audio settings.

If the iDatalink (commercially available) is connected, the audio settings revert to the values set by the iDatalink.

Remote control

This unit can be operated using the remote control KNA-RCDV331 (optional accessory).

A CAUTION

- Risk of fire or explosion if the battery is replaced by an incorrect type. Ensure to replace only with the same type.
- Risk of fire, explosion or the leakage of flammable liquid or gas if the battery is left in an extremely high temperature surrounding environment and/or subjected extremely low air pressure. The battery pack or batteries shall not be exposed to excessive heat such as sunshine fire or the like
- Risk of fire, explosion or the leakage of flammable liquid or gas if the battery is disposed into fire or a hot oven, recharged, shorted, mechanically crushed or cut of the battery.
- If spilled fluid comes in contact with your eyes or on clothing, immediately rinse with water and consult a physician.

Battery Installation

If the remote control operates only over shorter distances or does not operate at all, it is possible that the batteries are depleted. In such instances, replace the both batteries with new ones.


1 Insert two "AAA"/"R03"-size batteries with the ⊕ and ⊖ poles aligned properly, following the illustration inside the case.



Functions of the Remote control Buttons

Switch the operation mode

The functions operated from the remote control differ depending on the position of the mode switch.



■ AUD mode

Switch to this mode when controlling a selected source or tuner source, etc.

■ DVD mode/TV mode/NAV mode Not used.

NOTE

• When controlling a player that is not integrated in the unit, select "AUD" mode.

■ Direct search mode

Using the remote control, you can jump directly to the desired channel by entering the number corresponding to the content.

NOTE

- This operation cannot be performed for the USB device and iPod.
- 1 Press the **#BS** button several times until the desired content appears.

The available contents are different depending on the source type.

■ HD Radio tuner


Frequency value/Channel number

■ SiriusXM

Channel number

- 2 Enter the number of the content you want to play using the numeric keypad.
- 3 Press the ◀ or ►/I◀◀ or ►►I button.
 - ➤ The content corresponding to the number you entered is played.

Basic Operation



| | Key Name | Mode switch | Function | |
|----|------------|----------------|--|--|
| 1 | SRC | AUD | Switches to the source to be played. (P.64) In Hands-Free mode, hangs up the phone. | |
| 2 | NAV | _ | Displays the APP (Apple CarPlay/Android Auto/Wireless Mirroring) screen. | |
| 3 | MENU | _ | Not used. | |
| 4 | OUT, IN | _ | Not used. | |
| 5 | POSITION | AUD | Pauses the track or file, and resumes playing by pressing twice. For the HD Radio source switches the seek mode. | |
| 6 | Cursor Key | _ | Not used. | |
| 7 | ENTER | - | Not used. | |
| 8 | ROUTE M | AUD | Screen mode changes each time you press this key during video playback. | |
| 9 | VOICE | AUD | Displays the control screen of current source. (USB) | |
| 10 | VIEW | AUD | Switches the AV source to be output. | |
| 11 | MAP DIR | - | Not used. | |
| 12 | ▲/▼ | AUD | Selects the folder to be played. For the HD Radio source selects FM/AM band to be received. For the SiriusXM source selects the band to be received. | |

| | Key Name | Mode switch | Function | |
|----|-------------------|----------------|---|--|
| 13 | ⋖/ ▶ | AUD | Selects the track or file to be played. For the HD Radio, and SiriusXM sources, switches to broadcast stations received by the unit. | |
| 14 | Numeric Keypad | AUD | Allows you to enter the number to search in the direct search mode. For details on the direct search mode, see <i>Direct search mode (P.80)</i> . For the HD Radio and SiriusXM sources, allows you to enter the preset number. If the preset number is one digit, press the number. If the preset number is two digits, press continuously the numbers within 3 seconds. Pressing ◀ ➤ within 3 seconds allows you to determine the preset number of one digit. | |
| 15 | * + | - | Not used. | |
| 16 | # BS | AUD | Switches to the direct search mode. For details on the direct search mode, see <i>Direct search mode (P.80)</i> . | |
| 17 | AUDIO | - | Not used. | |
| 18 | CANCEL | - | Not used. | |
| 19 | SUBTITLE | - | Not used. | |
| 20 | 6 | - | When a call comes in, answers the call. | |
| 21 | ANGLE | _ | Not used. | |
| 22 | VOL ▲▼ | - | Adjusts the volume. | |
| 23 | ZOOM | - | Not used. | |
| 24 | 2 ZONE | AUD | Switches the Dual Zone function on and off. | |
| 25 | R.VOL | - | Adjusts volume at rear when the Dual Zone function is on. | |
| 26 | ATT | _ | Lowers the volume when pressed once. Restores the previous volume when pressed twice. | |

Connection/Installation

This section is for the professional installer. For safety's sake, leave wiring and mounting to professionals. Consult the car audio dealer.

Before Installation

Before installation of this unit, please note the following precautions.

▲ WARNINGS

- If you connect the ignition wire (red) and the battery wire (yellow) to the car chassis (ground), you may cause a short circuit, that in turn may start a fire. Always connect those wires to the power source running through the fuse box.
- Do not cut out the fuse from the ignition wire (red) and the battery wire (yellow). The power supply must be connected to the wires via the fuse.


A CAUTION

 Install this unit in the console of your vehicle.
 Do not touch the metal part of this unit during and shortly after the use of the unit. Metal part such as the heat sink and enclosure become hot.


- Mounting and wiring this product requires skills and experience. For best safety, leave the mounting and wiring work to professionals.
- Do not install the unit if it becomes an obstacle to driver performance.
- Adjust the panel position not to become an obstacle to driver performance.
- Make sure to ground the unit to a negative 12V DC power supply.
- Do not install the unit in a spot exposed to direct sunlight or excessive heat or humidity.
 Also avoid places with too much dust or the possibility of water splashing.
- Do not use your own screws. Use only the screws provided. If you use the wrong screws, you could damage the unit.

- If the power is not turned ON ("There is an error in the speaker wiring. Please check the connections." is displayed), the speaker wire may have a short-circuit or touched the chassis of the vehicle and the protection function may have been activated. Therefore, the speaker wire should be checked.
- If your car's ignition does not have an ACC position, connect the ignition wires to a power source that can be turned on and off with the ignition key. If you connect the ignition wire to a power source with a constant voltage supply, such as with battery wires, the battery may be drained.
- If the console has a lid, the lid will not be closed even when the unit is installed correctly.
- If the fuse blows, first make sure the wires are not touching to cause a short circuit, then replace the old fuse with one with the same rating.
- Insulate unconnected wires with vinyl tape or other similar material. To prevent a short circuit, do not remove the caps on the ends of the unconnected wires or the terminals.
- Connect the speaker wires correctly to the terminals to which they correspond. The unit may be damaged or fail to work if you share the

 wires or ground them to any metal part in the car.
- When only two speakers are being connected to the system, connect the connectors either to both the front output terminals or to both the rear output terminals (do not mix front and rear). For example, if you connect the ⊕ connector of the left speaker to a front output terminal, do not connect the ⊖ connector to a rear output terminal.
- After the unit is installed, check whether the brake lamps, blinkers, wipers, etc. on the car are working properly.
- Mount the unit so that the mounting angle is 30° or less.
- This unit has the cooling fan to decrease the internal temperature. Do not mount the unit in a place where the cooling fan of the unit is blocked. Blocking these openings will inhibit the cooling of the internal temperature and result in malfunction.




- Do not press hard on the panel surface when installing the unit to the vehicle. Otherwise scars, damage, or failure may result.
- · Reception may drop if there are metal objects near the Bluetooth/Wi-Fi antenna



Bluetooth/Wi-Fi antenna unit


Forward and Lateral Fields of Vision

• To determine driver's forward and lateral fields of vision under normal conditions, place a pole (directly visible from the front or visible through the car rear-view mirror) as shown.




- o: Pole (height: 1m, diameter: 0.3m)
- : Field of vision from steering position
- : Exempted area (pole size is subject to regulation)
- · For right hand drive vehicles, standards are reversed.
- *1 The pole must be visible from the driver's position as direct forward field of vision.
- *2 The pole must be directly visible or indirectly visible through the mirror, etc. from the driver's position.

Supplied accessories for installation



Connection/Installation



Installation procedure


- To prevent a short circuit, remove the key from the ignition and disconnect the ⊖ terminal of the battery.
- 2) Remove the vehicle parts for installing the unit and connecting wires to terminal.
- 3) Make the proper input and output wire connections for each unit.
- 4) Connect the speaker wires of the wiring harness.
- 5) Connect the wiring harness wires in the following order; ground, battery, ignition.
- Determine the height of the display unit and position of the slider. See Distance between the display unit and the main unit (P.85).
- 7) Connect the wiring harness connector to the unit.
- 8) Install the main unit to the vehicle.
- 9) Reinstall the vehicle parts.
- 10) Install the display unit.
- 11) Reconnect the \bigcirc terminal of the battery.
- 12) Perform the Initial Setup. See *Initial SETUP (P.6)*.

Installing the unit

Confirm the installing position of the display unit


Vehicles cannot be installed

It may be possible to install if it can avoid the following by adjustment for slider position and display height.



Distance between the display unit and the main unit

Adjust slider position and display height so that it does not interfere with display movement.



Unit: mm

Examples

Cluster panel on the vehicle



Slider in back

position



Slider in forward position

· C'=50mm:

Slider position: Forward position Display height: Set only "4"


· C'=30mm:

Slider position: Back position Display height: Set only "4"


Slider position: Forward position Display height: Set "2"~"4"

Positioning the slider in forward


1 Remove the four screws from the bottom of the main unit.




2 Remove the two cover for back position, and then remove the two hexagon head screws from the bracket for back position.




3 Pull the slider block forward and remove the two hexagon head screws to remove the bracket for back position.



4 Install the bracket for forward position (accessory (10)) each side so that its projections are aligned with the slots on the main unit.




5 Fix the bracket for forward position to the slider block with the two hexagon head screws. Push the slider block until it stops and then fix the bracket for forward position to the main unit with the two hexagon head screws.



6 Reinstall the four screws to the bottom of the main unit.




7 Install the cover for forward position (accessory (9)) to two locations, as shown.




Adjusting the display height

1 Remove the four flat head screws from both sides.



2 Adjust the display height according to the screw hole position. Default is "1".



3 Reinstall the four flat head screws on both sides and fix the display.

NOTE


· Fix with flat head screws correctly. After installing the display unit (accessory ®) to the main unit, tilt the display forward until it stops and confirm that the display unit (accessory (8)) does not hit vehicle parts. If the display unit hits vehicle parts, adjust the display height again.

GPS antenna

GPS antenna is installed inside of the car. It should be installed as horizontally as possible to allow easy reception of the GPS satellite

To mount the GPS antenna inside your vehicle:


- 1) Clean your dashboard or other surface.
- 2) Remove the separator of the metal plate (accessory (7)).
- 3) Press the metal plate (accessory (7)) down firmly on your dashboard or other mounting surface. You can bend the metal plate (accessory 7) to conform to a curved surface, if necessary.
- 4) Remove the separator of the GPS antenna (accessory 6), and stick the antenna to the metal plate (accessory 7).



- Use the supplied GPS antenna. Using the GPS antenna other than the supplied one may cause a drop in positioning accuracy.
- Depending on the type of car, reception of the GPS satellite signals might not be possible with an inside installation
- · Please install this GPS antenna in an area away from any antennas that are used with CB radios or satellite televisions.
- The GPS antenna should be installed at a position that is spaced at least 12 inch (30 cm) from smartphone/cell-phone or other transmitting antennas. Signals from the GPS satellite may be interfered with by these types of communication.
- · Painting the GPS antenna with (metallic) paint may cause a drop in performance.

Microphone unit


- 1) Check the installation position of the microphone (accessory ③).
- 2) Clean the installation surface.
- 3) Remove the separator of the microphone (accessory ③), and stick the microphone to the place shown below.
- 4) Wire the microphone cable up to the unit with it secured at several positions using tape or other desired method.
- 5) Adjust the direction of the microphone (accessory ③) to the driver.




Fix a cable with a commercial item of tape.

Installing the main unit


- Determine the slider position before installing the main unit. (P.86) The slider position cannot be changed after installing to the vehicle.
- Make sure that the unit is installed securely in place. If the unit is unstable, it may malfunction (eg, the sound may skip).
- 1 Remove parts that interfere with installing such as a panel on the vehicle.
- 2 Install the car bracket to the main unit.



- **3** Connect the wiring harness wires and peripheral equipment.
- 4 Install the main unit to the vehicle.
- 5 Reinstall the removed parts such as a panel on the vehicle.




6 Install the display unit (accessory ®) to the main unit.




NOTE

- If the display unit hits a panel on the vehicle, adjust the display height by referring to Adjusting the display height (P.87).
- **7** Fix the display unit with six hexagon head screws (accessory ①).




8 Attach the protective cover (accessory ②) to coupling part, and then fix it with two binding head screws (accessory ③).



- If the protective cover (accessory ②) is not attached, this unit will not turn on. Even if the unit is turned on, the power may be turned off halfway.
- Be sure to attach the protective cover (accessory
- 9 Raise the display manually.


Connecting wires to terminals



using the optional rear view camera.

3-way speaker system setup


DMX1057XR



NOTE

- · For speaker system setup, see 3-way speaker system setup (P.67).
- · For speaker setup and crossover setup, see Speaker / X'over setup (P.68).
- For how to connect speaker wires to terminals other than speaker terminals and Preout terminals, see Connecting the system and external components (P.91) and Connecting wires to terminals (P.90).

Connecting the system and external components



- 2 FM/AM antenna input
- 3 AV Audio output (ø3.5 mini jack)
- When connecting to an external amplifier, connect its ground wire to the car's chassis to avoid damaging the unit.



SiriusXM Connect Vehicle Tuner connector 5 For more information on how to install the SiriusXM Connect Vehicle tuner, consult the installation guide included with the tuner.


Connection/Installation

HDMI input 6 Use HDMI cable KCA-HD100 (optional accessorv). When you connect the cable to HDMI terminal, remove the fixture. After connecting the cable, put the fixture again. HDMI connector iDatalink connector 7 8 Dashboard camera interface Connect a Dashboard Camera DRV-N520 (optional accessory). (P.94) AV Audio input (ø3.5 mini jack) 9 10 Accessory 6: GPS Antenna Use the supplied GPS antenna. Using the GPS antenna other than the supplied one may cause a drop in positioning accuracy.

- 3rd view camera input (Yellow). See **To set up** the camera assignment settings (P.57).
- Rear view camera input (Yellow) *1
- Front view camera/Dashboard camera input (Yellow).
 See **To set up the camera assignment**
- settings (P.57). *2

 14 Video output (Yellow)
- 15 Video input (Yellow)
- *1 Connect an HD camera to Rear view camera input terminal to use HD video.
- *2 Connect an HD camera to Front view camera/ Dashboard camera input terminal to use HD video.


Connecting a USB device




- ^[1] USB maximum power supply current: DC 5 V 1.5 A
- [2] Sold separately
- [3] See **Securing the USB extension cable** (P.93).

Securing the USB extension cable

Secure the USB extension cable with insulating tape or the like so that its connectors are not disconnected.




■ Connecting an iPod/iPhone




- ^[1] USB maximum power supply current : DC 5 V 1.5 A
- [2] Sold separately
- [3] Optional accessory
- [4] See **Securing the USB extension cable** (**P.93**).

Connecting an Android smartphone



- ^[1] USB maximum power supply current : DC 5 V = 1.5 A
- [2] Sold separately
- [3] See **Securing the USB extension cable** (P.93).

Connecting the camera



- [1] Optional accessory
- [2] Sold separately
- ^[3] Up to 3 cameras of Dashboard camera, Front view camera, Left side view camera and Right side view camera can be connected. For more information, see *To set up the camera assignment settings (P.57)*.
- [4] CMOS-3xx series (optional accessory) or commercially available camera.

- [5] For HD video, an HD camera is also used as Rear view camera.
- ^[6] For HD video, an HD camera is also used as Front view camera.

Troubleshooting

Problems and Solutions

If any trouble occurs, first check the following table for possible problems.

NOTE

- Some functions of this unit may be disabled by some settings made on this unit.
- What might seem to be a malfunction in your unit may just be the result of slight misoperation or miswiring.

About settings

- · Cannot set up the subwoofer.
- · Cannot set up subwoofer phase.
- · No output from the subwoofer.
- Cannot set up the low pass filter.
- Cannot set up the high pass filter.

Subwoofer is not set to on.

➤ Set the subwoofer to on. See **Speaker / X'over** setup (P.68).

The dual zone function is enabled.

- Set the dual zone function to off. See Zone Control (P.73).
- Cannot select the output destination of the subsource in the dual zone.
- Cannot adjust the volume of the rear speakers.

The dual zone function is disabled.

- ➤ Set the dual zone function to on. See **Zone Control** (P.73).
- · Cannot set up the equalizer.
- · Cannot set up the crossover network.

The dual zone function is enabled.

 Set the dual zone function to off. See Zone Control (P.73).

About audio operations

Radio reception is poor.

The car antenna is not extended.

> Pull out the antenna all the way.

The antenna control wire is not connected.

 Connect the wire correctly. See Connecting the system and external components (P.91).

Cannot select a folder.

The random play function is enabled.

➤ Turn off the random function.

The unit does not respond when you try to perform a operation during USB mirroring.

➤ Unplug the smartphone from the USB terminal, then reattach the smartphone again.

Others

The Touch Sensor Tone doesn't sound.

The preout iack is being used.

➤ The Touch Sensor Tone cannot be output from the preout jack.

Error Messages

When you fail to operate the unit correctly, the cause of the failure appears as the message on the screen.

There is an error in the speaker wiring. Please check the connections.

Protective circuit has been activated because a speaker cord has shorted or it has come in contact with the car chassis.

➤ Wire or insulate the speaker cord as appropriate and turn the power off and on again.

Hot Error

When the internal temperature of this unit rises to 60°C or more, the protection circuit is activated and you may not be able to operate the unit.

➤ Use the unit again after reducing the temperature of the unit.

Error 07-67

The unit is not operating correctly due to some reason or other.

 Turn the power off and on again. If the "Error 07–67" message does not disappear, contact your nearest KENWOOD dealer.

No Device (USB device)

The USB device is selected as a source although no USB device is connected.

 Change the source to any source other than USB/ iPod. Connect a USB device, and change the source to USB again.

Disconnected (iPod, Bluetooth audio player)

The iPod/Bluetooth audio player is selected as a source although no iPod/Bluetooth audio player is connected.

➤ Change the source to any source other than iPod/ Bluetooth. Connect an iPod/Bluetooth audio player, and change the source to iPod/Bluetooth again.

No Media file

The connected USB device contains no playable audio file. Media was played that does not have data recorded that the unit can play.

➤ See **Playable Media and Files (P.97)** and try another USB device.

USB device over current status detected.

The connected USB device is rated a current capacity higher than the allowable limit.

- ➤ Check the USB device. Some trouble may have occurred to the connected USB device.
- Change the source to any source other than USB.
 Remove the USB device.

The speed sense wire is not connected. Please check the connection.

The speed pulse disconnection is detected. By default, it is treated as connected.

➤ To improve precision of a vehicle position recognition, check the connection of the speed pulse.

Starting tuner failed.

The tuner unit is not operating correctly due to some reason or other.

➤ Turn the power off and on again. If the "Starting tuner failed." message does not disappear, contact your nearest KENWOOD dealer.



Check Tuner

A SiriusXM tuner is not connected to this unit.

➤ Verify that the SiriusXM Connect Vehicle Tuner cable is securely connected to the radio.

Subscription Updated - Press Return To Continue

The SiriusXM subscription has been renewed.

Touching Return on the popup screen will clear the message.

SXM Chan Unavailable

The currently selected channel is unavailable.

➤ Visit www.siriusxm.com for more information about the SiriusXM channel lineup.

SXM Ch Unsubscribed

The currently selected channel is not subscribed to.

- ➤ In the U.S.A., visit www.siriusxm.com or call 1-866-635-2349 if you have questions about your subscription package or would like to subscribe to this channel.
- ➤ In Canada, visit www.siriusxm.ca or call 1-877-438-9677.

SXM Check Antenna

No antenna is connected to the SiriusXM tuner.

➤ Check that an antenna is connected to the SiriusXM tuner. Check antenna for damages.

SXM No Signal

No SiriusXM radio signal is received.

 Verify that your vehicle is outdoors with a clear view of the sky.

Channel Locked

The selected channel has been locked by the parental controls.

➤ Enter the unlock code when you are asked. See Parental Control (P.39).

Incorrect Pass Code entered

The selected channel is a mature or parental lock channel, and locked by the parental lock or user lock code.

Enter the correct lock code.



The GPS antenna must be connected to use Apple CarPlay wirelessly. Please verify the proper connections or plug in by USB to use Apple CarPlay.

The GPS antenna is not connected when the Apple CarPlay is started by connecting wirelessly or when the iPhone compatible with wireless Apple CarPlay is registered in **Device List**.

➤ Check the connection of the GPS antenna or plug in over USB to use Apple CarPlay.

Appendix

Playable Media and Files

You can play various kinds of media and files on this unit.

About files

The following audio and video files are supported.

■ Playable Audio files

| | Format | Bit rate | Sampling frequency | Bit count |
|-----------------------------|---|------------------|----------------------------|---------------|
| AAC-LC (.m4a) | MPEG-2/MPEG-4 AAC LC HE-AAC(V1,V2) | 8 – 320kbps, VBR | 16 – 48 kHz | 16 bit |
| MP3 (.mp3) | MPEG-1/MPEG-2 Audio Layer 3 | 8 – 320kbps, VBR | 16 – 48 kHz | 16 bit |
| WMA (.wma) | Windows Media Audio Standard L3 profile (Version 7,8,9) | 8 – 320kbps | 16 – 48 kHz | 16 bit |
| Linear PCM (WAVE) (.wav) | RIFF waveform Audio Format | _ | 16 – 192 kHz | 16 bit/24 bit |
| FLAC (.flac) | flac | - | 16 – 192 kHz | 16 bit/24 bit |
| Vorbis (.ogg) | vorbis | - | 16 – 48 kHz | 16 bit |
| DSD (.dsf, .dff) | DSF, DSDIFF | - | 2.8 MHz, 5.6 MHz, 11.2 MHz | 1 bit |

- · WMA and AAC files with DRM cannot be played.
- DSD sound is converted to PCM sound before playback.
- · The EmChinks tag of DSDIFF is not supported.
- Although the audio files complies with the standards listed above, they may not be played depending on the types or conditions of media or device.
- This unit supports playback of High-Resolution Audio files. It is recommended that a car audio system should be configured with all High-Resolution Audio compatible products from player to speaker to enjoy its high quality sound.

■ Acceptable Video files

| | Profile | Max. Picture size | Max. bit rate | Audio format |
|--|--|----------------------|---------------|--------------------------------|
| MPEG-1 (.mpg, .mpeg) | - | 352 × 240, 352 × 288 | 1.5 Mbps | MPEG Audio Layer 2 |
| MPEG-2 (.mpg, .mpeg) | MP@ML | 720 × 480, 720 × 576 | 8 Mbps | MPEG Audio Layer 2 |
| H.264/MPEG-4 AVC (.mp4, .m4v, .avi, .flv, .f4v) | Baseline Profile, Main Profile | 1920 × 1080 (30 fps) | 8 Mbps | MP3, AAC |
| MPEG-4 (.mp4, .avi) | Advanced Simple Profile | 1920 × 1080 (30 fps) | 8 Mbps | MP3, AAC |
| WMV (.wmv) | Main Profile | 1920 × 1080 (30 fps) | 8 Mbps | WMA |
| MKV (.mkv) | Video format follows H.264/MPEG-4 AVC, MPEG-4, WMV | | | MP3, AAC, WMA, Vorbis, FLAC |

[•] This unit can only play back files which are smaller than 4 GB.

Appendix

■ Limitation on structure of file and folder

| | USB device |
|--|------------|
| Maximum number of folder layers | 8 |
| Maximum number of files (per folder) | 999 |
| Maximum number of folders (per folder) | 9999 |
| Maximum number of folders (per device) | Unlimited |

- You can enter a folder name and file name with 255 or fewer single-byte characters.
- Files in the folder whose folder name begins with a dot (.) cannot be played.

Specifications

■ Monitor section

Picture Size

: 10.1 inches (diagonal) wide

: 223.7 mm (W) \times 125.8 mm (H)

8-13/16 × 4-15/16 inch

Display System

: AAS LCD panel

Drive System

:TFT active matrix system

Number of Pixels

: 2,764,800 (1280H × 720V × RGB)

Effective Pixels

: 99.99 %

Pixel Arrangement

: RGB striped arrangement

Back Lighting

: LED

■ USB interface section

USB Standard

: USB 2.0 High Speed

File System

: FAT16, FAT32, exFAT, NTFS

Maximum Power Supply Current

: DC 5 V 1.5 A

D/A Converter

: 24 bit/32 bit

Audio Decoder

: MP3 / WMA / AAC / WAV / FLAC / DSD / Vorbis

Video Decoder

: MPEG-1 / MPEG-2 / MPEG-4 / WMV / H.264 / MKV

Frequency Response

• 192 kHz: 20 – 88,000 Hz

• 96 kHz: 20 - 44,000 Hz

48 kHz: 20 – 22.000 Hz

44.1 kHz: 20 – 20,000 Hz

Total Harmonic Distortion

: 0.010 % (1 kHz)

S/N Ratio (dB)

: 98.5 dB

Dynamic Range

: 89 dB

■ Wireless Mirroring Section

Mode

: Sink

Copyright protection

: HDCP2.2

Touch Control

: UIBC

■ Wi-Fi section

IFFF Standard

: 802.11 a/b/g/n/ac

Frequency Range

: Dual Band (2.4GHz/5GHz)

Channels

: Auto(1-11ch)/Auto(149,153,157,161ch)

Transfer rates (MAX)

: 11a: 54 Mbps / 11b: 11 Mbps / 11g: 54 Mbps / 11n: 300 Mbps / 11ac: 867 Mbps

Output Power

2.4 GHz/SISO

: 11b: 12 dBm \pm 2 dB / 11g: 4 dBm \pm 2 dB / 11n (20MHz): 2 dBm \pm 2 dB

5 GHz/SISO

: 11a: 6 dBm ± 2 dB /

11n (20 MHz)/11ac (20 MHz): 6 dBm \pm 2 dB / 11n (40 MHz)/11ac (40 MHz): 5 dBm \pm 2 dB / 11ac (80 MHz): 5 dBm \pm 2 dB

5 GHz/MIMO

: 11n (20 MHz)/11ac (20 MHz): 9 dBm ± 2 dB / 11n (40 MHz)/11ac (40 MHz): 8 dBm ± 2 dB / 11ac (80 MHz): 8 dBm ± 2 dB

■ Bluetooth section

Technology

: Bluetooth Ver.5.0

Frequency

: 2.402 - 2.480 GHz

RF Output Power (E.I.R.P.)

: +4 dBm (MAX), Power Class 2

Maximum Communication range

: Line of sight approx. 10m (32.8 ft)

Audio Codec

: LDAC (DMX1057XR) / SBC / AAC

Profile (Multi Profile support)

- HFP (V1.7) (Hands Free Profile)
- SPP (Serial Port Profile)
- · A2DP (Advanced Audio Distribution Profile)
- · AVRCP (V1.6) (Audio/Video Remote Control Profile)
- · PBAP (Phonebook Access Profile)

Appendix

■ HDMI section

HDMI

:Type-A

Input Resolution

- VGA (640x480p @59.94Hz/60Hz)
- 480p (720x480p @59.94Hz/60Hz)
- 720p (1280x720p @59.94Hz/60Hz)

Input Audio Type

: 32K/44.1K/48K/88.2K/96K/176.2K/192K Hz 16 bit/20 bit/24 bit Linerar PCM

■ DSP section

Graphics equalizer

Band: 13 Band

Frequency (BAND1 - 13)

: 62.5/100/160/250/400/630/1k/1.6k/2.5k/4k/6.3k/ 10k/16k Hz

Gain

:-9/-8/-7/-6/-5/-4/-3/-2/-1/0/1/2/3/4/5/6/7/8/9 dB

2-way X'Over

High pass filter

Frequency: Through, 30/40/50/60/70/80/90/100/ 120/150/180/220/250 Hz

Slope: -6/-12/-18/-24 dB/Oct.

Low pass filter

Frequency: 30/40/50/60/70/80/90/100/120/150/ 180/220/250 Hz, Through

Slope: -6/-12/-18/-24 dB/Oct.

3-way X'Over (DMX1057XR)

High pass filter

Frequency: 250/300/1k/1.6k/2.5k/4k/5k/6.3k/8k/ 10k/12.5k Hz

Slope: -12/-18/-24 dB/Oct.

Band pass filter

Frequency: Through, 50/60/70/80/90/100/120/150/

180/220/250/300 Hz

250/300/1k/1.6k/2.5k/4k/5k/6.3k/8k Hz,

Through

Slope: -12/-18/-24 dB/Oct.

Low pass filter

Frequency: 30/40/50/60/70/80/90/100/120/150 Hz, Through

Slope: -12/-18/-24 dB/Oct.

Position

Front/Rear/Subwoofer Delay

: 0 - 20.01 ft (0.03 or 0.04 ft Step)

Gain

:-8 - 0 dB

Subwoofer level

:-50 - +10 dB

■ Digital FM tuner section

Frequency Range (step)

: 87.9 MHz - 107.9 MHz (200 kHz)

Frequency Response (± 3.0 dB)

: 20 Hz - 20 kHz

S/N Ratio

: 80 dB (STEREO)

■ Digital AM tuner section

Frequency Range (step)

: 530 kHz - 1700 kHz (10 kHz)

Frequency Response (± 3.0 dB)

: 40 Hz – 15 kHz

S/N Ratio (dB)

: 80 dB (STEREO)

■ FM tuner section

Frequency Range (step)

: 87.9 MHz - 107.9 MHz (200 kHz)

Usable Sensitivity (S/N: 30 dB)

: 7.3 dBf (0.7 μV/75 Ω)

Frequency Response

: 30 Hz - 15 kHz

S/N Ratio (dB)

: 70 dB (MONO)

Selectivity (± 400 kHz)

: 80 dB

Stereo Separation

: 45 dB (1 kHz)

AM tuner section

Frequency Range (step)

: 530 kHz - 1700 kHz (10 kHz)

Usable Sensitivity

: 30 dBμ (31 μV)

■ Video section

Color System of External Video Input

: NTSC/PAI

External Audio Max Input Level (mini jack)

: 2 V/25 kΩ

Video Input Level (RCA jacks)

: 1 Vp-p/75 Ω

Video Output Level (RCA jacks)

: 1 Vp-p/75 Ω

Audio Output Level (mini jack)

: 0.9 V/10 kΩ

■ Audio section

Maximum Power Output (Front & Rear)

 $:50 W \times 4$

Typical Power Output (Front & Rear)

Full Bandwidth Power (at less than 1% THD)

: 22 W × 4

Output frequency band

: 20 - 88,000 Hz

Preout Level (V)

DMX1057XR : 5 V/10 kΩ DMX1037S : 4 V/10 kΩ

Preout Impedance

: ≤ 300 Ω

Speaker Impedance

:4-8 Q

■ General

Operating Voltage

: 12V DC car battery

Installation Dimensions (W \times H \times D)

: $178 \times 100 \times 155 \text{ mm}$ $7 \times 3-15/16 \times 6-1/8 \text{ inch}$

Weight

: 3.25 kg (7.28 lbs)

NOTE

 Although the effective pixels for the liquid crystal panel is given as 99.99% or more, 0.01% of pixels may not light or may light incorrectly.

Specifications are subject to change without prior notice.

About this Unit



Important Notice on Software

■ Software License on This Product

The software embedded in this product comprises a number of independent software components, each of which is copyrighted by JVCKENWOOD Corporation or by a third party.

This product uses software components that are based on an End-User License Agreement (hereinafter called "EULA") stipulated by JVCKENWOOD Corporation and by third parties.

The EULA dictates the availability of the source codes of free-software components as a prerequisite to distributing them in executable form under the terms of the GNU General Public License or the Lesser General Public License (hereinafter called "GPL/LGPL"). To get information about the software components that are subject to the terms of the GPL/LGPL, please visit the following Website:

Website URL https://www2.jvckenwood.com/gpl/ Queries concerning the contents of the source code or the like will not be accepted.

Please note that software components based on a EULA that is not subject to the terms of the GPL/LGPL or those that have been developed or created by JVCKENWOOD Corporation will be excluded from the scope of source code disclosure.

Because licenses to use software components distributed under the GPL/LGPL are offered to the customers for free of charge, no warranty is granted to the customers, whether explicitly or implicitly, to the extent of the applicable laws.

Unless otherwise stipulated by the applicable laws or agreed upon in writing, the copyright holders or those who are entitled to modify and redistribute the software components are not held responsible for any and all damages resulting from their use or from inability to use them. For more information about the terms of use of the software components, required items of compliance and so on, please refer to the GPL/ LGPL.

Customers wishing themselves to use a software component that is subject to the GPL/LGPL embedded in this product are encouraged to read the terms of the corresponding license before use. Because each individual license is prescribed by a third party other than JVCKENWOOD Corporation, the original (English) of the license is presented.



■ Software License Agreement

JVCKENWOOD Corporation (hereinafter called "Licensor") holds either the copyright to the embedded software or the right to sublicense it. This agreement establishes the conditions under which the customer uses this "Licensed Software"

The customer shall agree to the terms of this license agreement before proceeding to use Licensed Software.

This agreement is deemed to have taken effect when the customer (hereinafter called "User") has used a product implementation of Licensed Software.

The Licensed Software may contain software Licensor has been licensed to use by third parties directly or indirectly. Some third parties may have terms of use prescribed for their customers, apart from this Software License Agreement. This agreement does not apply to such software. Be sure to consult "Important Notice on Software" as presented separately.

Article 1 (General)

Licensor grants to User a non-exclusive, nonassignable right of use Licensed Software within the country where the User purchases the Product (hereinafter the "Country") (except for the exception provided for in Paragraph 1, Article 3).

Article 2 (Right of Use)

- 1. The rise of use granted under this agreement is the right to use Licensed Software in this product.
- 2. User may not duplicate, copy, modify, add to, translate or otherwise alter, or loan licensed Software and the associated literature in whole or in part.
- 3. Use of Licensed Software is limited to a private extent, and Licensed Software may not be distributed, licensed or sublicensed for any purposes whatsoever, including commercial use.
- 4. User shall use Licensed Software as per the instruction manual or instructions given in the help file and may not use or duplicate data in violations of the regulations of the Copyright Law or other governing laws by using Licensed Software in whole or in part.

Article 3 (Terms of License)

- 1. In assigning this product, User may not retain the original copy of the embedded Licensed Software (including associated literature, updates and upgrades) and any duplicates and associated literature with regard to the license to use Licensed Software. User may transfer Licensed Software only to the condition of binding the assignee to abide by the terms of this Software License Agreement.
- 2. User may not reverse-engineer, disassemble, decompile or otherwise analyze the source code of Licensed Software.

Article 4 (Rights to Licensed Software)

All rights to Licensed Software and the associated literature, including copyrights, shall reside with Licensor or

the original right holder who has granted the Right of Use and right to sublicense to Licensor (hereinafter referred to as "Original Right Holder"), and User does not have any rights other than Right of Use granted hereunder with regard to Licensed Software and the associated literature.

Article 5 (Exemption Granted to Licensor)

- Licensor and Original Right Holder do not assume any responsibility for damages caused to User or third parties resulting from the exercise by User of the license granted hereunder, unless otherwise provided by any law to the contrary.
- Licensor does not warrant Licensed Software to be merchantable, compatible and fit for specific purposes.

Article 6 (Responsibility for Third Parties)

If disputes over the infringement of third parties' intellectual property rights, such as copyrights and patent rights, arise out of the use of Licensed Software by User, User shall resolve these disputes at User's own expenses while keep Licensor and Original Right Holder harmless.

Article 7 (Secrecy Obligation)

User shall keep confidential Licensed Software provided hereunder, information contained in the associated literature or the like and those provisions of this agreement not yet in public knowledge and may not disclose or leak these to third parties without prior written consent from Licensor.

Article 8 (Cancellation of the Agreement)

Licensor reserves the right to cancel this agreement forthwith and claim compensation from User for the damages caused by such cancellation when User:

- (1) Breaches any of the provisions of this agreement, or
- (2) Has received a petition for seizure, provisional seizure, provisional disposition or any other kind of compulsory execution.

Article 9 (Destruction of Licensed Software)

If this agreement is terminated under the provision of the foregoing paragraph, User shall destroy Licensed Software, along with all associated literature and its duplicates, within two (2) weeks from the date of termination.

Article 10 (Copyright Protection)

- Copyrights and all other intellectual property rights relating to Licensed Software shall reside with Licensor and Original Right Holder and in no circumstances with User.
- User shall abide by the laws relating to copyrights and intellectual property rights in using Licensed Software.

Article 11 (Export Control)

- Licensed Software and the associated literature or the like may not be exported to places outside the Country (including transmission outside the Country over the Internet or the like).
- User agrees that Licensed Software is subject to export controls imposed by the Country and the United States of America.
- User agrees to comply with all the international and domestic laws that apply to this software (U.S. Export Administration Regulations and regulations established by the U.S., the Country and their governmental agencies regarding usage by end users and export destinations).

Article 12 (Miscellaneous)

- 1. Even if this agreement is invalidated in part by law, all other provisions shall remain in effect.
- Licensor and User shall consult each other in good faith to resolve any matters not provided for in this agreement or questions arising from the interpretation of this agreement.
- Licensor and User agree that this agreement is governed by the law of Japan and that all disputes involving claims and obligations that may arise out of this agreement will be settled by arbitration at the Tokyo District Court as the court of first instance.

■ Copyrights

- · The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by JVCKENWOOD Corporation is under license. Other trademarks and trade names are those of their respective owners.
- DSD, LDAC and LDAC logo are trademarks of Sony Corporation.
- · Hi-Res Audio logo and Hi-Res Audio Wireless logo are used under license from Japan Audio Society.





- · Windows Media is a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries. This product is protected by certain intellectual property rights of Microsoft, Use or distribution of such technology outside of this product is prohibited without a license from Microsoft.
- This software is based in part on the work of the independent JPEG Group.
- · Use of the Made for Apple badge means that an accessory has been designed to connect specifically to the Apple product(s) identified in the badge, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with an Apple product may affect wireless performance.
- · Apple, iPhone, iPod, iPod touch, and Lightning are trademarks of Apple Inc., registered in the U.S. and other countries.
- · Apple, Siri, Apple CarPlay, Apple Music and Apple CarPlay logo are trademarks of Apple Inc., registered in the U.S. and other countries.
- · App Store is a service mark of Apple Inc., registered in the U.S. and other countries.
- IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under
- · Sirius, XM and all related marks and logos are trademarks of Sirius XM Radio Inc. All rights reserved.
- · HD Radio Technology manufactured under license from iBiguity Digital Corporation, U.S. and Foreign Patents. For patents see https://dts.com/patents. HD Radio and the HD, HD Radio, and "ARC" logos are registered trademarks or trademarks of iBiquity Digital Corporation in the United States and/or other countries
- · INRIX is a registered trademark of INRIX, Inc.
- · Google, Android, Google Play and Android Auto are trademarks of Google LLC. To use Android Auto on your car display, you'll need

an Android Auto compatible vehicle or aftermarket stereo, an Android phone running Android 5.0 or higher, and the Android Auto app.

- · Wi-Fi® is a registered trademark of Wi-Fi Alliance®.
- The Wi-Fi CERTIFIED™ Logo is a certification mark of Wi-Fi Alliance®
- · Copyright© 2018 Techpoint, Inc. All rights reserved.

HD-TVI

- · The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.
- This product includes FontAvenue® fonts licenced by NEC Corporation. Font Avenue is a registered trademark of NEC Corporation.



FontAvenue

 This product includes "Ubiquitous OuickBoot TM" technology developed by Ubiquitous Corp. Ubiquitous QuickBoot TM is a trademark of Ubiquitous Corp. Copyright@ 2017 Ubiquitous Corp. All rights reserved.

____ Ubiquitous

- THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA. L.L.C. SEE HTTPS://WWW.MPEGLA.COM
- THIS PRODUCT IS LICENSED UNDER THE MPEG-4 VISUAL PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER FOR (;) ENCODING VIDEO IN COMPLIANCE WITH THE MPEG-4 VISUAL STANDARD ("MPEG-4 VIDEO") AND/OR (ii) DECODING MPEG-4 VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED BY MPEG LA TO PROVIDE MPEG-4 VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE, ADDITIONAL INFORMATION INCLUDING THAT RELATING TO PROMOTIONAL INTERNAL AND COMMERCIAL USES AND LICENSING MAY BE OBTAINED FROM MPEG LA. LLC. SEE HTTPS://WWW.MPEGLA.COM.
- THIS PRODUCT IS LICENSED UNDER THE VC-1 PATENT. PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE VC-1 STANDARD ("VC-1 VIDEO") AND/OR (ii) DECODE VC-1 VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER

LICENSED TO PROVIDE VC-1 VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE <u>HTTPS://WWW.MPEGLA.</u>COM

libFLAC

Copyright (C) 2000-2009 Josh Coalson Copyright (C) 2011-2013 Xiph.Org Foundation Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the Xiph.org Foundation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission. THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE FOUNDATION OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES: LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE. EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

· libvorbis

Copyright (c) 2002-2008 Xiph.org Foundation Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the Xiph.org Foundation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission. THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY

EXPRESS OR IMPLIED WARRANTIES, INCLUDING. BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE FOUNDATION OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES: LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE. EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

libogg

Copyright (c) 2002, Xiph.org Foundation Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the Xiph.org Foundation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission. THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE FOUNDATION OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE. EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Appendix

■ FCC CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
- This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

■ ISED CAUTION

This device contains licence-exempt transmitter(s)/ receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s)

Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

A CAUTION

This equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the ISED radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 20cm or more away from person's body.

Supplier's Declaration of Conformity

Trade Name: KENWOOD

Products: MONITOR WITH RECEIVER
Model Name: DMX1057XR / DMX1037S

Responsible Party: JVCKENWOOD USA

CORPORATION

2201 East Dominguez Street, Long Beach, CA 90810, U.S.A. PHONE: 310 639-9000

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CALISE LINDESIRED, OPERATION

■ Información acerca de la eliminación de equipos eléctricos y electrónicos al final de la vida útil (aplicable a los países que hayan adoptado sistemas independientes de recogida de residuos)



Los productos con el símbolo de un contenedor con ruedas tachado no podrán ser desechados como residuos domésticos.

Los equipos eléctricos y electrónicos al final de la vida útil, deberán ser reciclados en instalaciones que puedan dar el tratamiento adecuado a estos productos y a sus subproductos residuales correspondientes. Póngase en contacto con su administración local para obtener información sobre el punto de recogida más cercano. Un tratamiento correcto del reciclaje y la eliminación de residuos ayuda a conservar los recursos y evita al mismo tiempo efectos perjudiciales en la salud y el medio ambiente

■ Informação sobre a eliminação de pilhas

Este produto não deve ser eliminado como lixo doméstico geral. Devolva a pilha usada ao revendedor ou entidade autorizada para que a mesma seja devolvida ao fabricante ou importador.

A reciclagem e a eliminação de lixo de maneira apropriada ajudarão a conservar os recursos naturais ao mesmo tempo que prevenirão os efeitos prejudicais à nossa saúde e ao meio ambiente.

■ Para cumplimiento de la IFT:

"La operación de este equipo esta sujeta a las siguientes dos condiciones:

- (1) es posible que este equipo o dispositivo no cause interferencia perjudicial y
- (2) este equipo o dispositivo debe aceptar cualquier interferencia,

incluyendo la que pueda causar su operación no deseada."





android auto









Hi-Res Audio logo and Hi-Res Audio Wireless logo are used under license from Japan Audio Society.









HD2/HD3

Bookmark

Digital Sound

Program Info

Artist Experience

Emergency Alerts





DMX1057XR DMX1037S

MONITOR WITH RECEIVER

Quick Start Guide

MONITEUR AVEC RÉCEPTEUR

Guide de démarrage rapide

MONITOR CON RECEPTOR

Guía de inicio rápido

JVCKENWOOD Corporation

- Updated information (the latest Instruction Manual, system updates, new functions, etc.) is available from https://www.kenwood.com/cs/ce/.
 The Instruction manual is subject to change for modification of specifications and so forth. Be sure to download the latest edition of the Instruction manual for reference. https://manual.kenwood.com/edition/im406/>
- Des informations actualisées (le dernier mode d'emploi, les mises à jour du système, les nouvelles fonctions, etc.) sont disponibles sur le site https://www.kenwood.com/cs/ce/.
- Le mode d'emploi est susceptible d'être modifié suite aux changements pouvant être apportés aux spécifications etc. Téléchargez impérativement la dernière édition du mode d'emploi aux fins de référence. https://manual.kenwood.com/edition/im406/
- La información actualizada (el Manual de instrucciones más actualizado, actualizaciones del sistema, nuevas funciones, etc.) está disponible desde https://www.kenwood.com/cs/ce/.
- El Manual de instrucciones está sujeto a cambios por modificaciones de las especificaciones, etc. Asegúrese de descargar la última edición del Manual de instrucciones a título de referencia. https://manual.kenwood.com/edition/im406/

Take the time to read through this instruction manual.

Familiarity with installation and operation procedures will help you obtain the best performance from your new receiver.

For your records

Record the serial number, found on the top of the unit, in the spaces designated on the warranty card, and in the space provided below. Refer to the model and serial numbers whenever you call upon your KENWOOD dealer for information or service on the product.

Model DMX1057XR / DMX1037S Serial number _____

US Residence Only

Register Online

Register your KENWOOD product at www.kenwood.com/usa/

Important Notice on Software

Software License on This Product

The software embedded in this product comprises a number of independent software components, each of which is copyrighted by JVCKENWOOD Corporation or by a third party. This product uses software components that are based on an End-User License Agreement (hereinafter called "EULA") stipulated by JVCKENWOOD Corporation and by third parties. The EULA dictates the availability of the source codes of free-software components as a prerequisite to distributing them in executable form under the terms of the GNU General Public License or the Lesser, General Public License (hereinafter called "GPL/LGPL"). To get information about the software components that are subject to the terms of the GPL/LGPL,

Website URL https://www2.jvckenwood.com/qpl/

please visit the following Website:

Queries concerning the contents of the source code or the like will not be accepted.

Please note that software components based on a EULA that is not subject to the terms of the GPL/LGPL or those that have been developed or created by JVCKENWOOD Corporation will be excluded from the scope of source code disclosure.

Because licenses to use software components distributed under the GPL/LGPL are offered to the customers for free of charge, no warranty is granted to the customers, whether explicitly or implicitly, to the extent of the applicable laws. Unless otherwise stipulated by the applicable laws or agreed upon in writing, the copyright holders or those who are entitled to modify and redistribute the software components are not held responsible for any and all damages resulting from their use or from inability to use them. For more information about the terms of use of the software components, required items of compliance and so on, please refer to the GPL/LGPL.

Customers wishing themselves to use a software component that is subject to the GPL/LGPL embedded in this product are encouraged to read the terms of the corresponding license before use. Because each individual license is prescribed by a third party other than

JVCKENWOOD Corporation, the original (English) of the license is presented.

EULA

Software License Agreement

JVCKENWOOD Corporation (hereinafter called "Licensor") holds either the copyright to the embedded software or the right to sublicense it. This agreement establishes the conditions under which the customer uses this "Licensed Software."

The customer shall agree to the terms of this license agreement before proceeding to use Licensed Software.

This agreement is deemed to have taken effect when the customer (hereinafter called "User") has used a product implementation of Licensed Software.

The Licensed Software may contain software Licensor has been licensed to use by third parties directly or indirectly. Some third parties may have terms of use prescribed for their customers, apart from this Software License Agreement. This agreement does not apply to such software. Be sure to consult "Important Notice on Software" as presented separately.

Article 1 (General)

Licensor grants to User a non-exclusive, non-assignable right of use Licensed Software within the country where the User purchases the Product (hereinafter the "Country") (except for the exception provided for in Paragraph 1, Article 3).

Article 2 (Right of Use)

- The rise of use granted under this agreement is the right to use Licensed Software in this product.
- User may not duplicate, copy, modify, add to, translate or otherwise alter, or loan licensed Software and the associated literature in whole or in part.
- Use of Licensed Software is limited to a private extent, and Licensed Software may not be distributed, licensed or sublicensed for any purposes whatsoever, including commercial use.
- 4. User shall use Licensed Software as per the instruction manual or instructions given in the help file and may not use or duplicate data in violations of the regulations of the Copyright Law or other governing laws by using Licensed Software in whole or in part.

Article 3 (Terms of License)

- In assigning this product, User may not retain the original copy of the embedded Licensed Software (including associated literature, updates and upgrades) and any duplicates and associated literature with regard to the license to use Licensed Software. User may transfer Licensed Software only to the condition of binding the assignee to abide by the terms of this Software License Agreement.
- User may not reverse-engineer, disassemble, decompile or otherwise analyze the source code of Licensed Software.

Article 4 (Rights to Licensed Software)

All rights to Licensed Software and the associated literature, including copyrights, shall reside with Licensor or

the original right holder who has granted the Right of Use and right to sublicense to Licensor (hereinafter referred to as "Original Right Holder"), and User does not have any rights other than Right of Use granted hereunder with regard to Licensed Software and the associated literature.

Article 5 (Exemption Granted to Licensor)

- Licensor and Original Right Holder do not assume any responsibility for damages caused to User or third parties resulting from the exercise by User of the license granted hereunder, unless otherwise provided by any law to the contrary.
- Licensor does not warrant Licensed Software to be merchantable, compatible and fit for specific purposes.

Article 6 (Responsibility for Third Parties)

If disputes over the infringement of third parties' intellectual property rights, such as copyrights and patent rights, arise out of the use of Licensed Software by User, User shall resolve these disputes at User's own expenses while keep Licensor and Original Right Holder harmless.

Article 7 (Secrecy Obligation)

User shall keep confidential Licensed Software provided hereunder, information contained in the associated literature or the like and those provisions of this agreement not yet in public knowledge and may not disclose or leak these to third parties without prior written consent from Licensor

Article 8 (Cancellation of the Agreement)

Licensor reserves the right to cancel this agreement forthwith and claim compensation from User for the damages caused by such cancellation when User:

- (1) Breaches any of the provisions of this agreement, or
- (2) Has received a petition for seizure, provisional seizure, provisional disposition or any other kind of compulsory execution.

Article 9 (Destruction of Licensed Software)

If this agreement is terminated under the provision of the foregoing paragraph, User shall destroy Licensed Software, along with all associated literature and its duplicates, within two (2) weeks from the date of termination.

Article 10 (Copyright Protection)

- Copyrights and all other intellectual property rights relating to Licensed Software shall reside with Licensor and Original Right Holder and in no circumstances with User.
- User shall abide by the laws relating to copyrights and intellectual property rights in using Licensed Software.

Article 11 (Export Control)

- Licensed Software and the associated literature or the like may not be exported to places outside the Country (including transmission outside the Country over the Internet or the like).
- User agrees that Licensed Software is subject to export controls imposed by the Country and the United States of America.
- 3. User agrees to comply with all the international and domestic laws that apply to this software (U.S. Export Administration Regulations and regulations established by the U.S., the Country and their governmental agencies regarding usage by end users and export destinations).

Article 12 (Miscellaneous)

- 1. Even if this agreement is invalidated in part by law, all other provisions shall remain in effect.
- Licensor and User shall consult each other in good faith to resolve any matters not provided for in this agreement or questions arising from the interpretation of this agreement.
- 3. Licensor and User agree that this agreement is governed by the law of Japan and that all disputes involving claims and obligations that may arise out of this agreement will be settled by arbitration at the Tokyo District Court as the court of first instance.

Contents

| Before Use4 | ٠ |
|---|---|
| About the Quick start guide4 | ŀ |
| How to read this manual4 | ٠ |
| Precautions4 | ٠ |
| Basic Operations6 | , |
| Functions of the Buttons on the Front Panel 6 | , |
| Turning on the Unit7 | |
| Initial Settings8 | |
| Adjusting the volume9 | , |
| Touch screen operations10 | į |
| HOME screen descriptions10 | į |
| Popup menu11 | |
| Source selection screen description11 | |
| Source control screen descriptions13 | , |
| List screen13 | , |
| USB/iPod14 | ŀ |
| Connecting a USB device14 | ŀ |
| Connect iPod/iPhone14 | ŀ |
| USB/iPod Basic Operation15 | , |
| HD Radio™ Tuner16 | , |
| HD Radio Tuner Basic Operation16 | , |
| Memory Operation17 | , |
| Bluetooth Control18 | ; |
| Register the Bluetooth device18 | 5 |
| Using the Hands-Free Unit19 | |
| Controlling Audio21 | |
| Connection/Installation22 | |
| Before Installation22 | , |
| Installing the unit25 | , |
| Appendix35 | , |
| Note for specifications 35 | |

Before Use

About the Quick start guide

 This Quick Start Guide describes basic functions of this unit. For functions not described in this Guide, refer to the Instruction Manual on the following website: https://manual.kenwood.com/edition/im406/



 The Instruction manual is subject to change for modification of specifications and so forth. Be sure to download the latest edition of the Instruction manual for reference.

How to read this manual

- The screens and panels shown in this manual are examples used to provide a clear explanation of operations.
- For this reason, they may be different from the actual screens or panels, or some display patterns may be different from the actual ones.
- Display language: English is used for the purpose of explanation. You can select a display language from the SETUP menu. See System Setup (P.65) in the Instruction Manual.

Precautions

▲ WARNINGS

To prevent injury or fire, take the following precautions:

- To prevent a short circuit, never put or leave any metallic objects (such as coins or metallic tools) inside the unit.
- Do not watch or fix your eyes on the unit's display when you are driving for any extended period.
- If you experience problems during installation, consult your KENWOOD dealer.

Precautions on using this unit

 When you purchase optional accessories, check with your KENWOOD dealer to make sure that they work with your model and in your area.

- You can select a language to display menus, audio file tags, etc. See System Setup (P.65) in the Instruction Manual.
- The Radio Broadcast Data System feature won't work in areas where the service is not supported by any broadcasting station.

Protecting the monitor

 To protect the monitor from damage, do not operate the monitor using a ball point pen or similar tool with a sharp tip.

Cleaning the unit

• If the faceplate of this unit is stained, wipe it with a dry soft cloth such as a silicon cloth. If the faceplate is stained badly, wipe it with a cloth moistened with neutral cleaner, then wipe it again with a clean soft dry cloth.

NOTE

 Applying spray cleaner directly to the unit may damage its mechanical parts. Wiping the faceplate with a hard cloth or using a volatile liquid such as thinner or alcohol may scratch the surface or erase the screened print.

Acquiring GPS signal

The first time you turn on this unit, you must wait while the system acquires satellite signals for the first time. This process could take up to several minutes. Make sure your vehicle is outdoors in an open area away from tall buildings and trees for fastest acquisition. After the system acquires satellites for the first time, it will acquire satellites quickly each time thereafter.

■ About GLONASS

This unit uses Global Navigation Satellite System (GLONASS) in addition to GPS.
Combining GPS and GLONASS can refine positioning accuracy than using GPS only.


☐ Caution for Smartphone Users

Simultaneously running multiple applications on your smartphone while screen sharing places heavy demand on the microprocessor of the phone, potentially affecting communication and performance.

For best results while pairing with your KENWOOD receiver, please be sure to close any unused applications.

Basic Operations

Functions of the Buttons on the Front Panel



| Number | Name | Motion | |
|--------|------------------|--|--|
| 1 | Remote Sensor | Receives the remote control signal. | |
| 2 | HOME/ | Displays the HOME screen (P.10). Pressing for 1 second turns the power off. When the power is off, turns the power on. | |
| 3 | CAM | Switches view camera display on/off. The camera whose view is displayed first changes according to the Camera Assignment Settings (P.34) and the shift lever position in the shift gate. The camera whose view was displayed last is kept and the same camera view will be displayed the next time. If its assignment setting is changed, the rear camera view is displayed. | |
| 4 | MENU/ATT | Displays the popup menu screen. Pressing for 1 second switches attenuation of the volume on/off. | |
| 5 | Volume knob | Adjusts the volume. (P.9) | |
| 6 | == | Displays the APP (Apple CarPlay/Android Auto/Wireless Mirroring) screen. While the APP screen is displayed, switches to the control screen of current source. | |
| 7 | VOICE | Switches the voice recognition function on/off. When neither Apple CarPlay, Android Auto, nor a Bluetooth Hands-Free phone is connected, pressing and holding displays Bluetooth pairing waiting dialog. | |

Turning on the Unit

1 Press the HOME/ U button.



➤ The unit is turned on.

- To turn off the unit:
- 1 Press the **HOME**/ \circlearrowleft button for 1 second.

NOTE

 If it is your first time to turn the unit on after installation, it will be necessary to perform Initial SETUP (P.8).

Initial Settings

Initial SETUP

Perform this setup when you use this unit first time.

1 Set each item as follows.



■ Language

Select the language used for the control screen and setting items. Default is "American English(en)".

- 1 Touch Language.
- (2) Touch Language Select.
- 3 Select the desired language.
- (4) Touch (5).

For details, see **System Setup (P.65)** in the Instruction Manual.

■ Clock

Sets the synchronization of the clock and adjusts it.

For details, see **Calendar/clock settings** (**P.9**).

■ Display & Button

Set the button illumination color.

- 1 Touch Display & Button.
- (2) Touch Button Illumination Color.
- (3) Select the desired color.
- 4 Touch 6.

For details, see *Display & Button Setup* (*P.63*) in the Instruction Manual.

■ Camera

Set the parameters for the camera.

- 1) Touch Camera
- ② Set each item and touch 有.

For details, see *Camera Setup (P.56)* in the Instruction Manual.

■ OEM SETUP

This function requires a commercial adaptor. Consult your KENWOOD dealer for details.

■ DEMO

Set the demonstration mode. Default is "ON".

2 Touch Finish.



NOTE

 These settings can be made from the SETUP menu. See Setup (P.61) in the Instruction Manual.

Calendar/clock settings

- 1 Press the HOME/ button.
- 2 Touch .
- 3 Touch SETUP.
 - > SETUP Menu screen appears.
- 4 Touch System.
 - > System setting menu appears.
- 5 Set each item as follows. Scroll the page to show hidden items.



■ Time Format

Select the time display format.

12-Hour (Default)/24-Hour

■ Clock

GPS-SYNC (Default): Synchronizes the clock time with the GPS.

Manual: Set the clock manually.

■ Time Zone

Select the time zone.

■ Clock Adjust

If you select Manual for Clock, adjust the date and time manually. (P.9)

NOTE

· Please set the date and time. If they are not set, some functions may not work.


- Adjust the date and time manually
- 1 Touch Clock Adjust in the System setting menu.
- 2 Adjust the date, then adjust the time.



3 Touch Set.

Adjusting the volume

You can adjust the volume (0 to 40). Turn the knob clockwise to increase, and counter-clockwise to decrease.



Touch screen operations

To perform operations on the screen, you need to touch, touch and hold, flick or swipe to select an item, display a setting menu screen or change pages.

Touch

Touch the screen gently to select an item on the screen.



Touch and hold

Touch the screen and keep your finger in place until the display changes or a message is displayed.



Flick

Slide your finger quickly to the left or right on the screen to change the page. You can scroll a list screen by flicking up/down on the screen.




Swipe

Slide your finger up or down on the screen to scroll the screen.



HOME screen descriptions

Most functions can be performed from the HOME screen.



- Widget
- Displays the source selection screen. (P.12)
- Displays the SETUP Menu screen.
- Short-cut playback source icons (P.12)

Display the HOME screen

1 Press the HOME/ U button.



➤ HOME screen appears.

Widget

- 1 Press the **HOME**/ \bigcirc button.
 - ➤ HOME screen appears.
- 2 You can change the widget or customize the widget area.




For details, see Widget (P.14) in the Instruction Manual.

Popup menu

- 1 Press the MENU/ATT button.
 - ➤ Popup menu appears.
- 2 Touch to display the popup menu.



The contents of the menu are as follows.



· Close the popup menu. · Displays the Device List screen. • Short-cut source icons: The source changes to the one you have set with a short-cut. For the short-cut setting, refer to Customize Short-cut source icons

Source selection screen description

(P.12).

You can display icons of all playback sources and options on the source selection screen.



- · Changes playback sources. П For playback sources, see Select the playback source (P.12).
- 2 Changes pages. (Touch (/).) You can also change pages by flicking left or right on the screen.
- · Returns to the previous screen. 3
- · Displays the SETUP Menu screen.

Select the playback source

- 1 Press the HOME/ button.
 - ➤ HOME screen appears.
- 2 Touch III.

From the screen, you can select the following sources and functions.

| HD Radio | • Switches to the HD Radio broadcast. (P.16) |
|-------------------|---|
| Apple CarPlay | Switches to the Apple CarPlay screen from the connected iPhone. |
| Android Auto | Switches to the Android Auto screen from the connected Android smartphone. |
| E m | Displays the Hands-Free screen. (P.19) When neither Apple CarPlay, Android Auto, nor a Bluetooth Hands-Free phone is connected, displays Bluetooth pairing waiting dialog. *1 |
| Windess Mirroring | Switches to the Wireless Mirroring screen from the connected Android smartphone. |
| SitusXM | Switches to the SiriusXM® satellite radio broadcast. |
| [r] Bluetooth | Plays a Bluetooth audio player. |
| J iPod | • Plays an iPod/iPhone. (P.15) |
| (f) USB | • Plays files on a USB device. (P.15) |
| P | Plays a device connected to the HDMI input terminal. |
| ∰ AV-IN | Switches to an external component connected to the AV Audio input and the Video input terminal. *2 *3 |
| CU | • Puts the unit in standby. (P.12) |

- *1 When connecting as Apple CarPlay or Android Auto, it works as a phone provided in Apple CarPlay or Android Auto. If Apple CarPlay or Android Auto are connected during talking by the Bluetooth device or iDatalink phone, the current call will be continued.
- *2 You can use the **AV-IN** source when a cable from a visual source except a camera is connected to the Video input terminal, and a cable is connected to the AV Audio input terminal.
- *3 Set "VIDEO IN" to "None" in Camera Assignment Settings. (**P.34**)

Put the unit in standby

- 1 Press the HOME/ button.
 - ➤ HOME screen appears.
- 2 Touch III.
- 3 Touch STANDBY.



Customize Short-cut source icons

You can arrange the positions of the source icons as you like.

The 4 items placed in bottom line will appear on the bottom bar in various screens, as the short-cut playback source icons.

- 1 Press the HOME/ button.
 - ➤ HOME screen appears.
- 2 Touch ...
- 3 Touch and hold the icon which you want to move in the customizing mode.
- 4 Drag the icon to the desired position.



Source control screen descriptions

There are some functions which can be performed from most screens.



Displays the source selection screen. (P.11)

2 🔯

Displays the SETUP Menu screen.

3 Short-cut source icons

The source changes to the one you have set with a short-cut. For the short-cut setting, refer to *Customize Short-cut source icons (P.12)*.

4 TEL Y.I CO

Connected Bluetooth device information.

5 Indicator items

Displays the current source condition and so on.

List screen

There are some common function keys in the list screens of most sources.

Display the list screen

1 Touch Q.

➤ The list screen appears.



1 Text scroll

Scrolls the displayed text.

Play etc.

Keys with various functions are displayed here.

- Play : Plays all tracks in the folder containing the current track.
- Q A-Z : Jumps to the letter you entered (alphabetical search).
- Top L Up: Moves to the upper hierarchy level.

3 ^/∨/⊼/⊻ Page scroll

You can change pages to display more items by touching .

• ► ✓ : Displays the top or bottom page.


4 Return

Returns to the previous screen.

USB/iPod

Connecting a USB device

Connect the USB device with the USB cable. (P.32)



- 2 Press the HOME/() button.
- **3** Touch **Ⅲ**.
- 4 Touch USB. (P.12)

■ Disconnect the USB device

- 1 Press the HOME/ U button.
- 2 Touch a source other than USB.
- 3 Detach the USB device.

Usable USB device

You can use a mass-storage-class USB device with this unit.

The word "USB device" appearing in this manual indicates a flash memory device.

Connect iPod/iPhone

Preparation

- With an iPhone compatible with Apple CarPlay, turn off Apple CarPlay by operating the iPhone at functional setup before connecting iPhone. For details of the setup method, contact the manufacturer of the terminal.
- Only one iPod/iPhone can be connected.

Wired connection

Preparation

- Connect an iPod/iPhone with the KCA-iP103 (optional accessory) while Apple CarPlay is not connected.
- 1 Connect the iPod/iPhone using the KCAiP103. (P.33)
- To disconnect the iPod/iPhone connected with the cable:
- 1 Detach the iPod/iPhone.

Bluetooth connection

Pair the iPhone through Bluetooth.

Preparation

- To connect an iPhone via Bluetooth, register it as a Bluetooth device and do the profile setting for the connection beforehand. See Switch the connected device (P.46) in the Instruction Manual and Register the Bluetooth device (P.18).
- Connect an iPhone via Bluetooth while Apple CarPlay and an iPod/iPhone are not connected via USB.

■ Connectable iPod/iPhone

The following models can be connected to this unit.

Made for

iPhone XS
 iPhone 8
 iPhone 6s
 iPhone 7 Plus
 iPhone XS
 iPhone 7
 iPhone XR
 iPhone SF
 iPhone SF
 iPhone 6s
 iPhone 6s
 iPhone 6s
 iPhone 6s
 iPhone 7
 iphone 5F
 iPhone 3D
 iphone 3

· iPhone X · iPh

iPhone XiPhone 6s

• iPhone 8 Plus Plus

USB/iPod Basic Operation

- 1 Press the HOME/ U button.
- **2** Touch **#**.
- 3 Touch USB or iPod. (P.12)

Control screen



1 CODEC

When a high-resolution source is played, its format information is displayed.

2 Operation keys

- Q : Searches track/file.
- Id I Searches the previous/next track/ file.

Touch and hold to fast forward or fast backward. (It will be cancelled automatically after about 50 seconds.)

- ►II : Plays or pauses.
- iii : Displays the Graphic Equalizer screen. (P.21)
- Repeats the current track/folder.
- Randomly plays all tracks in the current folder.

3 Content list

- Touch the left side of the screen to display the Content list. Touch again to close the list.
- Displays the playing list. When you touch a track/file name on the list, playback will start.

HD Radio™ Tuner

HD Radio Tuner Basic Operation

To listen to the HD Radio source, touch **HD Radio** icon on the source selection screen. (P.12)

NOTE

• HD Radio broadcasting is for North American sales area only.

Control screen



1 Operation keys

- Id ►► : Tunes in a station. The method of switching frequencies can be changed (see 3
 Seek mode/Band keys).
- CH▼ CH▲ : Selects a channel.
- Q: Display the Channel List screen.
- Display a list of registered bookmarks.
- iii : Displays the Graphic Equalizer screen. (P.21)

2 Function panel

Touch the right side of the screen to display the function panel. Touch again to close the panel.

- 10key Direct: Display the direct station/ channel search screen.
- AME: Presets stations automatically. (P.17)
- RCV: Change the HD Radio reception mode.
 Auto: Switch between digital and analog audio automatically.

Digital: Select this to tune to digital audio only.

Analog: Select this to tune to analog audio only.

• **PTY** (FM only): Searches for a program by program type.

- Stores the information about the song being received.
- **Emergency Alerts**: Turn on or off the alert message.
- Alert Message Log: Displays the alert message received.

3 Seek mode/Band keys

- Touch to switch seek mode in the following sequence: AUTO1, AUTO2, MANUAL.
 - AUTO1: Tunes in a station with good reception automatically.
- AUTO2: Tunes in the memorized stations one after another.
- MANUAL: Switches to the next frequency manually.
- · Switches bands (between FM and AM).

4 Information display

Displays the information on the current station: Frequency and Channel

Touching allows you to switch between Content A, Content B and Content C.

Content A: Station name, Song Title, Artist Name Content B: Station Message, Radio Text Content C: PTY Genre. Album Name

5 Preset list

- Touching (/) allows you to change the display size.
- Recalls the memorized station or channel.
- When touched for 2 seconds, stores the currently being received station or channel in the memory.

6 Indicator display

While receiving an HD Radio station, it lights with orange when the audio is digital and lights with gray when it is analog. While receiving an analog station, it is off.

Memory Operation

Auto memory

You can store stations with good reception in the memory automatically.

- 1 Touch desired band key.
- 2 Touch on the right side of the screen. Touch AME.
- 3 Touch Yes.
 - ➤ Auto memory starts.

■ Manual memory

You can store the currently being received station or channel in the memory.

- 1 Select the station or channel you wish to store in the memory.
- 2 Touch FM# (#:1-15) or AM# (#:1-5) in which you want to store the station or channel for 2 seconds until a beep sounds.

Preset select

1 Touch on the left side of the screen.
Select a station or channel from the list.

Bluetooth Control

Register the Bluetooth device

It is necessary to register the Bluetooth audio player or smartphone/cell-phone in this unit before using the Bluetooth function.

- 1 Press the HOME/ U button.
- 2 Touch .
- 3 Touch SETUP.> SETUP Menu screen appears.
- 4 Touch Connections & AV.
- 5 Touch Device List.
- **6** Select a device type.
 - **■** Bluetooth

To connect as Bluetooth audio source.

■ Apple CarPlay

To connect as Apple CarPlay source.

Android Auto

To connect as Android Auto source.

- **7** Touch **+**0.
 - ➤ Bluetooth pairing waiting dialog appears.





8 Search for the unit ("DMX****") from your smartphone/cell-phone.

Complete steps 8 to 10 within 30 seconds.

- 9 Operate your smartphone/cell-phone according to the displayed messages.
 - Confirm the request both on the smartphone/cell-phone.



 Input the PIN Code in your smartphone/cell-phone.

PIN Code is set to "0000" as the default.



10 Touch Yes.

When data transmission and connection have completed, the Bluetooth connection icon appears on the screen.

NOTE

 When registering the iPhone that is available for Apple CarPlay wirelessly, a confirmation message appears. Touch Yes to display the Apple CarPlay screen for wireless connection.

Using the Hands-Free Unit

You can use the telephone function by connecting the Bluetooth telephone to this unit.

NOTE

· While Apple CarPlay or Android Auto is connected, the Bluetooth Hands-Free function and two Bluetooth devices connections cannot be used. Only the Apple CarPlay or Android Auto Hands-Free function can be used.

Make a call

- 1 Press the HOME/ Ubutton.
- 2 Touch
- 3 Touch TEL.



➤ Hands-Free screen appears.

NOTE

- If your smartphone/cell-phone supports PBAP, you can display the phonebook and call lists onto the touch panel screen when the smartphone/ cell-phone is connected.
 - Phonebook: up to 1000 entries
 - Up to 50 entries including dialed calls, received calls, and missed calls

4 Select a dialing method.



- Call using call records
- 🕮 : Call using the phonebook

- ***** : Call using the preset number
- # : Call by entering a phone number

Select the smartphone/cell-phone to use

When you connect two smartphones/cellphones

1) Touch Device name1 Device name2 to select the phone you want to use.

Call using call records

- 1 Touch
- 2 Select the phone number from the list.

Call using the phonebook

- 1 Touch
- 2 Touch Q A-Z

3 Select the initial.

- Characters with no corresponding name will not appear.
- · A first character with an accent character such as "ii" can be searched for with a non-accent character "u". A character with an accent character in a sentence cannot be searched for.

4 Select the person you want to call from the list.



5 Select the phone number from the list.



NOTE

- You can sort the phone numbers in the list by last name or first name. For details, see *Hands-Free* Setup (P.55) in the Instruction Manual.
- When Russian or Hebrew is selected in "Language select", you can switch between English keyboard and the selected language keyboard. For details, see System Setup (P.65) in the Instruction Manual.
- You can search with 3 initial letters on the English keyboard and 1 initial letter on the Russian / Hebrew keyboard.

Call using the preset number

- 1 Touch
- 2 Touch the name or phone number.

Call by entering a phone number

- 2 Enter a phone number with number keys.
- 3 Touch

Receive a call

1 Touch to answer a phone call or to reject an incoming call.



NOTE

- When shifting the gear to the reverse (R) position and monitoring the picture from the rear view camera, this screen does not appear even if a call comes in.
- The portrait registered in the phonebook is displayed while making/receiving calls and during a call.
- If you edit the phonebook on the connected device side after downloading the phonebook, the portrait may not be displayed depending on the edited content. It is recommended that you download the phonebook whenever you edit it.
- The image quality of a displayed portrait may depend on a connected device.

To end call

1 While talking, touch .

Operations during a call



- Adjust the volume of your voice
- 1) Touch Speech Quality.
- 2) Touch ◀ or ▶ for Microphone Level.

Adjust the receiver volume

Turn the volume knob clockwise to increase, and counter-clockwise to decrease.

Mute your voice

Touch to mute or not to mute your voice.

Output the dial tone

Touch **DTMF** to display the tone input screen. You can send tones by touching desired keys on the screen.

Switching between speaking voice output destinations

Touching **Land** / **Land** each time switches speaking voice output destinations between the smartphone/cell-phone and the speaker.

Controlling Audio


You can adjust various settings such as audio balance or subwoofer level.

- 1 Press the HOME/ button.
- 2 Touch .
- 3 Touch Audio.



Controlling General Audio

- 1 Touch FAD / BAL / Zone.
- 2 Set each parameter as follows.



- **◄** and **►** adjust the left and right volume balance.
- ▲ and ▼ adjust the front and rear volume balance.

■ Center

Clear the adjustment.

Equalizer Control

You can adjust equalizer by selecting the optimized setting for each category.

- 1 Touch EQ / SW Level.
- 2 Touch the screen and set the Graphic Equalizer as desired.



■ Gain level (area in dotted frame)

Adjust the gain level by touching each frequency bar.

You can select a frequency bar and adjust its level by \blacktriangle , \blacktriangledown .

ALL SRC

Apply the adjusted equalizer curve to all sources. Touch **ALL SRC** and then touch **OK** on the confirmation screen.

■ Memory

Saves the adjusted equalizer curve as "User1" to "User4"

■ Initialize

Initialize (flatten) the current EQ curve.

■ Bass EXT (Bass Extend Settings)

When turned on, the frequencies lower than 62.5 Hz is set to the same gain level (62.5 Hz).

■ SW Level

Adjust the subwoofer volume.

Pops/Easy/Top40/Jazz/Powerful/ Rock/Flat/Bass Boost/User1/ User2/User3/User4

Recall the preset EQ curve.

Connection/Installation

This section is for the professional installer. For safety's sake, leave wiring and mounting to professionals. Consult the car audio dealer.

Before Installation

Before installation of this unit, please note the following precautions.

▲ WARNINGS

- If you connect the ignition wire (red) and the battery wire (yellow) to the car chassis (ground), you may cause a short circuit, that in turn may start a fire. Always connect those wires to the power source running through the fuse box.
- Do not cut out the fuse from the ignition wire (red) and the battery wire (yellow). The power supply must be connected to the wires via the fuse.

A CAUTION


 Install this unit in the console of your vehicle.
 Do not touch the metal part of this unit during and shortly after the use of the unit. Metal part such as the heat sink and enclosure become hor

- Mounting and wiring this product requires skills and experience. For best safety, leave the mounting and wiring work to professionals.
- Do not install the unit if it becomes an obstacle to driver performance.
- Adjust the panel position not to become an obstacle to driver performance.
- Make sure to ground the unit to a negative 12V DC power supply.
- Do not install the unit in a spot exposed to direct sunlight or excessive heat or humidity.
 Also avoid places with too much dust or the possibility of water splashing.
- Do not use your own screws. Use only the screws provided. If you use the wrong screws, you could damage the unit.
- If the power is not turned ON ("There is an error in the speaker wiring. Please check the


- connections." is displayed), the speaker wire may have a short-circuit or touched the chassis of the vehicle and the protection function may have been activated. Therefore, the speaker wire should be checked.
- If your car's ignition does not have an ACC position, connect the ignition wires to a power source that can be turned on and off with the ignition key. If you connect the ignition wire to a power source with a constant voltage supply, such as with battery wires, the battery may be drained.
- If the console has a lid, the lid will not be closed even when the unit is installed correctly.
- If the fuse blows, first make sure the wires are not touching to cause a short circuit, then replace the old fuse with one with the same rating.
- Insulate unconnected wires with vinyl tape or other similar material. To prevent a short circuit, do not remove the caps on the ends of the unconnected wires or the terminals.
- Connect the speaker wires correctly to the terminals to which they correspond. The unit may be damaged or fail to work if you share the

 wires or ground them to any metal part in the car.
- When only two speakers are being connected to the system, connect the connectors either to both the front output terminals or to both the rear output terminals (do not mix front and rear). For example, if you connect the ⊕ connector of the left speaker to a front output terminal, do not connect the ⊕ connector to a rear output terminal.
- After the unit is installed, check whether the brake lamps, blinkers, wipers, etc. on the car are working properly.
- Mount the unit so that the mounting angle is 30° or less.

 This unit has the cooling fan to decrease the internal temperature. Do not mount the unit in a place where the cooling fan of the unit is blocked. Blocking these openings will inhibit the cooling of the internal temperature and result in malfunction.




- Do not press hard on the panel surface when installing the unit to the vehicle. Otherwise scars, damage, or failure may result.
- Reception may drop if there are metal objects near the Bluetooth/Wi-Fi antenna



Bluetooth/Wi-Fi antenna unit


Forward and Lateral Fields of Vision

• To determine driver's forward and lateral fields of vision under normal conditions, place a pole (directly visible from the front or visible through the car rear-view mirror) as shown.




- o: Pole (height: 1m, diameter: 0.3m)
- : Field of vision from steering position
- : Exempted area (pole size is subject to regulation)
- For right hand drive vehicles, standards are reversed.
- *1 The pole must be visible from the driver's position as direct forward field of vision.
- *2 The pole must be directly visible or indirectly visible through the mirror, etc. from the driver's position.

Supplied accessories for installation



Connection/Installation



Installation procedure

- To prevent a short circuit, remove the key from the ignition and disconnect the ⊖ terminal of the battery.
- 2) Remove the vehicle parts for installing the unit and connecting wires to terminal.
- 3) Make the proper input and output wire connections for each unit.
- 4) Connect the speaker wires of the wiring harness.
- 5) Connect wiring harness wires in the following order; ground, battery, ignition.
- 6) Determine the height of the display unit and position of the slider. See *Distance between* the display unit and the main unit (P.25).
- 7) Connect the wiring harness connector to the unit.
- 8) Install the main unit to the vehicle.
- 9) Reinstall the vehicle parts.
- 10) Install the display unit.
- 11) Reconnect the \bigcirc terminal of the battery.
- 12) Perform the Initial Setup. See *Initial SETUP (P.8)*.

Installing the unit

Confirm the installing position of the display unit


Vehicles cannot be installed

It may be possible to install if it can avoid the following by adjustment for slider position and display height.



• Distance between the display unit and the main unit

Adjust slider position and display height so that it does not interfere with display movement.



Unit: mm

Examples

Cluster panel on the vehicle

Slider in back position




position

Slider in forward

• C'=50mm;

Slider position: Forward position
Display height: Set only "4"



2 C = 30mm


• C'=30mm;

Slider position: Back position Display height: Set only "4"


Slider position: Forward position Display height: Set "2"~"4"

Positioning the slider in forward


Remove the four screws from the bottom of the main unit.




2 Remove the two cover for back position, and then remove the two hexagon head screws from the bracket for back position.




3 Pull the slider block forward and remove the two hexagon head screws to remove the bracket for back position.



4 Install the bracket for forward position (accessory (10)) each side so that its projections are aligned with the slots on the main unit.




5 Fix the bracket for forward position to the slider block with the two hexagon head screws. Push the slider block until it stops and then fix the bracket for forward position to the main unit with the two hexagon head screws.



6 Reinstall the four screws to the bottom of the main unit.




7 Install the cover for forward position (accessory (9)) to two locations, as shown.




Adjusting the display height

1 Remove the four flat head screws from both sides.



2 Adjust the display height according to the screw hole position. Default is "1".



3 Reinstall the four flat head screws on both sides and fix the display.

NOTE


· Fix with flat head screws correctly. After installing the display unit (accessory ®) to the main unit, tilt the display forward until it stops and confirm that the display unit (accessory ®) does not hit vehicle parts. If the display unit hits vehicle parts, adjust the display height again.

GPS antenna

GPS antenna is installed inside of the car. It should be installed as horizontally as possible to allow easy reception of the GPS satellite signals.

To mount the GPS antenna inside your vehicle:


- 1) Clean your dashboard or other surface.
- 2) Remove the separator of the metal plate (accessory (7)).
- 3) Press the metal plate (accessory (7)) down firmly on your dashboard or other mounting surface. You can bend the metal plate (accessory 7) to conform to a curved surface, if necessary.
- 4) Remove the separator of the GPS antenna (accessory 6)), and stick the antenna to the metal plate (accessory 7).



- Use the supplied GPS antenna. Using the GPS antenna other than the supplied one may cause a drop in positioning accuracy.
- · Depending on the type of car, reception of the GPS satellite signals might not be possible with an inside installation
- · Please install this GPS antenna in an area away from any antennas that are used with CB radios or satellite televisions.
- The GPS antenna should be installed at a position that is spaced at least 12 inch (30 cm) from smartphone/cell-phone or other transmitting antennas. Signals from the GPS satellite may be interfered with by these types of communication.
- Painting the GPS antenna with (metallic) paint may cause a drop in performance.

■ Microphone unit


- 1) Check the installation position of the microphone (accessory ③).
- 2) Clean the installation surface.
- 3) Remove the separator of the microphone (accessory ③), and stick the microphone to the place shown below.
- 4) Wire the microphone cable up to the unit with it secured at several positions using tape or other desired method.
- 5) Adjust the direction of the microphone (accessory ③) to the driver.




Fix a cable with a commercial item of tape.

Installing the main unit


- Determine the slider position before installing the main unit. (P.26) The slider position cannot be changed after installing to the vehicle.
- Make sure that the unit is installed securely in place. If the unit is unstable, it may malfunction (eg, the sound may skip).
- 1 Remove parts that interfere with installing such as a panel on the vehicle.
- 2 Install the car bracket to the main unit.



- 3 Connect the wiring harness wires and peripheral equipment.
- 4 Install the main unit to the vehicle.
- 5 Reinstall the removed parts such as a panel on the vehicle.




6 Install the display unit (accessory ®) to the main unit.




NOTE

- If the display unit hits a panel on the vehicle, adjust the display height by referring to Adjusting the display height (P.27).
- **7** Fix the display unit with six hexagon head screws (accessory ①).




8 Attach the protective cover (accessory ②) to coupling part, and then fix it with two binding head screws (accessory ③).




- If the protective cover (accessory ②) is not attached, this unit will not turn on. Even if the unit is turned on, the power may be turned off halfway.
 - Be sure to attach the protective cover (accessory
- **9** Raise the display manually.

Connecting wires to terminals



3-way speaker system setup

DMX1057XR




Speaker impedance: 4-8 Ω

NOTE

- For speaker system setup, see 3-way speaker system setup (P.67) in the Instruction Manual.
- For speaker setup and crossover setup, see Speaker / X'over setup (P.68) in the Instruction Manual.
- For how to connect speaker wires to terminals other than speaker terminals and Preout terminals, see Connecting the system and external components (P.31) and Connecting wires to terminals (P.30).

Connecting the system and external components



SiriusXM Connect Vehicle Tuner connector For more information on how to install the SiriusXM Connect Vehicle tuner, consult the installation quide included with the tuner.

(Left: White, Right: Red)


(Left; White, Right; Red)

Subwoofer Preout

Connection/Installation

HDMI input
Use HDMI cable KCA-HD100 (optional accessory).

When you connect the cable to HDMI terminal, remove the fixture. After connecting the cable, put the fixture again.




- 7 iDatalink connector
- Dashboard camera interface
 Connect a Dashboard Camera DRV-N520
 (optional accessory). (P.34)
- AV Audio input (ø3.5 mini jack)
- Accessory (6): GPS Antenna
 Use the supplied GPS antenna. Using the GPS
 antenna other than the supplied one may
 cause a drop in positioning accuracy.




- 3rd view camera input (Yellow). See **To set up** the camera assignment settings (P.34).
- Rear view camera input (Yellow)*1
- Front view camera/Dashboard camera input (Yellow).*2
 - See **To set up the camera assignment settings (P.34)**.
- 14 Video output (Yellow)
- 15 Video input (Yellow)
- *1 Connect an HD camera to Rear view camera input terminal to use HD video.
- *2 Connect an HD camera to Front view camera/ Dashboard camera input terminal to use HD video.

Securing the USB extension cable

Secure the USB extension cable with insulating tape or the like so that its connectors are not disconnected




■ Connecting a USB device




- ^[1] USB maximum power supply current: DC 5 V == 1.5 A
- [2] Sold separately
- [3] See **Securing the USB extension cable** (**P.32**).

■ Connecting an iPod/iPhone




- ^[1] USB maximum power supply current: DC 5 V == 1.5 A
- [2] Sold separately
- [3] Optional accessory
- [4] See Securing the USB extension cable (P.32).

Connecting an Android smartphone



- ^[1] USB maximum power supply current : DC 5 V == 1.5 A
- [2] Sold separately
- [3] See Securing the USB extension cable (P.32).

Connecting the camera



- [1] Optional accessory
- [2] Sold separately
- ^[3] Up to 3 cameras of Dashboard camera, Front view camera, Left side view camera and Right side view camera can be connected. **(P.34)**.
- [4] CMOS-3xx series (optional accessory) or commercially available camera.
- [5] For HD video, an HD camera is also used as Rear view camera
- ^[6] For HD video, an HD camera is also used as Front view camera.

To set up the camera assignment settings

- 1 Press the HOME/ button.
- 2 Touch .
- 3 Touch SETUP.
 - > SETUP Menu screen appears.
- 4 Touch Camera.
 - ➤ Camera setting menu appears.
- 5 Touch Camera Assignment Settings.
- 6 Select the item to set up.

■ REAR VIEW CAMERA

Set the camera assignment from view camera connected to Rear view camera input terminal.

■ FRONT VIEW CAMERA / DASH CAM

Set the camera assignment from view camera connected to Front view camera/ Dashboard camera input terminal.


■ 3rd VIEW CAMERA

Set the camera assignment from view camera connected to 3rd view camera input terminal.

■ VIDEO IN

Set the camera assignment from view camera connected to Video input terminal.

7 Select the view camera to set up.



- Picture from view camera
- 2 Camera position
- 3 Picture quality settings
- 8 Touch Enter.

Appendix

Note for specifications

■ Bluetooth section

Frequency

: 2.402 – 2.480 GHz

RF Output Power (E.I.R.P.)

: +4 dBm (MAX), Power Class 2

■ General

Operating Voltage

: 12 V DC car battery

Speaker Impedance

:4 - 80

■ Copyrights

- The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by JVCKENWOOD Corporation is under license. Other trademarks and trade names are those of their respective owners.
- DSD, LDAC and LDAC logo are trademarks of Sony Corporation.
- Hi-Res Audio logo and Hi-Res Audio Wireless logo are used under license from Japan Audio Society.





- Windows Media is a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.
 - This product is protected by certain intellectual property rights of Microsoft. Use or distribution of such technology outside of this product is prohibited without a license from Microsoft.
- This software is based in part on the work of the independent JPEG Group.
- Use of the Made for Apple badge means that an accessory has been designed to connect specifically to the Apple product(s) identified in the badge, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with an Apple product may affect wireless performance.
- Apple, iPhone, iPod, iPod touch, and Lightning are trademarks of Apple Inc., registered in the U.S. and other countries.
- Apple, Siri, Apple CarPlay, Apple Music and Apple CarPlay logo are trademarks of Apple Inc., registered in the U.S. and other countries.
- App Store is a service mark of Apple Inc., registered in the U.S. and other countries.
- IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.
- Sirius, XM and all related marks and logos are trademarks of Sirius XM Radio Inc. All rights reserved.
- HD Radio Technology manufactured under license from iBiquity Digital Corporation. U.S. and Foreign Patents. For patents see https://dts.com/patents.
 HD Radio and the HD, HD Radio, and "ARC" logos are registered trademarks or trademarks of iBiquity Digital Corporation in the United States and/or other countries.
- INRIX is a registered trademark of INRIX, Inc.
- Google, Android, Google Play and Android Auto are trademarks of Google LLC.

To use Android Auto on your car display, you'll need an Android Auto compatible vehicle or aftermarket stereo, an Android phone running Android 5.0 or higher, and the Android Auto app.

Appendix

- · Wi-Fi® is a registered trademark of Wi-Fi Alliance®.
- The Wi-Fi CERTIFIED™ Logo is a certification mark of Wi-Fi Alliance®.
- Copyright@ 2018 Techpoint, Inc. All rights reserved.

HD-TVI

- The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.
- This product includes FontAvenue® fonts licenced by NEC Corporation.FontAvenue is a registered trademark of NEC Corporation.

♣ FontAvenue

 This product includes "Ubiquitous QuickBoot TM" technology developed by Ubiquitous Corp. Ubiquitous QuickBoot TM is a trademark of Ubiquitous Corp. Copyright© 2017 Ubiquitous Corp. All rights reserved.

Ubiquitous

- THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO (;) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (;;) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, LL.C. SEE HTTPS://WWW.MPEGLA.COM
- THIS PRODUCT IS LICENSED UNDER THE MPEG-4 VISUAL PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER FOR (;) ENCODING VIDEO IN COMPLIANCE WITH THE MPEG-4 VISUAL STANDARD ("MPEG-4 VIDEO") AND/OR (ii) DECODING MPEG-4 VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED BY MPEG LA TO PROVIDE MPEG-4 VIDEO, NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE, ADDITIONAL INFORMATION INCLUDING THAT RELATING TO PROMOTIONAL INTERNAL AND COMMERCIAL USES AND LICENSING MAY BE OBTAINED FROM MPEG LA. LLC. SEE HTTPS://WWW.MPEGLA.COM.
- THIS PRODUCT IS LICENSED UNDER THE VC-1 PATENT PORTFOLIO LICENSE FOR THE PERSONAL AND NON-COMMERCIAL USE OF A CONSUMER TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE VC-1 STANDARD ("VC-1 VIDEO") AND/OR (ii) DECODE VC-1 VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL AND NON-COMMERCIAL ACTIVITY

AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE VC-1 VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE https://www.mpegla.com/

libFLAC

Copyright (C) 2000-2009 Josh Coalson Copyright (C) 2011-2013 Xiph.Org Foundation Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the Xiph.org Foundation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission. THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO. THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE FOUNDATION OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY. WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE

libvorbis

Copyright (c) 2002-2008 Xiph.org Foundation Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the Xiph.org Foundation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.
 THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT

HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE FOUNDATION OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY. WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

· libogg

Copyright (c) 2002, Xiph.org Foundation Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of the Xiph.org Foundation nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission. THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE FOUNDATION OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY. WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

≰iPhone | iPod



android auto









Hi-Res Audio logo and Hi-Res Audio Wireless logo are used under license from Japan Audio Society.









HD2/HD3

Bookmark

Digital Sound

Program Info

Artist Experience

Emergency Alerts



MILITARY

Units purchased through the U.S.A. military exchange service overseas may be serviced under warranty in the continental U.S.A., subject to the following conditions.

- 1) The original warranty is in effect.
- 2) Proof of purchase is provided to the servicer.

WARRANTY FOR MILITARY MARKET

JVC KENWOOD corporation is proud of the quality and workmanship of its audio equipment. This unit has been properly designed, tested and inspected before it was shipped to you. If properly installed and operated in accordance with instructions furnished, it should give you an optimum reliable performance.

WARRANTY PERIOD

This product is warranted for a period of (1) year from the date of the original purchase.

SCOPE OF WARRANTY

Except as specified below, this warranty covers all defects in materials and workmanship of the Kenwood brand products.

During the warranty period, any authorized Kenwood Service Center in the military market listed in the back of this warranty card will provide you free-of-charge both parts and labor required to correct any defect in materials or workmanship.

The following are not covered by this warranty.

- 1. Voltage conversions.
- Periodic check-ups which do not disclose any defect covered by the warranty.
- Cabinets, grilles, other exterior finishes, belts, tape heads, and other non-durable parts and accessories.
- Units on which the serial number has been effaced, modified or removed.
- 5. Installation and/or removal charges.
- 6. Damaged magnetic tapes.
- 7. House call charges for any repairs.8. Shipping or delivery charges to or from an authorized
- Kenwood Service Center.

 9. This warranty will not cover any failure that is due to any of the following conditions in accordance with the visual inspection.
- following conditions in accordance with the visual inspection of the authorized Kenwood Service Center:

 * Improper maintenance or repair, including the installation of
- parts or accessories that do not conform to the quality and specifications of the original parts.

 * Misuse abuse peolect unauthorized product modification.
- * Misuse, abuse, neglect, unauthorized product modification or failure to follow instructions contained in the Owner's Manual.
- * Accidental or intentional damages.
- Repairs or attempted repairs by an unauthorized agency.
 (All repairs must be performed at an authorized Kenwood Service Center.)
- * Damages or deteriorations caused during shipment (Claims must be presented to the carrier).
- * Damages or deteriorations resulting from removal and/ or replacement.

PURCHASER'S RESPONSIBILITIES

As the purchased of a new Kenwood brand product, you are requested to do the following in order to obtain Kenwood warranty service.

- Retain your sales slip or other evidence of purchase for proving your eligibility for requesting Kenwood warranty service.
- Make your unit available to an authorized Kenwood Service Center in the military market for inspection and approved warranty service, or ship your unit in its original carton box or equivalent, fully insured and shipping charges prepaid, to the authorized Kenwood Service Center.

JVC KENWOOD Customer Information Center

LIMITATION OF IMPLIED WARRANTIES

Any and all implied warranties, including warranties of merchantability and fitness for a particular purpose, shall be limited in duration to the length of this warranty.

EXCLUSION OF CERTAIN DAMAGES

KENWOOD's liability for any defective product is limited to the repair or replacement of said product, at our potion, and shall not include damages of any kind, whether incidental, consequential or otherwise, expect to the extent prohibited by applicable law.

KENWOOD AUTHORIZED SERVICE CENTERS IN MILITARY MARKET

JAPAN:

Yokota

Kenwood Rep.; c/o Yokota BX, JAAX AAFES-PAC, APO San Francisco 96328

Zama

Kenwood Rep.; c/o Zama PX, JAAX AAFES-PAC, APO San Francisco 96343

Misawa

Kenwood Rep,; c/o Misawa BX, JAAX AAFES-PAC, APO San Francisco 96519

Yokosuka

Kenwood Rep,; c/o A-33, Yokosuka NEX No. 260-010 FPO Seattle 98760

Atsugi

Kenwood Rep.; c/o Atsugi NEX No. 260-020 FPO Seattle

lwakuni

Kenwood Rep.; c/o Marine Corps Exchange, Marine Corps Air Station, FPO Seattle 98764

Sasebo

Sasebo NEX; Navy Exchange 260-040 F.A. Box 115 FPO Seattle 98766

Okinawa

Kenwood Rep.; c/o OWAX, AAFES-PAC, APO San Francisco 96230

valid in the countries listed. If your country is not listed please contact your retailer for information on warranty

KOREA:

Kenwood Rep.; c/o KOAX Repair Shop, AAFES-PAC DD-Camp Market, APO San Francisco 96488

GUAM:

Kenwood Rep,; c/o Guam NEX No. 230-010, FPO San Francisco 96630 Kenwood Rep,; c/o GUAX, AAFES-PAC, APO San Francisco 96334

U.S.A.:

In The Continental U.S.A.

For Nearest Authorized Service Center; Tel: 1-800-536-9663 www.us.jvckenwood.com

EUROPE:

Please inquire at the military resale outlets where you bought your Kenwood products, or JVCKENWOOD DEUTSCHLAND GMBH: Konrad-Adenauer Allee 1-11, 61118 Bad Vilbel, Germany


Dear Customer, Thank you for purchasing this kenwood product. As mentioned in the pages of this booklet, our warranty is only


procedure, or write to:

3-12, Moriyacho, Kanagawa-ku, Yokohama-shi, Kanagawa 221-0022, Japan



Warranty Card





Nom & adresse du client Nome e endereço do cliente Name & address of customer

Purchase date

Attention

This card and receipt (or invoice) are necessary to purchase a new panel in case of theft or damage.

ttention:

Vous aurez besoin de cette carte et du reçu (ou de la facture) pour acheter un nouveau panneau en cas de vol ou d'endommagement.

Atenção:

Em caso de dano ou perda do painel frontal, este Certificado de Garantia e a Nota Fiscal de compra serão requisitados para a aquisição de um novo painel.

© B46-0824-00/04 (K) (15/11)

U.S.A.

This warranty will be honored only in the U.S.A.

KENWOOD LIMITED WARRANTY FOR CAR STEREO COMPONENTS

HOW LONG IS THE WARRANTY

JVCKENWOOD USA Corporation ("Kenwood") warrants this product for a period of one (1) year from the date of original purchase.

WHAT IS COVERED AND WHAT IS NOT COVERED

Except as specified below, this warranty covers all defects in material and workmanship in Kenwood car stereo components. The following are not covered by the warranty:

- I. Any product which is not distributed in the U.S.A. by Kenwood or which is not purchased in the U.S.A. from an authorized Kenwood car stereo dealer or an automobile dealer, unless the product is purchased through the U.S.A. Military Exchange Service.
- 2. Any product on which the serial number has been defaced, modified or removed.
- 3. Damage, deterioration or malfunction resulting from:
- a. Any shipment of the product (claims must be presented to the carrier).
- b. Installation or removal of the product.

BRASIL

- c. Accident, acts of nature, misuse, abuse, neglect, unauthorized product modification or failure to follow instructions supplied with the product.
- d. Repair or attempted repair by anyone not authorized by Kenwood.
- e. Any other cause which does not relate to a product defect

JVCKENWOOD USA Corporation

WHO IS PROTECTED This warranty is enforceable only by the original purchaser.

WHAT WE WILL PAY FOR

We will pay for all labor and material expenses for covered items. Payment of shipping charges is discussed in the next section of this warranty

HOW TO OBTAIN WARRANTY SERVICE

If your KENWOOD product ever needs service:

- 1. Take or ship it to any KENWOOD Authorized Service Center in the U.S.A. along with & complete description of the problem. (if you are uncertain as to whether a Service Center is authorized, please call 1-800-KENWOOD for the nearest Service Center 1-800-536-9663)
- 2. Although you must pay any shipping charges if it is necessary to ship the product for warranty service, we will pay the return shipping charges if the repairs are covered by the warranty within the United States.
- 3. Whenever your units are taken or sent for warranty service. you must include a copy of the original dated sales receipt as proof of warranty coverage.

LIMITATION OF IMPLIED WARRANTIES

ALL IMPLIED WARRANTIES. INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE LENGTH OF THIS WARRANTY

EXCLUSION OF DAMAGES

KENWOOD'S LIABILITY FOR ANY DEFECTIVE PRODUCT IS LIMITED TO THE REPAIR OR REPLACEMENT OF THE PRODUCT AT OUR OPTION, KENWOOD SHALL NOT BE LIABLE FOR-

- 1. INSTALLATION OR REMOVAL CHARGES, DAMAGE TO OTHER PROPERTY CAUSED BY ANY DEFECTS IN KENWOOD CAR STEREO COMPONENTS, DAMAGES BASED UPON INCONVENIENCE, LOSS OF USE OF THE PRODUCT: OR
- 2. ANY OTHER DAMAGES. WHETHER INCIDENTAL. CONSEQUENTIAL OR OTHERWISE.

SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS AND/OR DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY TO YOU

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

If a problem develops during or after the Limited Warranty Period, or if you have any questions regarding the operation of the product, you should contact your KENWOOD Authorized Dealer or Authorized Service Center. If the problem or your question is not handled to your satisfaction, please contact our Customer Relations Department at the address listed below:

JVCKENWOOD USA Corporation PO Box 22745, 2201 E. Dominguez St. Long Beach, CA 90810-5745 Tel: (800) 536-9663 www.us.jvckenwood.com

CANADA

KENWOOD WARRANTY

JVCKENWOOD Canada Inc. (hereinafter called "KENWOOD"), gives the following written warranty to the original customer of each new Kenwood product distributed in Canada by KENWOOD and purchased from a dealer authorized by KENWOOD.

KENWOOD warrants that each new Kenwood product under normal use, is free from any defects, subject to the terms and conditions set forth below. If a defect should occur within the warranty period, repairs will be made free of charge for parts and Jahour when such defects are determined by KENWOOD or its' authorized service centres to be attributable to faulty materials or workmanship at time of manufacture. Please contact KENWOOD to confirm if a dealer or service centre is authorized by KENWOOD.

WARRANTY PERIOD

This Kenwood product is warranted for parts and labour for a period of one (1) year from the date of original purchase, lease or rental, except for products which are used in a professional or commercial application, which are warranted for a period of ninety (90) days for parts and labour and are subject to the terms and conditions of the warranty.

WARRANTY EXCLUSIONS

This warranty excludes:

- (a) Products purchased in a foreign country or purchased in Canada and taken to a foreign country.
- (b) Products purchased from a dealer not authorized by KENWOOD
- (c) Products with the serial number defaced, altered or missing
- (d) Periodic check-ups which do not disclose any defects covered by this warranty.

JVCKENWOOD Canada Inc.

- (e) Defects resulting from disaster, accident, abuse, misuse, lightning, power surges, neglect or lack of periodic maintenance unauthorized modification or failure to follow instructions in the owner's manual.
- (f) Defects or damage as a result of repairs performed by a person or party not authorized by KENWOOD.
- (g) Defects resulting from the use of parts or devices that do not conform to KENWOOD specifications.
- (h) Damage or deterioration occurring to any exterior finishes, cosmetic parts, tape heads, adaptors, antennas, cables, tapes, discs or faults or damage caused by defective or leaking batteries.
- (i) Defects or damage occurring during shipping (claims should be presented to the shipping company).
- (j) Product voltage and /or line frequency conversions.
- (k) Product installation or removal charges.

TO OBTAIN WARRANTY SERVICE

Should your Kenwood product require warranty service, deliver it to any authorized KENWOOD service centre and present the original copy of your bill of sale and this warranty card as proof of warranty, or send your product fully insured and freight prepaid to the nearest authorized KENWOOD service centre. To avoid possible shipping damage, make sure the product is properly packed. Include a copy of your original bill of sale and this warranty card as proof of warranty along with your name, home and /or work telephone number(s), a complete return address and a detailed description of the fault(s). Products renaired within warranty will be returned freight prepaid to destinations within Canada. The customer is responsible for all freight and related costs for the return of product(s) to destinations outside Canada

ENTIRE WARRANTY

This warranty constitutes the entire written warranty given by KENWOOD. No person, party, dealer or service centre or their agents or employees are authorized to extend or enlarge this warranty on behalf of KENWOOD by any written or verbal statement or advertisement or promotion, including any extended warranty program or plan that may be offered by the dealer or service centre, unless approved in writing by KENWOOD

DISCLAIMER

KENWOOD disclaims any responsibility for loss of time or use of the product or any other indirect, incidental or consequential damage to other products or goods, inconvenience or commercial loss.

NOTICE TO CONSUMER

The provisions contained in this written warranty are not intended to limit, modify, take away, disclaim or exclude any warranties or rights you may have which are set forth in any applicable provincial or federal laws or legislation.

IMPORTANT

This warranty card by itself is not considered by KENWOOD as a valid proof of purchase. When applying for warranty repairs. you must present the original copy of your bill of sale and this warranty card as proof of warranty, so we recommend that they be kept in a safe place, should they be required in the future.

JVCKENWOOD Canada Inc. 6070 Kestrel Road, Mississauga, Ontario, Canada L5T 1S8

Tel.: (905) 670-7211 Fax: (905) 670-7248

JVC KENWOOD DO BRASIL COMÉRCIO DE ELETRÔNICOS LTDA

O fabricante garante o produto identificado na Nota Fiscal de venda ao consumidor contra qualquer defeito de fabricação ou de matéria-prima durante o período de garantia. Esta garantia é válida no território brasileiro desde que o produto tenha sido adquirido no Brasil e distribuído pela JVC KENWOOD do Brasil Comércio de Eletrônicos Ltda.

PERÍODO DE GARANTIA

Este produto é garantido pelo prazo de 01 (um) ano, incluindo o período estabelecido por lei, a partir da data de aquisição, comprovada mediante a apresentação da respectiva Nota Fiscal de venda ao consumidor final

Eventuais reparos realizados no produto durante o período de garantia não implicam na dilatação do seu prazo.

EXCLUSÃO DA GARANTIA

- (a) Produtos com o número de série ou certificado de garantia rasurados, adulterados ou ilegíveis: (b) Defeitos resultantes de acidentes (quedas, batidas e etc), uso em desacordo com o manual de instruções, má utilização, ligação à fonte de tensão diferente da especificada no Manual
- de Instruções, modificações não autorizadas; (c) Danos causados por agentes da natureza (Ex: chuvas, raios, maresia, enchentes e etc);
- (d) Defeitos ou danos em decorrência de consertos realizados por pessoas não autorizadas;
- (e) Defeitos ou danos resultantes do uso de peças ou dispositivos não conformes às especificações da JVC KENWOOD
- (f) Danos ou deteriorações aos acabamentos externos, partes cosméticas, cabos, chicotes, parafusos de fixação, luvas, alças, bolsas, estojos, adaptadores, antenas, fitas, cabecas gravadoras, CDs ou danos causados por pilhas defeituosas ou com vazamento;
- (g) Defeitos ou danos devido ao transporte (reclamações devem ser feitas junto à empresa transportadora);
- (h) Qualquer outra causa que não esteja relacionada a defeitos de matéria-prima e de fabricação;
- (i) Danos causados por tentativa de roubo ou furto:
- (i) Danos causados por uso de CDs de má qualidade:
- (k) Danos decorrentes do desgaste natural do produto:
- (I) Danos causados por mau uso. (derramamento de líquidos e/ou alimentos, corrosão, oxidação, exposição à umidade ou situações climáticas extremas, riscos ou quedas).

CONSERTO EM GARANTIA

É indispensável a apresentação deste Certificado de Garantia devidamente preenchido, acompanhado da respectiva Nota Fiscal de compra do produto, desde que não apresente rasuras ou modificações.

O consumidor somente terá direito a estes benefícios, quando o produto for entreque diretamente no balcão de um Serviço Autorizado da JVC KENWOOD.

O QUE NÃO É COBERTO PELA GARANTIA

Instalação e remoção do produto, despesas de frete, seguro e embalagem são de responsabilidade do proprietário

Este produto é destinado exclusivamente ao uso doméstico.

IMPORTANTE:

Para qualquer informação sobre seu equipamento JVC KENWOOD, ou para obter o endereço do Serviço Autorizado mais próximo, acesse o site www.kenwood.com.br , ou ligue para a Central de Atendimento JVC KENWOOD - Tel.: +55 (11) 3777-6771 com os dados abaixo preenchidos.

JVC KENWOOD DO BRASIL COMÉRCIO DE ELETRÔNICOS LTDA Tel: (11) 3777-6771 www.kenwood.com.br

| Nome do consumidor: | A STATE OF THE PARTY OF THE PAR |
|---------------------|--|
| Endereço: | CEP: |
| Cidade: | Estado: |
| Telefone: | |
| Data da compra: / | / Nota Fiscal: |

GARANTIE KENWOOD

JVCKENWOOD Canada Inc. (ci-après appelée "KENWOOD"), donne par écrit la garantie suivante à l'acheteur original de chaque nouveau produit Kenwood distribué au Canada par KENWOOD et acheté à un concessionnaire autorisé par KENWOOD.

KENWOOD garantit, sous réserve des termes et des conditions énoncés ci-dessous, que chaque nouveau produit Kenwood. dans des conditions d'emploi normales, est exempt de tous défauts. Si l'un défaut se produit pendant la période de garantie, KENWOOD s'engage à assumer le coût des pièces défectueuses et de la main-d'oeuvre nécessaires pour effectuer les réparations pourvu que de tels défauts sont attribuables à des pièces défectueuses employées lors de la fabrication du produit Kenwood ou à la main-d'oeuvre tel qu'établi par KENWOOD ou par l'un de ses centres de service autorisés. Appelez KENWOOD pour vérifier si un concessionnaire ou un centre de service est autorisé par KENWOOD.

PÉRIODE DE GARANTIE

Les pièces et la main-d'oeuvre nécessaires pour la réparation des produits Kenwood sont garanties pendant la période d'un (1) an à compter de la date d'achat, de bail ou de location originale. sauf dans les cas où les produits Kenwood sont employés dans un but professionnel ou commercial, où la garantie des pièces et de la main-d'oeuvre demeure en vigueur pendant une période de quatre-vingt-dix (90) jours sous réserve des termes et des conditions de la garantie.

EXCLUSIONS DE GARANTIE

Cette garantie ne couvre pas:

- (a) les produits achetés à l'étranger ou achetés au Canada et transportés à l'étranger;
- (b) les produits achetés à un concessionnaire non autorisé par KENWOOD: (c) les produits dont le numéro de série manque, a été effacé
- ou modifié: (d) les services d'entretien périodiques qui n'indiquent aucun défaut couvert par cette garantie;

- (e) les défauts causés par les désastres, les accidents, les abus, les emplois incorrects, les éclairs, les surtensions de courant, les manques de soins ou d'entretiens périodiques. les modifications non autorisées ou les manques de respect du mode d'emploi:
- (f) les défauts ou les dommages causés lors de réparations effectuées par une personne ou par une partie non autorisée nar KENWOOD
- (a) les défauts causés par l'emploi de pièces ou de dispositifs qui ne se conforment pas aux exigences de KENWOOD:
- (h) les finitions extérieures, les pièces cosmétiques, les têtes de bandes, les adaptateurs, les antennes, les câbles, les bandes, les disques endommanés ou dépéris, ni les défauts ou dommages causés par des piles défectueuses
- (i) les défauts ou dommages qui se produisent pendant l'expédition des produits Kenwood (On devrait déposer de telles réclamations auprès des compagnies de transport); (j) les conversions de tension et/ou de fréquence du
- produit: (k) les frais d'installation ou d'enlèvement du produit.

COMMENT OBTENIR DU SERVICE SOUS GARANTIE

Au cas où un service sous garantie de votre produit Kenwood s'avère nécessaire, veuillez livrer le produit à n'importe quel centre de service KENWOOD et présenter la copie originale du contrat de vente et cette carte de garantie en tant que preuve de garantie ou veuillez faire parvenir votre produit assuré et port payé au centre de service KENWOOD autorisé le plus proche. Pour éviter toutes possibilités de dommages pendant le transport, veuillez bien emballer le produit. Veuillez inclure une copie du contrat de vente original et cette carte de garantie en tant que preuve de garantie aussi bien que votre nom numéros de téléphone au poste de travail et/ou au domicile. votre adresse et une description détaillée des défauts. Les produits sous garantie réparés seront retoumés port payé aux destinations à l'intérieur du Canada. Le consommateur sera responsable de tous frais de transport et d'autres frais qui s'y rapportent pour faire expédier les produits à destinations à l'extérieur du Canada.

L'ENTIÈRE GARANTIE

Cette garantie représente l'entière garantie donnée par écrit par KENWOOD, KENWOOD ne se tient aucunement responsable de toutes extensions ni de toutes augmentations de cette garantie faites ou entreprises par toutes personnes, parties, concessionnaires ou centres de service ou par leurs agents ou employés au nom de KENWOOD au moyen d'affirmations verbales quécrites, d'annonces ou de promotions, vinclus tous programmes ou plans de garantie étendue que puissent offrir les concessionnaires ou les centres de service, à moins que KENWOOD n'v ait consenti par écrit d'avance.

RENONCIATION

KENWOOD renonce à toutes responsabilités de perte de temps, d'emploi du produit, de tous dommages indirects ou accessoires causés à d'autres produits ou biens, de tous inconvénients ou de toutes pertes commerciales.

AVIS AUX CONSOMMATEURS

Les stipulations contenues dans la présente garantie écrite n'ont pas pour but de limiter, de modifier, de diminuer, de rejeter ni d'exclure d'autres garanties ni droits énoncés dans n'importe quelles lois ou législations provinciales ou fédérales.

IMPORTANT

KENWOOD ne considère pas cette garantie toute seule comme étant une preuve d'achat valide. Lorsqu'on demande du service sous garantie, il faudra présenter la copie originale du contrat de vente aussi bien que cette carte de garantie en tant que preuve de garantie. On recommande de les conserver dans un lieu sû au cas où elles s'avèreraient nécesaires à l'avenir

JVCKENWOOD Canada Inc. 6070 Kestrel Road, Mississauga, Ontario, Canada L5T 1S8 Téléphone: (905) 670-7211 Télécopieur: (905) 670-7248