

Assembly Instructions

Model:	Jeep JL (Wrangler)
Description:	MB Quart Jeep JL Wrangler 12" Subwoofer Enclosure
Part Number:	MBQJL-302 MBQJL-302E - Unloaded Enclosure
Assembly Time:	90 Minutes (1.5-Hours)


Before you begin, read through these instructions and check that all parts are present. Please note that MB Quart cannot assume any responsibility for damage resulting from incorrect installation.

Parts List		
No.	Component Name	Qty
1	Subwoofer Enclosure	1
2	ST4.2 x 19mm Screw	14
3	M6 x 60mm Flathead Screw	2
4	M6 x 60mm Bolt	2
5	7mm Rubber Plug	4
6	9mm Rubber Plug	2
7	L Bracket	2
8	M6 x 16mm Torx Screw	2
9	13 x 30mm Spacer	2
10	13 x 45mm Spacer	2
11	M6 Washer	2
12	8" Zip Tie	6
13	Grill	1
14	White Gasket	1
15	Wire Harness	1


Tools Required	
1	Bojo or Panel Tool
2	T20 Torx Driver
3	T40 Torx Driver (Trailrail Equiped Only)
4	9/16" Drill Bit
5	Drill
6	4mm Allen Wrench
7	10mm Socket

Disassembly Instructions

- Remove four T20 Torx screws holding the subwoofer in the enclosure. Then disconnect the wiring from the subwoofer.



- Install four 7mm rubber plugs into the inside of the enclosure.



- Install the white gasket material into the channel of the grill.



Disassembly Instructions


- Disconnect negative battery terminal of the vehicle.
- If Trailrail equipped - remove three T40 screws and remove rail.
- If Trailrail ready - use panel tool to unclip cover and remove.



- Using a panel tool carefully unclip the tailgate panel and remove.



- With the tailgate panel laying face down, drill two 9/16" holes at the dimples at the bottom of the panel.



Disassembly Instructions

- Install the tailgate panel back into the vehicle by snapping into location.



- Install two L brackets, 45mm spacers, and M6 x 60mm flathead screws in the bottom two holes of the tailgate panel with a 4mm Allen wrench.



- Loosely install two M6 x 16mm Torx screws with a T40 Torx driver.

NOTE - You will tighten in another step.



Disassembly Instructions

- Loosely install two M6 x 16mm Torx screws with a T40 Torx driver.

NOTE - You will tighten in another step.



- Tighten down the two M6 Torx screws on the bottom of the enclosure with a T40 Torx driver.



Installation Instructions

- Connect the red wire to the + terminal and the black wire to the - terminal of the subwoofer.
- Install the subwoofer with eight ST4.2 x 19mm screws using a T20 Torx.



- Install the subwoofer grill to the enclosure with six ST4.2 x 19mm screws using a T20 Torx.



- Secure subwoofer enclosure wiring along vehicle tailgate wiring using zip ties. Then connect the extension harness and continue to amplifier location and make proper connections.
- Reconnect the negative battery terminal of the vehicle.





WARRANTY

Maxxsonics, LLC. warrants this product, to the original consumer purchaser, to be free from defects in material and workmanship for a period of one (1) year from the date of purchase. Maxxsonics, LLC. will, at its discretion, repair or replace defective products during the warranty period. Components that prove to be defective in materials and workmanship under proper installation and use must be returned to the original authorized Maxxsonics, LLC. retailer from where it was purchased. A photocopy of the original receipt must accompany the product being returned. The costs associated with removal, re-installation, and freight are not the responsibility of Maxxsonics, LLC. This warranty is limited to defective parts and specifically excludes any incidental or consequential damages connected therewith. To view the full warranty, please visit the website.

MB Quart products are designed and engineered in the USA by

MAXXSONICS®

www.maxxsonics.com

MBQJL-302 - MBQJL-302E REV 01