

## VEHICLE APPLICATIONS

<b>CHRYSLER</b>	1993-97 INTREPID	1976-80 VOLARE
1995-00 CIRRUS	1984-89 LANCER	1984-00 VOYAGER
1993-97 CONCORDE	1978-79 MAGNUM XE	<b>EAGLE</b>
1975-83 CORDOBA	1980-83 MIRADA	1993-97 VISION
1984-90 E CLASS	1974-78 MONACO	<b>JEEP</b>
1979-93 FIFTH AVENUE	1995-99 NEON	1997-01 CHEROKEE
1994-97 LHS	1978-90 OMNI	1996-98 GRAND CHEROKEE
1979-94 IMPERIAL	1974-01 RAM P/U	1997-02 WRANGLER
1984-86 LASER	1974-93 RAMCHARGER	
1977-81 LE BARON	1982-87 RAMPAGE	
1987-95 LE BARON SEDAN	1987-94 SHADOW	
1985-89 LE BARON GTS	1989-95 SPIRIT	
1982-95 LE BARON COUPE, CONV.	1979-81 ST. REGIS	
	1995-00 STRATUS	
1975-83 NEWPORT	1978-00 VAN	
1975-97 NEW YORKER	1993-00 VIPER	
1995-00 SEBRING	<b>PLYMOUTH</b>	
1996-00 SEBRING CONV.	1989 95 ACCLAIM	
1990-00 TOWN & COUNTRY	1996-00 BREEZE	
<b>DODGE</b>	1985-88 CARAVELLE SE	
1981-82 024	1975-78 FURY	
1982-83 400	1975-89 GRAND FURY	
1983-87 600	1978-90 HORIZON	
1981-89 ARIES	1995-99 NEON	
1976-80 ASPEN	1992-00 PROWLER	
1980-00 CARAVAN	1981-89 RELIANT	
1975-91 CHARGER	1983-84 SCAMP	
1987-00 DAKOTA P/U	1987-94 SUNDANCE	
1984-94 DAYTONA	1982 TC3	
1977-89 DIPLOMAT	1983-87 TOURISMO, DUSTER	
1998-00 DURANGO	1974-81 TRAILDUSTER	
1988-93 DYNASTY	1981-92 VAN	

**CRB630 Mounting Kit**

## VEHICLE APPLICATIONS

<b>CHRYSLER</b>	1993-97 INTREPID	1976-80 VOLARE
1995-00 CIRRUS	1984-89 LANCER	1984-00 VOYAGER
1993-97 CONCORDE	1978-79 MAGNUM XE	<b>EAGLE</b>
1975-83 CORDOBA	1980-83 MIRADA	1993-97 VISION
1984-90 E CLASS	1974-78 MONACO	<b>JEEP</b>
1979-93 FIFTH AVENUE	1995-99 NEON	1997-01 CHEROKEE
1994-97 LHS	1978-90 OMNI	1996-98 GRAND CHEROKEE
1979-94 IMPERIAL	1974-01 RAM P/U	1997-02 WRANGLER
1984-86 LASER	1974-93 RAMCHARGER	
1977-81 LE BARON	1982-87 RAMPAGE	
1987-95 LE BARON SEDAN	1987-94 SHADOW	
1985-89 LE BARON GTS	1989-95 SPIRIT	
1982-95 LE BARON COUPE, CONV.	1979-81 ST. REGIS	
	1995-00 STRATUS	
1975-83 NEWPORT	1978-00 VAN	
1975-97 NEW YORKER	1993-00 VIPER	
1995-00 SEBRING	<b>PLYMOUTH</b>	
1996-00 SEBRING CONV.	1989 95 ACCLAIM	
1990-00 TOWN & COUNTRY	1996-00 BREEZE	
<b>DODGE</b>	1985-88 CARAVELLE SE	
1981-82 024	1975-78 FURY	
1982-83 400	1975-89 GRAND FURY	
1983-87 600	1978-90 HORIZON	
1981-89 ARIES	1995-99 NEON	
1976-80 ASPEN	1992-00 PROWLER	
1980-00 CARAVAN	1981-89 RELIANT	
1975-91 CHARGER	1983-84 SCAMP	
1987-00 DAKOTA P/U	1987-94 SUNDANCE	
1984-94 DAYTONA	1982 TC3	
1977-89 DIPLOMAT	1983-87 TOURISMO, DUSTER	
1998-00 DURANGO	1974-81 TRAILDUSTER	
1988-93 DYNASTY	1981-92 VAN	

**CRB630 Mounting Kit**

## VEHICLE APPLICATIONS

<b>CHRYSLER</b>	1993-97 INTREPID	1976-80 VOLARE
1995-00 CIRRUS	1984-89 LANCER	1984-00 VOYAGER
1993-97 CONCORDE	1978-79 MAGNUM XE	<b>EAGLE</b>
1975-83 CORDOBA	1980-83 MIRADA	1993-97 VISION
1984-90 E CLASS	1974-78 MONACO	<b>JEEP</b>
1979-93 FIFTH AVENUE	1995-99 NEON	1997-01 CHEROKEE
1994-97 LHS	1978-90 OMNI	1996-98 GRAND CHEROKEE
1979-94 IMPERIAL	1974-01 RAM P/U	1997-02 WRANGLER
1984-86 LASER	1974-93 RAMCHARGER	
1977-81 LE BARON	1982-87 RAMPAGE	
1987-95 LE BARON SEDAN	1987-94 SHADOW	
1985-89 LE BARON GTS	1989-95 SPIRIT	
1982-95 LE BARON COUPE, CONV.	1979-81 ST. REGIS	
	1995-00 STRATUS	
1975-83 NEWPORT	1978-00 VAN	
1975-97 NEW YORKER	1993-00 VIPER	
1995-00 SEBRING	<b>PLYMOUTH</b>	
1996-00 SEBRING CONV.	1989 95 ACCLAIM	
1990-00 TOWN & COUNTRY	1996-00 BREEZE	
<b>DODGE</b>	1985-88 CARAVELLE SE	
1981-82 024	1975-78 FURY	
1982-83 400	1975-89 GRAND FURY	
1983-87 600	1978-90 HORIZON	
1981-89 ARIES	1995-99 NEON	
1976-80 ASPEN	1992-00 PROWLER	
1980-00 CARAVAN	1981-89 RELIANT	
1975-91 CHARGER	1983-84 SCAMP	
1987-00 DAKOTA P/U	1987-94 SUNDANCE	
1984-94 DAYTONA	1982 TC3	
1977-89 DIPLOMAT	1983-87 TOURISMO, DUSTER	
1998-00 DURANGO	1974-81 TRAILDUSTER	
1988-93 DYNASTY	1981-92 VAN	

**CRB630 Mounting Kit**

## VEHICLE APPLICATIONS

<b>CHRYSLER</b>	1993-97 INTREPID	1976-80 VOLARE
1995-00 CIRRUS	1984-89 LANCER	1984-00 VOYAGER
1993-97 CONCORDE	1978-79 MAGNUM XE	<b>EAGLE</b>
1975-83 CORDOBA	1980-83 MIRADA	1993-97 VISION
1984-90 E CLASS	1974-78 MONACO	<b>JEEP</b>
1979-93 FIFTH AVENUE	1995-99 NEON	1997-01 CHEROKEE
1994-97 LHS	1978-90 OMNI	1996-98 GRAND CHEROKEE
1979-94 IMPERIAL	1974-01 RAM P/U	1997-02 WRANGLER
1984-86 LASER	1974-93 RAMCHARGER	
1977-81 LE BARON	1982-87 RAMPAGE	
1987-95 LE BARON SEDAN	1987-94 SHADOW	
1985-89 LE BARON GTS	1989-95 SPIRIT	
1982-95 LE BARON COUPE, CONV.	1979-81 ST. REGIS	
	1995-00 STRATUS	
1975-83 NEWPORT	1978-00 VAN	
1975-97 NEW YORKER	1993-00 VIPER	
1995-00 SEBRING	<b>PLYMOUTH</b>	
1996-00 SEBRING CONV.	1989 95 ACCLAIM	
1990-00 TOWN & COUNTRY	1996-00 BREEZE	
<b>DODGE</b>	1985-88 CARAVELLE SE	
1981-82 024	1975-78 FURY	
1982-83 400	1975-89 GRAND FURY	
1983-87 600	1978-90 HORIZON	
1981-89 ARIES	1995-99 NEON	
1976-80 ASPEN	1992-00 PROWLER	
1980-00 CARAVAN	1981-89 RELIANT	
1975-91 CHARGER	1983-84 SCAMP	
1987-00 DAKOTA P/U	1987-94 SUNDANCE	
1984-94 DAYTONA	1982 TC3	
1977-89 DIPLOMAT	1983-87 TOURISMO, DUSTER	
1998-00 DURANGO	1974-81 TRAILDUSTER	
1988-93 DYNASTY	1981-92 VAN	

**CRB630 Mounting Kit**