

DASH DISASSEMBLY

1. Remove Ashtray and shift lever trim.
2. Remove (2) T-20 Torx Head Screws.
3. Remove the climate control/ hazard button assembly.
4. Loosen/Remove (2) T-20 Torx Head Screws from the bottom of the OEM Radio.
5. Remove OEM radio and unplug harness(s).

DIN MOUNT INSTALLATION INSTRUCTIONS**Requires new radio's metal sleeve**

1. Insert pocket in lower kit location.
2. Insert DIN metal-sleeve from your new radio into the top radio opening of the installation kit.
3. Depress the tabs from inside the sleeves opening upward, outward, and downward to secure sleeve to the installation kit.
4. Slide new radio through DIN metal-Sleeve until it locks in place.



For information about other American International automotive accessories visit our website at:

<http://www.americaninternational.net>

**American International****Automotive Products Division**

1040 Avenida Acaso • Camarillo, CA 93012, U.S.A.
USA Sales (800) 336-6500
Canada Sales (888) 922-3006 • USA Fax (805) 388-7950

CUSTOMER HELP LINE

8am-4:30 P.S.T. Monday-Friday Except Holidays

USA 800-323-4329 • Canada 800-245-8777

iMBK125E

VEHICLE APPLICATIONS**MERCEDES**

2003-06 E-CLASS

MBK125E Mounting Kit