

2001-04 VOLVO S60/V70/XC70

DASH DISASSEMBLY

1. Remove Ashtray and shift lever trim.
2. Carefully remove the shifter trim bezel.
3. Remove (2) T-25 Torx Head Screws from the bottom of the climate control panel, remove.
4. Remove (2) T-25 Torx Head Screws from the bottom of the factory radio, remove.

DIN MOUNT INSTALLATION INSTRUCTIONS

Requires new radio's metal sleeve

1. Remove factory radio brackets, reinstall onto the VVOK1055.
2. Insert DIN metal-sleeve from your new radio into the radio opening of the installation kit.
3. Depress the tabs from inside the sleeves opening upward, outward, and downward to secure sleeve to the installation kit.
4. Slide new radio through DIN metal-Sleeve until it locks in place



**American
International**
Car Stereo Installation Kits & Accessories



VVOK1055 Mounting Kit



American International

WWW.AIUS.NET

2500 East Francis Street Ontario, CA 91761, U.S.A.

USA Sales (800) 336-6500

Canada Sales (888) 922-3006

CUSTOMER HELP LINE

8am-4:30 P.S.T. Monday-Friday Except Holidays

USA 800-323-4329 • Canada 800-245-8777

IVVOK1055

VEHICLE APPLICATIONS

VOLVO

2001-04 S60

2001-04 V70

2001-04 XC70