



SSV WORKS, 201 N. Rice Ave Unit A, Oxnard, CA 93030
www.SSVworks.com | Phone: 818-991-1778 | Fax: 866-293-6751

RZ4-F65

RZR XP1000 & 2014+ RZR900
6.5" Speaker Front Kick Panels

WARRANTY INFORMATION:

All SSV Works enclosures are covered by a limited lifetime warranty against defects in material or workmanship. All SSV Works Electronics are covered by a limited 1 year warranty against defects in material or workmanship. All SSV Works Speakers are covered by a limited 1 year warranty against defects in material or workmanship. Labor for replacement of defective components is not covered. Contact SSV Works for further warranty information.



Please read and understand these instructions completely before installation to avoid possible injury, or damage to the accessory or vehicle.

TOOLS NEEDED FOR INSTALLATION

- T-40 Torx Driver

- #2 Phillips Screwdriver

PARTS LIST IMAGES



1. RZ4-F65 Enclosures
(1 pair)



2. #14 Screws x4



3. #7 Screws x8



A

A. Starting at driver side footwell, remove the factory T40 torx screw as shown.



B

B. Place the driver kick pod into location so that both vehicle screw bosses line up with kick pod brackets.

**C**

C. Using (x2) #14 screw loosely secure the kick pod to the factory screw bosses.

**D**

D. Re-use the factory T40 torx screw previously removed in Step A to loosely bolt through the lower kick pod bracket to vehicle panel.

**E**

E. Connect the B-H1149 cable to the speaker pod and zip tie all cables to the frame.

F. Once all three screws are in place go back and re-tighten. Repeat steps 1-5 to install passenger kick pod.