
Manuel d'utilisation / User manual





Français page 4 English page 5 Deutsch p 6 Italiano p 7 Español p 8 Português p 9 Nederlands p 10 Pyccкий p 11 中文 第12页 日本語第13页 한국어 페이지 (14)

Manuel d'utilisation / User manual

2

Connection Subwoofer E 25KX et E 30KX /E 25KX and E 30KX subwoofer connection





Manuel d'utilisation / User manual

## Caisson clos / Sealed enclosure

	E 25KX	E 30KX
Volume	F-3 (Hz)	F-3 (Hz)
15L 0.52 cu.ft.	51 Hz	
20L 0.70 cu.ft.	48 Hz	
30L 1.05 cu.ft.		45 Hz
35L 1.23 cu.ft.		41 Hz
40L 1.4 cu.ft.		43 Hz

## Caisson bass reflex / Ported enclosure

	E 25KX		
Volume	F-3	Ø event	LG event
	(Hz)	Ø port	Port lenght
22L	33 Hz	8 cm -	35 cm -
0.88 cu.ft.		3 <sup>5/32</sup> "	13 <sup>25/32</sup> "
30L	27 Hz	8 cm -	43 cm -
1.05 cu.ft.		3 <sup>5/32</sup> "	16 <sup>15/16</sup> "

	E 30KX			
Volume	F-3	Ø event	LG event	
	(Hz)	Ø port	Port lenght	
35L	30 Hz	8 cm -	35 cm -	
1.58 cu.ft.		3 <sup>5/32</sup> "	13 <sup>25/32</sup> "	
50L 1.76 cu.ft.	29 Hz	10 cm - 3 <sup>15/16</sup> "	40 cm - 15 <sup>3/4</sup> "	

User manual

English

Register your product online at www.focal.com/warranty and get your certificate of quarants;



## Warning

The performance of the Focal E 25KX and E 30KX allows high sound pressure levels to be generated. We remind you that sustained listening beyond 110dB SPL can permanently and irreversibly damage your hearing. We recommend that you adjust the level of your equipment correspondingly.

## Important recommendations

First of all, check the space available for the loudspeakers (see the plans on the packaging) and then start cutting. If the loudspeakers are to be mounted in their original place, check whether there is enough space between the loudspeaker and the protective grating.

- Keep the loudspeakers away from metal chips and dust.
- Clean carefully prior to mounting the loudspeakers.

### Warranty conditions

If you encounter problems, contact your Focal distributor first. For all Focal equipment, the warranty applicable to France covers a 2-year period as of the purchase date and is non-transmissible in case of resale. In the event of faulty equipment, it should be sent, at your own expense, in its original packaging to your distributor, who will then check the equipment and determine the nature of the problem. If it is under warranty, the equipment will be returned to you or replaced "postage paid". Otherwise, a quote for repair will be sent to you. The warranty does not cover damage arising from improper use or incorrect connection (e.g. burned voice coils...)

#### **Environmental information**

Your Focal-JMlab product has been designed and manufactured using high quality materials and components, which can be recycled and reused. This symbol signifies that the electrical and electronic devices, at the end of their life, should be disposed of separately from household waste. Please take this device to the local collection point or to a recycling centre. You will thus contribute to environmental conservation.



