



HOW TO USE THIS INSTALL GUIDE

- 1** Open the Bookmarks menu and find your vehicle OR scroll down until you find the install guide for your vehicle.
- 2** Print only the pages for your vehicle using the advanced options in the Print menu.
- 3** Install your Maestro RR according to the guide for your vehicle.

WARNING

Pressing the printer icon or “quick printing” this document will print all of the guides in this compilation.

RETAINS STEERING WHEEL CONTROLS, FACTORY AMPLIFIER, AND MORE!



**HEAD UNIT
ADAPTER READY KIT**



PRODUCTS REQUIRED

iDatalink Maestro RR or RR2 Radio Replacement Interface
iDatalink Maestro EDG2 Dash Kit

PROGRAMMED FIRMWARE

ADS-RR(SR)-FOR02C-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)

HEAD UNIT ADAPTER:
ACC-HU-PI01, SON1, KEN1, KEN2, ALP1

WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	7
Radio Wire Reference Chart	8
Module Diagnostics	9
Troubleshooting Table	10

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

INSTALLATION INSTRUCTIONS P1/4

DASH DISASSEMBLY

NOTE: Requires shallow mount radio.

1. Using a panel tool, carefully pry outward on the center console trim panels. (Fig. 1.1)
2. Engage the parking brake, turn the ignition ON, and place the shifter in drive. Lift the upper center console trim panel, disconnect the two wiring harnesses, and remove the panel. (Fig. 1.2)
3. Pull down on the shifter boot (Fig. 1.3) and remove the two Phillips screws securing the shifter in place. Remove the shift knob. (Fig. 1.4)
4. Remove the four 7mm screws securing the storage pocket. Disconnect the wiring harness and USB cables. (Fig. 1.5)
5. Remove the five 7mm screws securing the shifter carriage. Disconnect the wire harness and remove the carriage. (Fig. 1.6)
6. Place the transmission into park and turn the ignition off.
7. Remove the two 7mm screws at the base of the radio bezel. Using a panel tool, gently pry outward on the radio bezel to release the clips securing it. Disconnect the wire harnesses from the back. (Fig. 1.7)
8. Remove the four 7mm screws securing the radio display. Disconnect the wiring harness and remove the display. Remove the two 7mm screws at the bottom of the CD player. Disconnect the wire harnesses and antenna connections. Remove the CD player. (Fig. 1.8)
9. To make room for a double DIN radio chassis, cut the plastic sub dash brace as shown. (Fig. 1.9)
10. Open the glove compartment and push up on the retaining clips securing it. Slide the control arm off the side of the glove compartment to allow it to open completely. (Fig. 1.10)
11. The SYNC module is located above the glove compartment. Disconnect the main 54-pin wiring harness from the module.




Fig. 1.1




Fig. 1.2




Fig. 1.3




Fig. 1.4




Fig. 1.5




Fig. 1.6




Fig. 1.7




Fig. 1.8




Fig. 1.9




Fig. 1.10

INSTALLATION INSTRUCTIONS P2/4

DISASSEMBLE FACTORY RADIO

1. Remove the climate vents from the bezel assembly by releasing the two clips securing them. (Fig. 2.1)
2. Remove the eighteen T9 Torx screws securing the backplate. Remove the connector housing. (Fig. 2.2)
3. Remove the backplate from the bezel (Fig. 2.3)
4. Pull outward on the ribbon cable connector at the top of the climate control board. (Fig. 2.4)
5. Flip the climate board down to expose the ribbon cable on the back side. (Fig. 2.5)
6. Pull outward to disconnect the ribbon cable. (Fig. 2.6)
7. Remove the six T6 Torx screws securing the upper bezel to the climate controls and remove the upper radio bezel. This will not be used. (Fig. 2.7)
8. Remove the factory USB housing from the pocket. Depress the four tabs using a small pick tool. (Fig. 2.8)




Fig. 2.1




Fig. 2.2




Fig. 2.3




Fig. 2.4




Fig. 2.5




Fig. 2.6




Fig. 2.7




Fig. 2.8

INSTALLATION INSTRUCTIONS P3/4

ASSEMBLE THE EDG2 DASH KIT

1. Place the EDG2 display trim onto the factory climate bezel. Secure it with the six included Phillips screws. (Fig. 3.1)
2. Reconnect the climate control board to the climate housing. (Fig. 3.2)
3. Snap the EDG2 backplate onto the bezel assembly and secure with the four included Phillips screws (Fig. 3.3)
4. Reinstall the connector housing removed earlier. Secure the backplate with the ten included Phillips screws. (Fig. 3.4)
5. Install the four metal clips and rubber stops on to the back of the bezel. (Fig. 3.5)
6. Attach the climate vents on to the EDG2 assembly making sure the clips snap into place. (Fig. 3.6)
7. Install the CD slot cover provided with the EDG2. (Fig. 3.7)
8. Install in the pocket the correct size USB housing provided with the EDG2.
9. Place the EDG2 radio brackets on to the aftermarket radio and secure with the hardware provided with the radio. (Fig. 3.8)




Fig. 3.1




Fig. 3.2




Fig. 3.3




Fig. 3.4




Fig. 3.5




Fig. 3.6




Fig. 3.7




Fig. 3.8

INSTALLATION INSTRUCTIONS P4 / 4

MAKE CONNECTIONS (refer to wiring diagram)

1. If using head unit adapter (sold separately), connect HRR-EDG2 harness to adapter and skip to step 2.

- Locate aftermarket radio's main harness.
- Cut and remove the black 20 pin connector from the HRR-EDG2 T-harness and connect the wires, shown in the wiring diagram, from aftermarket radio main harness to the HRR-EDG2 T-harness and match the wire functions.

Note: only connect purple/white wire to radio reverse input or module damage will occur.

2. Connect the EDG2 harness to the main factory radio wiring harness.

- Connect the supplied antenna adapter to the black factory antenna connection.
- Connect the reverse camera harness to the factory display harness. Connect the yellow 2-pin plug to the main EDG2 harness.

3. Connect the secondary harness to the 54-pin SYNC module harness above glove box.

- Connect the black 2-pin plug to the main EDG2 harness.

4. Connect all harnesses to the Maestro RR module.

5. Route the T-harness assembly and antenna adapter to the upper dash cavity.

- Route the supplied USB-C or USB-A cables from the pocket location to the upper dash cavity.

Make all connections to the back of the aftermarket radio:

- Connect the antenna.
- Connect the camera RCA cable (in the BC IN or rear-view camera input).
- Connect the 4-pin data cable to the data port.
- Insert the audio cable into the iDatalink 3.5mm audio jack of the aftermarket radio (labeled iDatalink. If there is no iDatalink audio input, connect to AUX).


Note: When using a Pioneer radio, please ensure that there is nothing plugged into the W/R port of the radio.

Fit the radio into the dash cavity and secure it with the four 7mm screws removed earlier.


Assembly is the reverse order of disassembly. Make sure to install the two USB cables in the back of the pocket housing, making sure they click into place.

WIRING DIAGRAM


STEP 1




STEP 5




STEP 2





STEP 3



STEP 4



NOT REQUIRED



RADIO WIRE REFERENCE CHART

EDG2 T-harness Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood/ JVC cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light*	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A
Power Antenna	(+)	Blue	Blue	Blue	Blue/White	Blue or Blue/White

Head unit adapter wiring (optional accessory, sold separately)

ACC-HU-ALP1 Wire Description	Polarity	Wire Color on Adapter	Alpine Radio
VSS (vehicle speed sensor)	(DATA)	Green/White	Green/White

ACC-HU-KEN1 Wire Description	Polarity	Wire Color on Adapter	Kenwood Radio
CAM	(+)	Green/Red	Refer to camera/radio manual
CAM	(-)	Green/White	Refer to camera/radio manual
Steering Wheel Controls	(DATA)	Blue/Yellow	n/a

ACC-HU-KEN2 Wire Description	Polarity	Wire Color on Adapter	Kenwood Radio
E-Brake	(-)	LtGreen	LtGreen
Reverse Light*	(+)	Purple/White	Purple/White
Steering Wheel Controls	(DATA)	Blue/Yellow	n/a

* Reverse light wire: Only connect to radio or module damage will occur.

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure SYNC module connector is securely attached to the SYNC connector of the vehicle.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
The light on the Maestro is blinking RED TWICE and the radio IS NOT turning on.	<p>If installing a modular radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error as well.</p> <p>Test red and yellow wires for DC voltage at radio using a multimeter. Contact support if no voltage on red or yellow.</p>
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>

MAESTRO RR RESET PROCEDURE:


Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999
 Email: maestro.support@idatalink.com

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, FACTORY AMPLIFIER, AND MORE!



**HEAD UNIT
ADAPTER READY KIT**



PRODUCTS REQUIRED

iDatalink Maestro RR or RR2 Radio Replacement Interface
iDatalink Maestro EDG2 Dash Kit

PROGRAMMED FIRMWARE

ADS-RR(SR)-FOR02C-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)

HEAD UNIT ADAPTER:
ACC-HU-PI01, SON1, KEN1, KEN2, ALP1

WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	7
Radio Wire Reference Chart	8
Module Diagnostics	9
Troubleshooting Table	10

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

INSTALLATION INSTRUCTIONS P1/4

DASH DISASSEMBLY

NOTE: Requires shallow mount radio.

1. Using a panel tool, carefully pry outward on the center console trim panels. (Fig. 1.1)
2. Engage the parking brake, turn the ignition ON, and place the shifter in drive. Lift the upper center console trim panel, disconnect the two wiring harnesses, and remove the panel. (Fig. 1.2)
3. Pull down on the shifter boot (Fig. 1.3) and remove the two Phillips screws securing the shifter in place. Remove the shift knob. (Fig. 1.4)
4. Remove the four 7mm screws securing the storage pocket. Disconnect the wiring harness and USB cables. (Fig. 1.5)
5. Remove the five 7mm screws securing the shifter carriage. Disconnect the wire harness and remove the carriage. (Fig. 1.6)
6. Place the transmission into park and turn the ignition off.
7. Remove the two 7mm screws at the base of the radio bezel. Using a panel tool, gently pry outward on the radio bezel to release the clips securing it. Disconnect the wire harnesses from the back. (Fig. 1.7)
8. Remove the four 7mm screws securing the radio display. Remove the radio display and disconnect the wiring harness, USB cable, and antenna connections. Remove the two 7mm screws at the bottom of the audio control module. Disconnect the wire harnesses. Remove the audio control module. (Fig. 1.8)
9. To make room for a double DIN radio chassis, cut the plastic sub dash brace as shown. (Fig. 1.9)




Fig. 1.1




Fig. 1.2




Fig. 1.3




Fig. 1.4




Fig. 1.5




Fig. 1.6




Fig. 1.7




Fig. 1.8




Fig. 1.9

INSTALLATION INSTRUCTIONS P2/4

DISASSEMBLE FACTORY RADIO

1. Remove the climate vents from the bezel assembly by releasing the two clips securing them. (Fig. 2.1)
2. Remove the eighteen T9 Torx screws securing the backplate. Remove the connector housing. (Fig. 2.2)
3. Remove the backplate from the bezel (Fig. 2.3)
4. Pull outward on the ribbon cable connector at the top of the climate control board. (Fig. 2.4)
5. Flip the climate board down to expose the ribbon cable on the back side. (Fig. 2.5)
6. Pull outward to disconnect the ribbon cable. (Fig. 2.6)
7. Remove the six T6 Torx screws securing the upper bezel to the climate controls and remove the upper radio bezel. This will not be used. (Fig. 2.7)
8. Remove the factory USB housing from the pocket. Depress the four tabs using a small pick tool. (Fig. 2.8)




Fig. 2.1




Fig. 2.2




Fig. 2.3




Fig. 2.4




Fig. 2.5




Fig. 2.6




Fig. 2.7




Fig. 2.8

INSTALLATION INSTRUCTIONS P3/4

ASSEMBLE THE EDG2 DASH KIT

1. Place the EDG2 display trim onto the factory climate bezel. Secure it with the six included Phillips screws. (Fig. 3.1)
2. Reconnect the climate control board to the climate housing. (Fig. 3.2)
3. Snap the EDG2 backplate onto the bezel assembly and secure with the four included Phillips screws (Fig. 3.3)
4. Reinstall the connector housing removed earlier. Secure the backplate with the ten included Phillips screws. (Fig. 3.4)
5. Install the four metal clips and rubber stops on to the back of the bezel. (Fig. 3.5)
6. Attach the climate vents on to the EDG2 assembly making sure the clips snap into place. (Fig. 3.6)
7. Install in the pocket the correct size USB housing provided with the EDG2.
8. Place the EDG2 radio brackets on to the aftermarket radio and secure with the hardware provided with the radio. (Fig. 3.8)




Fig. 3.1




Fig. 3.2




Fig. 3.3




Fig. 3.4




Fig. 3.5




Fig. 3.6




Fig. 3.8

INSTALLATION INSTRUCTIONS P4/4

MAKE CONNECTIONS (refer to wiring diagram)

1. If using head unit adapter (sold separately), connect HRR-EDG2 harness to adapter and skip to step 2.

- Locate aftermarket radio's main harness.
- Cut and remove the black 20 pin connector from the HRR-EDG2 T-harness and connect the wires, shown in the wiring diagram, from aftermarket radio main harness to the HRR-EDG2 T-harness and match the wire functions.

Note: only connect purple/white wire to radio reverse input or module damage will occur.

2. Connect the EDG2 harness to the main factory radio wiring harness.

- Connect the supplied antenna adapter to the black factory antenna connection.
- Connect the secondary harness to the 54-pin SYNC module harness behind radio.
- Connect the black and yellow 2-pin plugs to the main EDG2 harness.

3. Connect all harnesses to the Maestro RR module.

4. Route the T-harness assembly and antenna adapter to the upper dash cavity.

- Route the supplied USB-C or USB-A cables from the pocket location to the upper dash cavity.

Make all connections to the back of the aftermarket radio:

- Connect the antenna.
- Connect the camera RCA cable (in the BC IN or rear-view camera input).
- Connect the 4-pin data cable to the data port.
- Insert the audio cable into the iDatalink 3.5mm audio jack of the aftermarket radio (labeled iDatalink. If there is no iDatalink audio input, connect to AUX).


Note: When using a Pioneer radio, please ensure that there is nothing plugged into the W/R port of the radio.

Fit the radio into the dash cavity and secure it with the four 7mm screws removed earlier.


Assembly is the reverse order of disassembly. Make sure to install the two USB cables in the back of the pocket housing, making sure they click into place.

WIRING DIAGRAM


STEP 1




STEP 5



STEP 2



STEP 4



RADIO WIRE REFERENCE CHART

EDG2 T-harness Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood/ JVC cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light*	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A
Power Antenna	(+)	Blue	Blue	Blue	Blue/White	Blue or Blue/White

Head unit adapter wiring (optional accessory, sold separately)

ACC-HU-ALP1 Wire Description	Polarity	Wire Color on Adapter	Alpine Radio
VSS (vehicle speed sensor)	(DATA)	Green/White	Green/White









ACC-HU-KEN1 Wire Description	Polarity	Wire Color on Adapter	Kenwood Radio
CAM	(+)	Green/Red	Refer to camera/radio manual
CAM	(-)	Green/White	Refer to camera/radio manual
Steering Wheel Controls	(DATA)	Blue/Yellow	n/a

ACC-HU-KEN2 Wire Description	Polarity	Wire Color on Adapter	Kenwood Radio
E-Brake	(-)	LtGreen	LtGreen
Reverse Light*	(+)	Purple/White	Purple/White
Steering Wheel Controls	(DATA)	Blue/Yellow	n/a

* Reverse light wire: Only connect to radio or module damage will occur.

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
 or 		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure SYNC module connector is securely attached to the SYNC connector of the vehicle.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
The light on the Maestro is blinking RED TWICE and the radio IS NOT turning on.	<p>If installing a modular radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error as well.</p> <p>Test red and yellow wires for DC voltage at radio using a multimeter. Contact support if no voltage on red or yellow.</p>
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999
 Email: maestro.support@idatalink.com

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, FACTORY AMPLIFIER, AND MORE!



HEAD UNIT
ADAPTER READY KIT



PRODUCTS REQUIRED

iDatalink Maestro RR or RR2 Radio Replacement Interface
iDatalink Maestro EDG2 Dash Kit

PROGRAMMED FIRMWARE

ADS-RR(SR)-FOR02C-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)

HEAD UNIT ADAPTER:
ACC-HU-PI01, SON1, KEN1, KEN2, ALP1

WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	7
Radio Wire Reference Chart	8
Module Diagnostics	9
Troubleshooting Table	10

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

INSTALLATION INSTRUCTIONS P1/4

DASH DISASSEMBLY

NOTE: Requires shallow mount radio.

1. Using a panel tool, carefully pry outward on the center console trim panels. (Fig. 1.1)
2. Engage the parking brake, turn the ignition ON, and place the shifter in drive. Lift the upper center console trim panel, disconnect the two wiring harnesses, and remove the panel. (Fig. 1.2)
3. Pull down on the shifter boot (Fig. 1.3) and remove the two Phillips screws securing the shifter in place. Remove the shift knob. (Fig. 1.4)
4. Remove the four 7mm screws securing the storage pocket. Disconnect the wiring harness and USB cables. (Fig. 1.5)
5. Remove the five 7mm screws securing the shifter carriage. Disconnect the wire harness and remove the carriage. (Fig. 1.6)
6. Place the transmission into park and turn the ignition off.
7. Remove the two 7mm screws at the base of the radio bezel. Using a panel tool, gently pry outward on the radio bezel to release the clips securing it. Disconnect the wire harnesses from the back. (Fig. 1.7)
8. Remove the four 7mm screws securing the radio display. Disconnect the wiring harness and remove the display. Remove the two 7mm screws at the bottom of the CD player. Disconnect the wire harnesses and antenna connections. Remove the CD player. (Fig. 1.8)
9. To make room for a double DIN radio chassis, cut the plastic sub dash brace as shown. (Fig. 1.9)




Fig. 1.1




Fig. 1.2




Fig. 1.3




Fig. 1.4




Fig. 1.5




Fig. 1.6




Fig. 1.7




Fig. 1.8




Fig. 1.9

INSTALLATION INSTRUCTIONS P2/4

DISASSEMBLE FACTORY RADIO

1. Remove the climate vents from the bezel assembly by releasing the two clips securing them. (Fig. 2.1)
2. Remove the eighteen T9 Torx screws securing the backplate. Remove the connector housing. (Fig. 2.2)
3. Remove the backplate from the bezel (Fig. 2.3)
4. Pull outward on the ribbon cable connector at the top of the climate control board. (Fig. 2.4)
5. Flip the climate board down to expose the ribbon cable on the back side. (Fig. 2.5)
6. Pull outward to disconnect the ribbon cable. (Fig. 2.6)
7. Remove the six T6 Torx screws securing the upper bezel to the climate controls and remove the upper radio bezel. This will not be used. (Fig. 2.7)
8. Remove the factory USB housing from the pocket. Depress the four tabs using a small pick tool. (Fig. 2.8)




Fig. 2.1




Fig. 2.2




Fig. 2.3




Fig. 2.4




Fig. 2.5




Fig. 2.6




Fig. 2.7




Fig. 2.8

INSTALLATION INSTRUCTIONS P3/4

ASSEMBLE THE EDG2 DASH KIT

1. Place the EDG2 display trim onto the factory climate bezel. Secure it with the six included Phillips screws. (Fig. 3.1)
2. Reconnect the climate control board to the climate housing. (Fig. 3.2)
3. Snap the EDG2 backplate onto the bezel assembly and secure with the four included Phillips screws (Fig. 3.3)
4. Preinstall the connector housing removed earlier. Secure the backplate with the ten included Phillips screws. (Fig. 3.4)
5. Install the four metal clips and rubber stops on to the back of the bezel. (Fig. 3.5)
6. Attach the climate vents on to the EDG2 assembly making sure the clips snap into place. (Fig. 3.6)
7. Install the CD slot cover provided with the EDG2. (Fig. 3.7)
8. Install in the pocket the correct size USB housing provided with the EDG2.
9. Place the EDG2 radio brackets on to the aftermarket radio and secure with the hardware provided with the radio. (Fig. 3.8)




Fig. 3.1




Fig. 3.2




Fig. 3.3




Fig. 3.4




Fig. 3.5




Fig. 3.6




Fig. 3.7




Fig. 3.8

INSTALLATION INSTRUCTIONS P4/4

MAKE CONNECTIONS (refer to wiring diagram)

1. If using head unit adapter (sold separately), connect HRR-EDG2 harness to adapter and skip to step 2.

- Locate aftermarket radio's main harness.
- Cut and remove the black 20 pin connector from the HRR-EDG2 T-harness and connect the wires, shown in the wiring diagram, from aftermarket radio main harness to the HRR-EDG2 T-harness and match the wire functions.

Note: only connect purple/white wire to radio reverse input or module damage will occur.

2. Connect the EDG2 harness to the main factory radio wiring harness.

- Connect the supplied antenna adapter to the black factory antenna connection.
- Connect the reverse camera harness to the factory display harness. Connect the yellow 2-pin plug to the main EDG2 harness.
- Connect the secondary harness to the 54-pin SYNC module harness behind radio.
- Connect the black 2-pin plug to the main EDG2 harness.

3. Connect all harnesses to the Maestro RR module.

4. Route the T-harness assembly and antenna adapter to the upper dash cavity.

- Route the supplied USB-C or USB-A cables from the pocket location to the upper dash cavity.

Make all connections to the back of the aftermarket radio:

- Connect the antenna.
- Connect the camera RCA cable (in the BC IN or rear-view camera input).
- Connect the 4-pin data cable to the data port.
- Insert the audio cable into the iDatalink 3.5mm audio jack of the aftermarket radio (labeled iDatalink. If there is no iDatalink audio input, connect to AUX).


Note: When using a Pioneer radio, please ensure that there is nothing plugged into the W/R port of the radio.

Fit the radio into the dash cavity and secure it with the four 7mm screws removed earlier.


Assembly is the reverse order of disassembly. Make sure to install the two USB cables in the back of the pocket housing, making sure they click into place.

WIRING DIAGRAM


STEP 1




STEP 5





STEP 2



STEP 4



NOT REQUIRED



RADIO WIRE REFERENCE CHART

EDG2 T-harness Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood/ JVC cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light*	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A
Power Antenna	(+)	Blue	Blue	Blue	Blue/White	Blue or Blue/White

Head unit adapter wiring (optional accessory, sold separately)

ACC-HU-ALP1 Wire Description	Polarity	Wire Color on Adapter	Alpine Radio
VSS (vehicle speed sensor)	(DATA)	Green/White	Green/White

ACC-HU-KEN1 Wire Description	Polarity	Wire Color on Adapter	Kenwood Radio
CAM	(+)	Green/Red	Refer to camera/radio manual
CAM	(-)	Green/White	Refer to camera/radio manual
Steering Wheel Controls	(DATA)	Blue/Yellow	n/a

ACC-HU-KEN2 Wire Description	Polarity	Wire Color on Adapter	Kenwood Radio
E-Brake	(-)	LtGreen	LtGreen
Reverse Light*	(+)	Purple/White	Purple/White
Steering Wheel Controls	(DATA)	Blue/Yellow	n/a

* Reverse light wire: Only connect to radio or module damage will occur.

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure SYNC module connector is securely attached to the SYNC connector of the vehicle.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
The light on the Maestro is blinking RED TWICE and the radio IS NOT turning on.	<p>If installing a modular radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error as well.</p> <p>Test red and yellow wires for DC voltage at radio using a multimeter. Contact support if no voltage on red or yellow.</p>
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999
 Email: maestro.support@idatalink.com

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.

RETAINS STEERING WHEEL CONTROLS, FACTORY AMPLIFIER, AND MORE!



**HEAD UNIT
 ADAPTER READY KIT**



PRODUCTS REQUIRED

iDatalink Maestro RR or RR2 Radio Replacement Interface
 iDatalink Maestro EDG2 Dash Kit

PROGRAMMED FIRMWARE

ADS-RR(SR)-FOR02C-DS

ADDITIONAL RESOURCES

[Maestro RR2 Programmable Outputs Guide](#)

OPTIONAL ACCESSORIES



Click here for:
[Radar Installation Guides](#)

HEAD UNIT ADAPTER:
 ACC-HU-PI01, SON1, KEN1, KEN2, ALP1

WELCOME

Congratulations on the purchase of your iDatalink Maestro RR Radio replacement solution. You are now a few simple steps away from enjoying your new car radio with enhanced features.

Before starting your installation, please ensure that your iDatalink Maestro module is programmed with the correct firmware for your vehicle and that you carefully review the install guide.

Please note that Maestro RR will only retain functionalities that were originally available in the vehicle.

TABLE OF CONTENTS

Installation Instructions	3
Wiring Diagram	7
Radio Wire Reference Chart	8
Module Diagnostics	9
Troubleshooting Table	10

NEED HELP?

 1 866 427-2999

 maestro.support@idatalink.com

INSTALLATION INSTRUCTIONS P1/4

DASH DISASSEMBLY

NOTE: Requires shallow mount radio.

1. Using a panel tool, carefully pry outward on the center console trim panels. (Fig. 1.1)
2. Engage the parking brake, turn the ignition ON, and place the shifter in drive. Lift the upper center console trim panel, disconnect the two wiring harnesses, and remove the panel. (Fig. 1.2)
3. Pull down on the shifter boot (Fig. 1.3) and remove the two Phillips screws securing the shifter in place. Remove the shift knob. (Fig. 1.4)
4. Remove the four 7mm screws securing the storage pocket. Disconnect the wiring harness and USB cables. (Fig. 1.5)
5. Remove the five 7mm screws securing the shifter carriage. Disconnect the wire harness and remove the carriage. (Fig. 1.6)
6. Place the transmission into park and turn the ignition off.
7. Remove the two 7mm screws at the base of the radio bezel. Using a panel tool, gently pry outward on the radio bezel to release the clips securing it. Disconnect the wire harnesses from the back. (Fig. 1.7)
8. Remove the four 7mm screws securing the radio display. Remove the radio display and disconnect the wiring harness, USB cable, and antenna connections. Remove the two 7mm screws at the bottom of the audio control module. Disconnect the wire harnesses. Remove the audio control module. (Fig. 1.8)
9. To make room for a double DIN radio chassis, cut the plastic sub dash brace as shown. (Fig. 1.9)




Fig. 1.1




Fig. 1.2




Fig. 1.3




Fig. 1.4




Fig. 1.5




Fig. 1.6




Fig. 1.7




Fig. 1.8




Fig. 1.9

INSTALLATION INSTRUCTIONS P2/4

DISASSEMBLE FACTORY RADIO

1. Remove the climate vents from the bezel assembly by releasing the two clips securing them. (Fig. 2.1)
2. Remove the eighteen T9 Torx screws securing the backplate. Remove the connector housing. (Fig. 2.2)
3. Remove the backplate from the bezel (Fig. 2.3)
4. Pull outward on the ribbon cable connector at the top of the climate control board. (Fig. 2.4)
5. Flip the climate board down to expose the ribbon cable on the back side. (Fig. 2.5)
6. Pull outward to disconnect the ribbon cable. (Fig. 2.6)
7. Remove the six T6 Torx screws securing the upper bezel to the climate controls and remove the upper radio bezel. This will not be used. (Fig. 2.7)
8. Remove the factory USB housing from the pocket. Depress the four tabs using a small pick tool. (Fig. 2.8)




Fig. 2.1




Fig. 2.2




Fig. 2.3




Fig. 2.4




Fig. 2.5




Fig. 2.6




Fig. 2.7




Fig. 2.8

INSTALLATION INSTRUCTIONS P3/4

ASSEMBLE THE EDG2 DASH KIT

1. Place the EDG2 display trim onto the factory climate bezel. Secure it with the six included Phillips screws. (Fig. 3.1)
2. Reconnect the climate control board to the climate housing. (Fig. 3.2)
3. Snap the EDG2 backplate onto the bezel assembly and secure with the four included Phillips screws (Fig. 3.3)
4. Reinstall the connector housing removed earlier. Secure the backplate with the ten included Phillips screws. (Fig. 3.4)
5. Install the four metal clips and rubber stops on to the back of the bezel. (Fig. 3.5)
6. Attach the climate vents on to the EDG2 assembly making sure the clips snap into place. (Fig. 3.6)
7. Install in the pocket the correct size USB housing provided with the EDG2.
8. Place the EDG2 radio brackets on to the aftermarket radio and secure with the hardware provided with the radio. (Fig. 3.8)




Fig. 3.1




Fig. 3.2




Fig. 3.3




Fig. 3.4




Fig. 3.5




Fig. 3.6




Fig. 3.8

INSTALLATION INSTRUCTIONS P4/4

MAKE CONNECTIONS (refer to wiring diagram)

1. If using head unit adapter (sold separately), connect HRR-EDG2 harness to adapter and skip to step 2.

- Locate aftermarket radio's main harness.
- Cut and remove the black 20 pin connector from the HRR-EDG2 T-harness and connect the wires, shown in the wiring diagram, from aftermarket radio main harness to the HRR-EDG2 T-harness and match the wire functions.

Note: only connect purple/white wire to radio reverse input or module damage will occur.

2. Connect the EDG2 harness to the main factory radio wiring harness.

- Connect the supplied antenna adapter to the black factory antenna connection.
- Connect the secondary harness to the 54-pin SYNC module harness behind radio.
- Connect the black and yellow 2-pin plugs to the main EDG2 harness.

3. Connect all harnesses to the Maestro RR module.

4. Route the T-harness assembly and antenna adapter to the upper dash cavity.

- Route the supplied USB-C or USB-A cables from the pocket location to the upper dash cavity.

Make all connections to the back of the aftermarket radio:

- Connect the antenna.
- Connect the camera RCA cable (in the BC IN or rear-view camera input).
- Connect the 4-pin data cable to the data port.
- Insert the audio cable into the iDatalink 3.5mm audio jack of the aftermarket radio (labeled iDatalink. If there is no iDatalink audio input, connect to AUX).


Note: When using a Pioneer radio, please ensure that there is nothing plugged into the W/R port of the radio.

Fit the radio into the dash cavity and secure it with the four 7mm screws removed earlier.


Assembly is the reverse order of disassembly. Make sure to install the two USB cables in the back of the pocket housing, making sure they click into place.

WIRING DIAGRAM


STEP 1




STEP 5



STEP 2



STEP 4



NOT REQUIRED



RADIO WIRE REFERENCE CHART

EDG2 T-harness Wire Description	Polarity	Wire Color on Maestro T-Harness	Wire Color on Alpine cable	Wire Color on Kenwood/ JVC cable	Wire Color on Pioneer cable	Wire Color on Sony cable
Illumination	(+)	Orange	N/A	Orange/White	Orange/White	Orange
Reverse Light*	(+)	Purple/White	Orange/White	Purple/White	Purple/White	Purple/White
E-Brake	(-)	Lt Green	Yellow/Blue	Lt Green	Lt Green	Lt Green
VSS (vehicle speed sensor)	(DATA)	Pink	Green/White	Pink	Pink	N/A
Power Antenna	(+)	Blue	Blue	Blue	Blue/White	Blue or Blue/White

Head unit adapter wiring (optional accessory, sold separately)

ACC-HU-ALP1 Wire Description	Polarity	Wire Color on Adapter	Alpine Radio
VSS (vehicle speed sensor)	(DATA)	Green/White	Green/White

ACC-HU-KEN1 Wire Description	Polarity	Wire Color on Adapter	Kenwood Radio
CAM	(+)	Green/Red	Refer to camera/radio manual
CAM	(-)	Green/White	Refer to camera/radio manual
Steering Wheel Controls	(DATA)	Blue/Yellow	n/a

ACC-HU-KEN2 Wire Description	Polarity	Wire Color on Adapter	Kenwood Radio
E-Brake	(-)	LtGreen	LtGreen
Reverse Light*	(+)	Purple/White	Purple/White
Steering Wheel Controls	(DATA)	Blue/Yellow	n/a

* Reverse light wire: Only connect to radio or module damage will occur.

MODULE DIAGNOSTICS



LED 1 Module/Firmware status	LED 2 (RR2) Bluetooth activity	LED STATUS	DIAGNOSTIC
or		RED or GREEN flashing	LED flashes 1 or more times, either red or green, when a steering wheel button is pressed : normal operation.
		1 RED flash	Module has no firmware. Flash module using Weblink Desktop and log in. Do <u>NOT</u> use DEMO MODE.
		2 RED flashes	Problem detected. Consult troubleshooting table.
		1 GREEN flash	After radio boots up : Normal operation.
		3 GREEN flashes	Bluetooth is activated. Turns off after one minute: Normal operation.
		OFF	Normal operation (inactive).

VIDEO HELP		Installation, product information, vehicle specific videos.
VERIFY FLASH		Last flash information, steering control configuration, vehicle information.
WEBLINK		Software to program module.

TROUBLESHOOTING TABLE

PROBLEM	SOLUTION
Gauges do not work, radio shows OBD2 Error 1 or Error 2.	<p>Ensure SYNC module connector is securely attached to the SYNC connector of the vehicle.</p> <p>If anything else is connected to the OBD2 or CAN wires of vehicle (programmer, throttle controller, insurance tracker, etc.) try unplugging it to see if gauges work. If gauges work without it installed, call tech support for options.</p> <p>Reset the RR.</p>
The light on the Maestro is blinking RED TWICE and the radio IS NOT turning on.	<p>If installing a modular radio and it is not turning on, ensure the screen is secured and any trim pieces on the radio have been installed fully. Not installing these fully will prevent radio from powering up and show a 2x red error as well.</p> <p>Test red and yellow wires for DC voltage at radio using a multimeter. Contact support if no voltage on red or yellow.</p>
The light on the Maestro is blinking RED TWICE and the radio IS turning on.	<p>Ensure the 4-pin data cable is connected between the radio and the RR, and that it is plugged into the black port on the Maestro RR. The red and blue ports on the RR should be empty.</p> <p>Make sure the correct radio model and serial number were entered during the flash. Verify the radio's serial number entered during the flash matches what is listed on the radio screen. This can be found in the settings of the radio, listed as Device Id, Device Number, or Serial Number.</p>

MAESTRO RR RESET PROCEDURE:

Turn the key to the OFF position, then disconnect all connectors from the module.
 Press and hold the module's programming button and connect all the connectors back to the module. Wait, the module's LED will flash RED rapidly (this may take up to 10 seconds).
 Release the programming button. Wait, the LED will turn solid GREEN for 2 seconds to show the reset was successful.

TECHNICAL ASSISTANCE

Phone: 1-866-427-2999
 Email: maestro.support@idatalink.com

IMPORTANT: To ensure proper operation, the aftermarket radio needs to have the latest firmware from the manufacturer. Please visit the radio manufacturer's website and look for any updates pertaining to your radio.