




**American  
International**  
*Car Stereo Installation Kits & Accessories*



# NDK746 Mounting Kit

## VEHICLE APPLICATION

Nissan  
2009-2020      370Z (Without Factory Navigation)

## DASH DISASSEMBLY INSTRUCTIONS

1. Using a soft tool, unclip the shifter panel.  
Note: This may include one or two pieces
2. Remove (2) Phillips screws from both side panels of the center console.  
Unclip and remove the panels.
3. Remove (2) Phillips screws from the bottom dash bezel with the air vents.  
Unclip and remove the panel.
4. Remove (4) Phillips screws securing the factory radio trim bezel and A/C control.
5. Remove (4) Phillips screws securing the factory radio to the subdash.
6. Remove (5) Phillips screws securing the climate controls to the dash trim bezel.  
Save for re assembly.
7. Remove (2) Phillips screws securing the climate control module to the OEM radio brackets. Save for reassembly.


## KIT ASSEMBLY INSTRUCTIONS

### Single ISO Mount Application

1. Install the OEM climate controls to the NDK746 main frame using the (5) screws removed during disassembly.
2. Install OEM climate control module into the NDK746 brackets using the (2) screw removed during disassembly.
3. Insert pocket into lower section of the brackets and snap into rear pocket support tabs.
4. Insert ISO mountable radio between ISO mount brackets and loosely attach to sides of radio using screws provided with radio when possible, or screws supplied with kit.
5. Using the main frame of the as a guide, slide radio forward or backward for desired look and then tighten screws to the radio.

Note: Attach a rear support bracket to the rear of the new radio and adjust as necessary to support the weight of the radio. Suggested

Figure A





## DOUBLE DIN INSTALLATION INSTRUCTIONS


### Double DIN ISO Mount Application

See Fig B for bracket tab removal.

1. Install the OEM climate controls to the NDK746 main frame using the (5) screws removed during disassembly.
2. Install OEM climate control module into the NDK746 brackets using the (2) screw removed during disassembly.
3. Remove rear pocket support tabs.
4. Insert ISO mountable radio between ISO mount brackets and loosely attach to sides of radio using screws provided with radio when possible, or screws supplied with kit.
5. Using the main frame of the as a guide, slide radio forward or backward for desired look and then tighten screws to the radio.

Note: Attach a rear support bracket to the rear of the new radio and adjust as necessary to support the weight of the radio. Suggested

Figure B





American International by PAC

Tech Support: [support@aampglobal.com](mailto:support@aampglobal.com) or 727-592-5991

Tech Support in Spanish/Para servicio técnico en español, llame al +1 727 205-0436

Find vehicle applications and additional information at [pac-audio.com](http://pac-audio.com)