

MAZK855 Mounting Kit



www.aampglobal.com **www.aius.net**
2500 East Francis Street Ontario, CA 91761, U.S.A.
Sales: (800) 477-2267
Intl: (727) 572-9255
Support: 888-228-5560

VEHICLE APPLICATION

Mazda
2013-2016 CX5
2014-2015 MAZDA6

DASH DISASSEMBLY & RADIO REMOVAL INSTRUCTIONS


1. Using a soft tool, carefully unclip center dash trim from above glove box to below the radio, working right to left.
2. Unplug hazard switch and remove panel.
3. Remove radio trim panel.
4. Remove (1) bolt from the bottom and (2) screws from the sides of the OEM Radio.
5. Unclip the OEM radio and remove. Unplug harness.

KIT ASSEMBLY INSTRUCTIONS

Single ISO Mounting Applications

1. This kit is an (ISO) mounting kit only. The mounting sleeve of your new radio and trim ring cannot be used when ISO mounting an aftermarket radio. Your radio must have a removeable trim ring.
2. Snap & screw the side trim pieces to the IMB855 L&R as shown in Figure A. DO NOT attach the (4) metal clips included with the kit yet.
3. Insert pocket into lower section of kit from rear & lock into slots of mounting brackets.
4. Insert ISO mountable radio between ISO mount brackets and loosely attach to sides of radio using screws provided with radio when possible or screws supplied with kit.
5. Slide radio forward or backward for desired look and tighten screws.
6. Test fit kit/radio by mounting it using the (2) OEM screws, and making sure the main frame of the MAZK855 aligns correctly and does not leave any gaps when installed. If everything looks correct go to step #7. If not, go back to step # 5.
7. Attach the metal panel fastener clips (included with kit) (4) to each mounting tab on the back side of the MAZK855 panel.
8. Attach a rear support bracket to the rear of the new radio and adjust as necessary to support the weight of the radio.

Fig. A



KIT ASSEMBLY INSTRUCTIONS

Double DIN Mounting Applications

1. Snap & screw the side trim pieces to the IMB855 L&R as shown Figure B. DO NOT attach the (4) metal clips included with the kit yet.
2. Insert radio between ISO mount brackets and loosely attach to sides of radio using screws provided with radio when possible or hardware included with kit.
3. Slide radio component forward or backward for desired look and tighten screws.
4. Test fit kit/radio by mounting it using the (2) OEM screws, and making sure the main frame of the MAZK855 aligns correctly and does not leave any gaps when installed. If everything looks correct go to step #5. If not, go back to step # 3.
5. Attach the metal panel fastener clips (included with kit) (4) to each mounting tab on the back side of the MAZK855 panel.
6. Attach a rear support bracket to the rear of the new radio and adjust as necessary to support the weight of the radio.

Fig. B

