

KIT ASSEMBLY INSTRUCTIONS


NOTE: Remove pocket support tabs from both right and left brackets (shaded) see figure C.

Double DIN & Double ISO Mount Applications


1. Cut and remove center rib from main frame and file edges smooth.
2. Attach the left and right side brackets to the main frame. See figure C below.
3. Attach (1) ISO Spacer to the inside of upper section on both Left & Right mounting brackets as shown in Fig. A. (See note #2 below)
4. Insert ISO mountable radio between ISO mount brackets and loosely attach to sides of radio using screws provided with radio when possible or hardware included with kit.
5. Slide radio component forward or backward for desired look and tighten screws.
6. Attach a rear support bracket to the rear of the radio components and adjust as needed to allow rear support bracket to rest in the sub-dash (Optional).

NOTE: 1) ISO trim ring (DITR726) must be used in place of after-market radio's trim rings. For ISO mount applications, mount after-market radio components to side brackets using screws provided with radio when possible or hardware included with kit.

2) Spacers must read upright (This side up for DBL ISO install).



**American
International**
Car Stereo Installation Kits & Accessories



VEHICLE APPLICATIONS

Nissan
2005-06 ALTIMA

NDK726 Mounting Kit

CUSTOMER HELP LINE
USA 800-336-6500 • Canada 800-245-8777

iNDK726


DASH DISASSEMBLY INSTRUCTIONS

1. Disconnect the Negative battery cable.
2. Carefully pry outward and forward the trim from around the Climate controls, disconnect the connector attached to the rear and remove trim.
3. Remove the (4) Phillips screws securing the Climate controls to the sub-dash, pull forward, and lower out of the way.
4. Carefully pry the Vent/Radio trim bezel forward and remove.
5. Remove the (4) Phillips screws securing the factory radio to the sub-dash.
6. Carefully pull radio forward, disconnect all harnesses and antenna lead from rear of radio and remove radio.

KIT ASSEMBLY INSTRUCTIONS

Single DIN Mount Applications

1. Attach the left and right side brackets to the main bracket. See Figure B opposite page.
2. Insert pocket (part # POC726) into lower section of the main frame.
3. Attach left and right side brackets to the rear of the pocket using screws supplied.
4. Insert DIN sleeve from your new radio into the upper section of the installation kit.
5. Depress the tabs from inside the sleeves opening upward, outward, and downward to secure sleeve to the installation kit.
6. Install radio into sleeve and lock into place.
7. Attach a rear support bracket to the rear of the new radio and adjust as necessary to attach to the rear support stud located on the back of the pocket using the small phillips screw supplied with kit (Optional).



NOTE: ISO trim ring (ITR-726) may be used in place of after-market radio's removable trim ring.

KIT ASSEMBLY INSTRUCTIONS

Single ISO Mount Applications

1. Attach the left and right side brackets to the main bracket. See Figure B.
2. Insert pocket (part # POC726) into lower section of the main frame.
3. Attach left and right side brackets to the rear of the pocket using screws supplied.
4. Attach (1) ISO Spacer to the inside of upper section on both Left & Right mounting brackets as shown in Fig. A. (See note #2 below)
5. Insert ISO mountable radio between ISO mount brackets and loosely attach to sides of radio using screws provided with radio when possible or hardware included with kit.
6. Slide radio component forward or backward for desired look and tighten screws.
7. Attach a rear support bracket to the rear of the new radio and adjust as necessary to attach to the rear support stud located on the back of the pocket using the small phillips screw supplied with kit (Optional).

NOTE: 1) ISO trim ring (ITR726) may be used in place of after-market radio's removable trim ring.
2) Spacers must read upright (This side up for single ISO install).

